

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ferm](#) /
- › [Ferm GRM1022 Home and Car High Pressure Washer User Manual](#)

Ferm GRM1022

Ferm GRM1022 Home and Car High Pressure Washer User Manual

Model: GRM1022

1. INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Ferm GRM1022 Home and Car High Pressure Washer. Please read these instructions carefully before using the appliance and retain them for future reference. The Ferm GRM1022 is designed for cleaning vehicles, machines, boats, and buildings by removing stubborn dirt using high-pressure water.



Figure 1: FERM GRM1022 High Pressure Washer. This image shows the pressure washer unit on a dark background, suggesting its robust design and readiness for use.

2. SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the appliance. Do not operate the pressure washer with a damaged cord or plug. Keep all connections dry and off the ground.
- **Water Pressure:** Never direct the water jet at people, animals, electrical equipment, or the appliance itself. High-pressure jets can be dangerous if misused.
- **Personal Protective Equipment:** Wear appropriate eye protection and protective clothing when operating the

pressure washer.

- **Stability:** Operate the pressure washer on a stable, level surface to prevent tipping.
- **Children and Bystanders:** Keep children and bystanders away from the operating area.
- **Maintenance:** Disconnect the appliance from the power supply before performing any cleaning or maintenance.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Ferm GRM1022 pressure washer.



Figure 2: Front view of the Ferm GRM1022 High Pressure Washer. This image displays the main unit, high-pressure hose, and spray lance assembly.





Figure 3: Angled view of the Ferm GRM1022 High Pressure Washer. This image provides a perspective of the unit with its integrated hose and power cord storage.

Key Components:

- **Main Unit:** Houses the motor, pump, and controls.
- **High-Pressure Hose:** Connects the main unit to the spray lance. (5 meters long)
- **Spray Lance:** For directing the high-pressure water jet. Includes various spray lances for adjustable spray strength.
- **Power Cord:** For connecting to the electrical supply. (5 meters long)
- **Water Inlet Filter:** Prevents debris from entering the pump.



Figure 4: Close-up of the control dial and brand logo. This image highlights the main control interface on the pressure washer unit.



Figure 5: Transparent water inlet filter. This component is crucial for protecting the pump from impurities in the water supply.

4. SETUP

1. **Unpack the Appliance:** Carefully remove all components from the packaging. Ensure all parts listed in the product overview are present.
2. **Connect the High-Pressure Hose:** Securely attach one end of the high-pressure hose to the outlet on the main unit and the other end to the spray lance. Ensure connections are tight to prevent leaks.
3. **Connect the Water Supply:** Attach a garden hose (not supplied) to the water inlet of the pressure washer. Ensure the water inlet filter is properly installed. Connect the other end of the garden hose to a water tap.
4. **Connect the Spray Lance:** Assemble the desired spray lance attachment to the spray gun.
5. **Connect to Power:** Plug the power cord into a suitable 240V electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Before Starting

- Ensure all connections (water, high-pressure hose, power) are secure.
- Open the water tap fully.
- Squeeze the trigger on the spray gun to purge air from the system until a steady stream of water emerges. This protects the pump.

5.2 Starting the Unit

1. Turn on the pressure washer using the power switch. The motor will start.
2. The automatic shutdown system will engage when the trigger is released, stopping the motor to save energy and reduce noise. The motor will restart when the trigger is squeezed again.

5.3 Adjusting Spray Strength

The Ferm GRM1022 comes with various spray lances, allowing you to adjust the spray strength according to the cleaning task. Select the appropriate lance for the desired pressure and spray pattern.

5.4 Cleaning Techniques

- Always start cleaning from a distance and move closer as needed to avoid damaging the surface.
- Use a sweeping motion to clean evenly.
- For stubborn dirt, consider using a detergent (if the model supports a detergent tank/attachment, refer to specific accessory instructions).

5.5 Shutting Down

1. Turn off the power switch on the pressure washer.
2. Turn off the water tap.
3. Squeeze the trigger on the spray gun to release any remaining pressure in the system.
4. Disconnect the power cord and water supply.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your pressure washer.

- **Clean the Water Inlet Filter:** Regularly check and clean the water inlet filter to prevent blockages and protect the pump. Remove the filter, rinse it under running water, and reinsert it.

- **Drain Water for Storage:** Before storing, especially in freezing temperatures, ensure all water is drained from the pump and hoses to prevent damage. Run the pump for a few seconds after disconnecting the water supply to expel residual water.
- **General Cleaning:** Wipe down the exterior of the pressure washer with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Hose and Cord Storage:** Neatly coil the high-pressure hose and power cord for storage to prevent kinks and damage.

7. TROUBLESHOOTING

This section addresses common issues you might encounter. For problems not listed here, contact customer support.

Problem	Possible Cause	Solution
Motor does not start	No power supply; Faulty power switch; Thermal overload activated	Check power connection and outlet; Ensure switch is ON; Allow unit to cool down
No water pressure or low pressure	Water tap closed; Water inlet filter blocked; Air in pump; Kinked hose	Open water tap fully; Clean water inlet filter; Purge air from system; Straighten hose
Water leaks	Loose connections; Damaged O-rings/seals	Tighten all connections; Inspect and replace damaged O-rings/seals

8. SPECIFICATIONS

Specification	Value
Model Number	GRM1022
Brand	Ferm
Power Source	Corded Electric
Voltage	240 Volts
Wattage	1400 Watts
Maximum Workload Pressure	110 bar
Maximum Flow Rate	6.5 Liters Per Hour
Hose Length	5 Metres
Power Cord Length	5 Metres
Item Weight	5.86 Kilograms
Product Dimensions (LxWxH)	32 x 25.5 x 40 cm

Specification	Value
Specification Met	CE, CSA

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support or spare parts, please contact Ferm customer service through their official website or the contact details provided with your product.