

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DASH](#) /

› [Dash DCAF150GBBK02 Compact Air Fryer Instruction Manual](#)

DASH DCAF150GBBK02

Dash DCAF150GBBK02 Compact Air Fryer

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Dash DCAF150GBBK02 Compact Air Fryer. This appliance is designed to cook your favorite foods using rapid air circulation technology, resulting in crispy textures with little to no oil. Please read this manual thoroughly before operating your new air fryer to ensure safe and efficient use. Keep this manual for future reference.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.

Parts & Features



Image: The Dash DCAF150GBBK02 Compact Air Fryer, showing its main body and the removable frying basket. This image illustrates the compact design and primary components of the appliance.

1. **Temperature Control Dial:** Used to set the desired cooking temperature.
2. **Timer Dial:** Used to set the cooking time.
3. **Power Indicator Light:** Illuminates when the air fryer is powered on.
4. **Heating Indicator Light:** Illuminates when the heating element is active.
5. **Frying Basket:** Removable basket for holding food during cooking.
6. **Crisper Tray:** Inserted into the frying basket to allow air circulation around food.
7. **Handle:** For safely pulling out and inserting the frying basket.
8. **Air Outlet Vent:** Located at the rear, releases hot air during operation.

Setup

1. **Unpacking:** Carefully remove all packaging materials and stickers from the air fryer.
2. **Cleaning:** Wash the frying basket and crisper tray with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the interior and exterior of the appliance with a damp cloth.
3. **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 4 inches of space around the appliance.
4. **First Use (Burn-in):** It is recommended to run the air fryer empty for about 10 minutes at 400°F (200°C) before first use. This helps to burn off any manufacturing residues and odors. A slight odor may be present during this process; this is normal.

Operating Instructions

1. **Prepare Food:** Prepare your food as desired. For best results, pat food dry and lightly coat with oil if specified by the recipe.
2. **Load Basket:** Place the crisper tray into the frying basket. Arrange food in a single layer on the crisper tray. Do not overfill the basket to ensure even cooking.
3. **Insert Basket:** Slide the frying basket back into the air fryer until it clicks securely into place.
4. **Set Temperature:** Turn the Temperature Control Dial to your desired cooking temperature.
5. **Set Timer:** Turn the Timer Dial to the recommended cooking time. The air fryer will begin heating. The Power and Heating indicator lights will illuminate.

6. **Shake/Flip Food (Optional):** For even cooking, especially with smaller items, pull out the basket halfway through the cooking time and gently shake or flip the food. Reinsert the basket firmly.
7. **Completion:** When the timer reaches zero, the air fryer will automatically turn off and a bell will sound. Carefully pull out the basket.
8. **Serve:** Use tongs to remove cooked food from the basket. Be cautious of hot steam.
9. **Cool Down:** Allow the appliance to cool down completely before cleaning or storing.

Cooking Tips:

- Smaller items usually require a slightly shorter cooking time than larger items.
- A larger amount of food only requires a slightly longer cooking time.
- Shaking smaller items halfway through the cooking time optimizes the end result and can help prevent unevenly fried items.
- For crispy results, some foods benefit from a light coating of oil.
- You can also use the air fryer to reheat food. To reheat, set the temperature to 300°F (150°C) for approximately 10 minutes.

Maintenance & Cleaning

Proper cleaning after each use will extend the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Clean Basket & Tray:** The frying basket and crisper tray are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak them in hot water for about 10 minutes.
3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth. Do not use abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Caution: Never immerse the main unit of the air fryer in water or any other liquid.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded wall outlet.
Food is not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake or flip food halfway through cooking.
Food is not crispy.	Not enough oil (for some foods); temperature too low.	Lightly coat food with oil if desired. Increase cooking temperature slightly.
White smoke coming from appliance.	Grease from previous use; fatty food cooking.	Clean the basket and crisper tray thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the outer pan to prevent smoke.

Problem	Possible Cause	Solution
Appliance smells during first use.	Manufacturing residues burning off.	This is normal for first use. Run empty for 10 minutes at 400°F (200°C) before cooking. Ensure good ventilation.

Specifications

Model Number: DCAF150GBBK02

ASIN: B075FV62N7

Manufacturer: Dash

Date First Available: September 7, 2017

(Additional specifications such as wattage, voltage, capacity, and dimensions would typically be listed here if available in the input data.)

Warranty & Support

DASH products are manufactured to high quality standards. This product is covered by a limited warranty from the date of original purchase against defects in material or workmanship. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official DASH website.

For customer support, troubleshooting assistance, or to inquire about replacement parts, please contact DASH customer service. Contact information can typically be found on the product packaging, the official DASH website, or by calling the number provided in your warranty documentation.

Online Support: [Visit the DASH Store on Amazon](#)