



[Manuals.plus](#) /

› [SKMEI](#) /

› SKMEI Simple Digital Military Watch User Manual

SKMEI SKMEI Digital Sport Watch

SKMEI Digital Sport Watch User Manual

Model: SKMEI Digital Sport Watch

INTRODUCTION

This manual provides comprehensive instructions for the operation, maintenance, and troubleshooting of your SKMEI Digital Sport Watch. Please read this manual carefully before using your watch to ensure proper function and longevity. The SKMEI Digital Sport Watch is designed for daily use and various indoor and outdoor sports activities. It features a sleek design, a large digital display, and multiple functions including dual time, calendar, chronograph, and alarm.

PRODUCT OVERVIEW



Figure 1: Front view of the SKMEI Digital Sport Watch, displaying time, day, and date.



Figure 2: Side profile of the SKMEI Digital Sport Watch, highlighting its robust casing.



Figure 3: Top-down view of the SKMEI Digital Sport Watch, showcasing the large digital display.

Key Features:

- **Dual Time Function:** Allows setting and displaying time for two different time zones.
- **Calendar Display:** Shows month, date, and day of the week.
- **Chronograph:** Stopwatch function for timing activities.
- **Countdown Timer:** Useful for various timed tasks.
- **Alarm Clock:** Daily alarm function.
- **LED Backlight:** Electro-Luminescent (EL) backlight for easy reading in low light conditions.
- **Water Resistance:** Rated 50M (164 FT) for swimming, showering, and general water exposure. *Note: Do not press buttons underwater or expose to hot water.*
- **Durable Construction:** Features a scratch-resistant resin glass window and a high-elastic PC shell.
- **Comfortable Band:** High-quality silicone band designed for comfort and durability, suitable for various wrist sizes.

Button Functions:

The SKMEI Digital Sport Watch features four primary buttons:

- **LIGHT (Top Left):** Activates the EL backlight.
- **MODE (Bottom Left):** Cycles through different modes (Time, Alarm, Chronograph, Countdown, Dual Time).
- **START (Top Right):** Used to start/stop functions in Chronograph mode, and to adjust values in setting modes.
- **RESET (Bottom Right):** Used to reset functions in Chronograph mode, and to adjust values in setting modes.



Figure 4: Comparison of the watch display in normal mode versus with the EL backlight activated.

Setting Time and Date:

1. From the Time Display Mode, press and hold the **MODE** button until the seconds begin to flash. This indicates you are in setting mode.
2. Press the **RESET** button to cycle through the setting parameters: Seconds → Hours → Minutes → Year → Month →

Day.

3. Use the **START** button to adjust the flashing value. For seconds, pressing **START** will reset them to 00.
4. Once all desired values are set, press the **MODE** button again to exit the setting mode and return to the Time Display.

Setting 12/24 Hour Format:

While in the Time Display Mode, press the **START** button to toggle between 12-hour (AM/PM indicator) and 24-hour formats.

OPERATING INSTRUCTIONS

Using the Alarm:

1. From the Time Display Mode, press the **MODE** button once to enter Alarm Mode. The alarm time will be displayed.
2. Press and hold the **RESET** button until the alarm hours begin to flash.
3. Use the **START** button to adjust the alarm hours.
4. Press the **RESET** button to move to the alarm minutes, then use the **START** button to adjust.
5. Press the **MODE** button to exit alarm setting.
6. To turn the alarm ON/OFF, press the **START** button while in Alarm Mode. An alarm icon will appear/disappear.

Using the Chronograph (Stopwatch):

1. From the Time Display Mode, press the **MODE** button twice to enter Chronograph Mode. The display will show 00:00:00.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to reset the chronograph to 00:00:00.
5. To record lap times, press **RESET** while the chronograph is running. The lap time will freeze, but the chronograph continues to run in the background. Press **RESET** again to return to the running chronograph.

Using the Countdown Timer:

1. From the Time Display Mode, press the **MODE** button three times to enter Countdown Mode.
2. Press and hold the **RESET** button until the hours begin to flash.
3. Use the **START** button to adjust hours, then **RESET** to move to minutes, and **START** to adjust minutes.
4. Press **MODE** to confirm the countdown time.
5. Press **START** to begin the countdown. Press **START** again to pause.
6. Press **RESET** to reset the countdown to the set time.

Using Dual Time:

1. From the Time Display Mode, press the **MODE** button four times to enter Dual Time Mode.
2. Press and hold the **RESET** button until the hours begin to flash.
3. Use the **START** button to adjust the hours, then **RESET** to move to minutes, and **START** to adjust minutes for the second time zone.
4. Press **MODE** to exit Dual Time setting.

MAINTENANCE

Cleaning Your Watch:

To clean your SKMEI Digital Sport Watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and materials.

Water Resistance Guidelines:

50M
WATER-RESISTANT
Stainless Steel Back Cover



Wash



Shower



Rain



Figure 5: The watch is suitable for activities like washing hands, showering, and exposure to rain.

- The watch is rated for 50 meters (5 ATM) water resistance, suitable for swimming, showering, and general water exposure.
- **Important:** Do not press any buttons while the watch is submerged in water. This can compromise the water seal.
- Avoid exposing the watch to hot water or steam (e.g., hot showers, saunas), as extreme temperature changes can affect the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

Battery Replacement:

The watch uses 1 CR2 battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure the water resistance seal is properly maintained.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the battery (CR2).
Time is incorrect.	Time not set correctly or accidental button press.	Refer to "Setting Time and Date" section to re-adjust.
Buttons are unresponsive.	Watch may be in a locked mode or internal issue.	Try pressing the LIGHT button. If still unresponsive, consider battery replacement or professional service.
Water inside the watch.	Buttons pressed underwater or exposure to hot water/steam.	Immediately take the watch to a professional for inspection and repair to prevent further damage.

SPECIFICATIONS



Figure 6: Visual representation of watch dimensions and a summary of its functions.

Feature	Detail
Brand	SKMEI
Model	SKMEI Digital Sport Watch
Movement	Digital
Case Shape	Round
Clasp Type	Buckle
Water Resistance Depth	50 meters (164 ft)
Dial Case Diameter	1.97 inch / 5.0 cm
Case Thickness	0.59 inch / 1.5 cm

Feature	Detail
Band Width	0.87 inch / 2.2 cm
Band Length	10.43 inch / 26.5 cm
Max Band Perimeter	9.45 inch / 24 cm
Watch Weight	2.22 oz / 63 g
Case Material	PC (Polypropylene)
Band Material	Silicone Rubber
Mirror Surface	Mineral Glass Mirror
Battery Type	1 x CR2 (included)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the retailer or the official SKMEI website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance or inquiries, please contact SKMEI customer service.