

- [Manuals.plus](#) /
- › [Redlemon](#) /
 - › Redlemon Wristwatch 77951_N User Manual

Redlemon 77951_N

Redlemon Wristwatch 77951_N User Manual

Model: 77951_N | Brand: Redlemon

1. INTRODUCTION

Thank you for choosing the Redlemon 77951_N Digital Sports Wristwatch. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new watch. Please read this manual thoroughly to ensure optimal performance and longevity of your device.



Image 1.1: Front view of the Redlemon 77951_N Digital Sports Wristwatch, displaying time and date.

2. PACKAGE CONTENTS

- Redlemon 77951_N Digital Sports Wristwatch
- User Manual (this document)

3. PRODUCT FEATURES

The Redlemon 77951_N wristwatch is designed for durability and functionality, offering a range of features for daily use and sports activities:

- **Durable Design:** Constructed with robust materials and an impact-resistant casing.
- **Digital Display:** Clear digital interface for time, date, and other functions.
- **Water Resistance:** ATM5 rated, allowing submersion up to 1 meter.
- **Sports Functions:** Integrated stopwatch and timer for tracking activities.
- **Backlight:** LED backlight for visibility in low-light conditions.
- **Alarm Function:** Customizable alarm to help manage your schedule.
- **Comfortable Strap:** Made with flexible and durable TPU material, adjustable to wrist size.



**Diseño
resistente**



**Múltiples
funciones**



**Resistente
al agua**



**Sumergible
hasta 1 m**



**Funciones
para
deportistas**



**Ideal para
la noche**

Image 3.1: Overview of key features including durable design, multiple functions, water resistance, and sports capabilities.

4. WATCH CONTROLS

The watch features four buttons for navigation and setting functions. Familiarize yourself with their locations and primary uses:

- **LED Light Button (Top Right):** Activates the backlight.
- **Mode Button (Middle Right):** Cycles through different modes (Time, Stopwatch, Timer, Alarm).
- **Reset Button (Bottom Right):** Used to reset values or confirm settings in various modes.
- **Start/Stop Button (Top Left):** Initiates or pauses functions like stopwatch or timer, and adjusts values during setting.

FUNCIONES ESPECIALES **PARA DEPORTISTAS**

Rompe tus récords con su
cronómetro y temporizador



Image 4.1: Diagram illustrating the watch's control buttons and their labels.

5. SETUP AND BASIC OPERATION

5.1 Setting Time and Date

1. From the Time Display Mode, press and hold the **Mode Button** until the seconds begin to flash. This indicates you are in setting mode.
2. Press the **Start/Stop Button** to adjust the flashing value (e.g., seconds, hours, minutes, year, month, day).
3. Press the **Reset Button** to move to the next setting item.
4. Repeat steps 2 and 3 until all desired values (seconds, hour, minute, year, month, day) are set.
5. Press the **Mode Button** again to exit the setting mode and return to the Time Display Mode.

5.2 Setting the Alarm

1. From the Time Display Mode, press the **Mode Button** repeatedly until you reach the Alarm Mode (indicated by an alarm icon or 'AL').
2. Press and hold the **Start/Stop Button** until the alarm hour begins to flash.

3. Press the **Start/Stop Button** to adjust the hour.
4. Press the **Reset Button** to move to the minute setting.
5. Press the **Start/Stop Button** to adjust the minutes.
6. Press the **Reset Button** to toggle the alarm ON/OFF. An alarm icon will appear on the display when the alarm is active.
7. Press the **Mode Button** to exit the alarm setting mode.

6. OPERATING MODES

6.1 Time Display Mode

This is the default mode, displaying the current time, day of the week, and date. Press the **LED Light Button** to illuminate the display in dark environments.



Image 6.1: The watch display with backlight activated, showing time and date clearly in low light.

6.2 Stopwatch Mode

The stopwatch function allows you to measure elapsed time, ideal for sports and activities.

1. From Time Display Mode, press the **Mode Button** until 'ST' or 'STOP' appears on the display.
2. Press the **Start/Stop Button** to begin timing.
3. Press the **Start/Stop Button** again to pause timing.
4. To resume, press the **Start/Stop Button**.
5. To reset the stopwatch to zero, ensure it is paused, then press the **Reset Button**.

INNOVACIÓN DIGITAL

Controla la precisión de sus **múltiples funciones** con gran facilidad.



Image 6.2: The watch highlighting its special functions for athletes, including stopwatch and timer.

6.3 Timer Mode

The timer function allows you to set a countdown for specific durations.

1. From Time Display Mode, press the **Mode Button** repeatedly until 'TR' or 'TIMER' appears on the display.
2. Press and hold the **Start/Stop Button** until the timer digits begin to flash.
3. Use the **Start/Stop Button** to adjust the flashing value (hours, minutes, seconds).
4. Use the **Reset Button** to move between hours, minutes, and seconds.

5. Once the desired time is set, press the **Mode Button** to exit setting mode.
6. Press the **Start/Stop Button** to begin the countdown.
7. To pause, press the **Start/Stop Button** again. To resume, press it once more.
8. When the timer reaches zero, an alert will sound. Press any button to stop the alert.

7. WATER RESISTANCE GUIDELINES

Your Redlemon 77951_N watch is rated ATM5, meaning it is resistant to water splashes, rain, and can be submerged up to 1 meter. This makes it suitable for showering, washing hands, and brief immersion in water.

- **Do NOT** press any buttons while the watch is submerged or wet, as this can compromise the water seal.
- Avoid exposure to hot water, steam, or extreme temperature changes, which can damage the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.



Image 7.1: The watch submerged in water, illustrating its water-resistant capabilities.

8. MAINTENANCE

8.1 Cleaning

Wipe the watch regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and thorough drying. Avoid harsh chemicals or abrasive materials.

8.2 Battery Replacement

The watch uses one CR2 battery. When the display dims or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified technician to ensure the water resistance seal is maintained.

9. TROUBLESHOOTING

- **Display is blank or dim:** Check battery level. Replace battery if necessary.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not specify one). Try a soft reset by removing and reinserting the battery (professional assistance recommended).
- **Water inside the watch:** Immediately cease use and seek professional repair. Water damage is typically not covered under warranty if proper water resistance guidelines were not followed.
- **Incorrect time/date:** Refer to Section 5.1 to reset the time and date.

10. SPECIFICATIONS

Feature	Specification
Model Number	77951_N
Screen Dimensions	52 mm
Water Resistance Grade	ATM5 (up to 1 meter)
Battery Type	1 x CR2 (included)
Strap Material	TPU

DISEÑO DE GRAN RESISTENCIA



Carcasa rígida **antimpactos** protege al reloj de rayaduras y caídas si practicas de algún **deporte extremo**.

Image 10.1: The watch's robust design, built for high resistance against impacts and daily wear.

11. WARRANTY AND SUPPORT

Your Redlemon 77951_N Wristwatch comes with a **100-day warranty** directly from Redlemon. This warranty covers manufacturing defects and ensures your peace of mind. For any questions, complaints, or suggestions, please contact Redlemon customer support.

For further assistance, please refer to the official Redlemon website or contact their customer service department.

© 2024 Redlemon. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0786XH8WM>

More documents and user manuals: **<https://manuals.plus/>**