

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SKMEI](#) /
- › [SKMEI Multifunction Digital Watch Instruction Manual \(Model B078RDTY5T\)](#)

SKMEI B078RDTY5T

SKMEI Multifunction Digital Watch Instruction Manual

Model: B078RDTY5T

INTRODUCTION

Thank you for choosing the SKMEI Multifunction Digital Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch. Please read this manual carefully to ensure proper use and to maximize the lifespan of your timepiece.



A clear view of the SKMEI Multifunction Digital Watch, showcasing its square face, digital display, and stainless steel band.

PRODUCT FEATURES

- **Accurate Timekeeping:** Japanese movement ensures precise time.
- **Multifunction Display:** Includes time, date, day of the week, and visual second display.
- **Water Resistance:** 5 ATM (50 meters / 164 feet) suitable for water splashes, rain, showering, and swimming. *Not suitable for hot water/steam or diving. Avoid pressing buttons underwater.*
- **Additional Functions:** Alarm, hourly chime, 12/24-hour format, stopwatch, and countdown timer.
- **Durable Construction:** Features a clear resin dial window, stainless steel buckle, and back case.
- **Comfortable Wear:** Soft PU rubber watch band designed for daily comfort.

- **EL Luminous Backlight:** Provides illumination for low-light conditions.

WATCH OVERVIEW AND BUTTON FUNCTIONS



This diagram illustrates the various buttons on your SKMEI digital watch and their primary functions. Familiarize yourself with these controls for optimal use.

LIGHT Button (Top Left): Activates the EL Luminous backlight.

MODE Button (Bottom Left): Cycles through different modes: Time, Stopwatch, Alarm, Countdown Timer.

START/STOP Button (Top Right): Used to start/stop functions in Stopwatch and Countdown modes, and to adjust values in setting modes.

RESET Button (Bottom Right): Used to reset values in Stopwatch and Countdown modes, and to select items in setting modes.

SETUP AND TIME SETTING

1. **Initial Power-On:** The watch typically comes with a pre-installed battery. If the display is blank, ensure the battery insulator tab (if present) has been removed.
2. **Entering Time Setting Mode:** From the normal *Time Mode*, press the **MODE** button repeatedly until the seconds begin to flash. This indicates you are in the time setting mode.

3. **Adjusting Seconds:** While seconds are flashing, press the **START/STOP** button to reset them to 00.
4. **Selecting Next Item:** Press the **RESET** button to move to the next setting item (e.g., hours, minutes, year, month, day).
5. **Adjusting Values:** While an item is flashing, press the **START/STOP** button to increase its value. Hold the button for faster adjustment.
6. **12/24-Hour Format:** In the hour setting, pressing the **START/STOP** button will cycle between 12-hour (with AM/PM indicator) and 24-hour formats.
7. **Exiting Setting Mode:** Once all settings are adjusted, press the **MODE** button to return to the normal *Time Mode*.
8. **Band Adjustment:** The stainless steel band may require professional adjustment to fit your wrist. This typically involves removing links using a specialized tool.

OPERATING INSTRUCTIONS

Time Mode

- The default display shows the current time (hours, minutes, seconds), day of the week, and date.
- Press the **LIGHT** button to illuminate the display for a few seconds.
- To toggle the hourly chime (SIG) on/off, press the **RESET** button while in *Time Mode*. An icon will appear/disappear to indicate its status.

Alarm Mode

1. From *Time Mode*, press the **MODE** button once to enter *Alarm Mode*. The alarm time will be displayed.
2. Press the **START/STOP** button to toggle the alarm (ALM) on/off. An alarm icon will appear/disappear.
3. To set the alarm time, press the **RESET** button. The hour digits will flash.
4. Use the **START/STOP** button to adjust the hour.
5. Press the **RESET** button again to select the minute digits, then use the **START/STOP** button to adjust.
6. Press the **MODE** button to exit *Alarm Setting Mode*.

Stopwatch Mode

1. From *Time Mode*, press the **MODE** button twice to enter *Stopwatch Mode*. The display will show 00:00:00.
2. Press the **START/STOP** button to start the stopwatch.
3. Press the **START/STOP** button again to pause the stopwatch.
4. Press the **RESET** button to reset the stopwatch to 00:00:00 while it is paused.
5. To record lap times, press the **RESET** button while the stopwatch is running. The lap time will be displayed temporarily, while the stopwatch continues to run in the background. Press **RESET** again to return to the running stopwatch display.

Countdown Timer Mode

1. From *Time Mode*, press the **MODE** button three times to enter *Countdown Timer Mode*.
2. To set the countdown time, press the **RESET** button. The hour digits will flash.
3. Use the **START/STOP** button to adjust the hour.
4. Press the **RESET** button again to select the minute digits, then use the **START/STOP** button to adjust.
5. Press the **MODE** button to exit *Countdown Timer Setting Mode*.

6. To start the countdown, press the **START/STOP** button.
7. To pause/resume the countdown, press the **START/STOP** button again.
8. To reset the countdown to the set time, press the **RESET** button while the timer is paused.

MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying. Avoid harsh chemicals or abrasive materials.
- **Water Resistance:** While the watch is water-resistant to 5 ATM, avoid exposing it to hot water or steam (e.g., hot showers, saunas) as this can compromise the seals. Do not press buttons underwater.
- **Battery Replacement:** The watch uses a Japanese MAXCELL battery. When the display dims or functions become erratic, it may be time for a battery replacement. It is recommended to have this done by a professional watch repair service to ensure proper sealing and maintain water resistance.
- **Storage:** Store your watch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Display is blank or dim.	Battery may be low or depleted. Replace the battery.
Buttons are unresponsive.	Ensure the watch is not exposed to extreme temperatures. If problem persists, a battery reset or replacement may be needed.
Time is inaccurate.	Re-set the time according to the instructions in the 'Setup' section. If inaccuracy persists, the battery may be low or the movement requires service.
Water inside the watch.	This indicates a breach in the water resistance. Avoid further water exposure and seek professional repair immediately to prevent damage. Ensure buttons were not pressed underwater.

SPECIFICATIONS

- **Model:** B078RDTY5T
- **Brand:** SKMEI
- **Movement:** Japanese Digital Movement
- **Water Resistance:** 5 ATM (50 meters / 164 feet)
- **Case Dimensions:** Approximately 1.7 x 1.8 inches (Square Shape)
- **Clasp Type:** Foldover Clasp
- **Battery:** Japanese MAXCELL (Type not specified, typically CR2016 or similar for digital watches)
- **Functions:** Time, Date, Day, Alarm, Hourly Chime, Stopwatch, Countdown Timer, EL Backlight, 12/24H Format.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2023 SKMEI. All rights reserved.