

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MasterChef](#) /

› [MasterChef 13-in-1 Digital Pressure Cooker User Manual](#)

## MasterChef MTF-PCR-417

# MasterChef 13-in-1 Digital Pressure Cooker Instruction Manual

Model: MTF-PCR-417 | Brand: MasterChef

## 1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your MasterChef 13-in-1 Digital Pressure Cooker. Failure to follow these safety guidelines may result in property damage, personal injury, or death.

- Always ensure the lid is properly sealed and locked before operating.
- Do not overfill the inner pot beyond the maximum fill line.
- Exercise extreme caution when opening the lid after pressure cooking, as hot steam may escape.
- Never attempt to force open the lid while the cooker is pressurized.
- Keep hands and face clear of the steam release valve during operation and pressure release.
- Do not immerse the main unit in water or other liquids.
- Always unplug the appliance when not in use and before cleaning.

## 2. PRODUCT OVERVIEW

### 2.1 Components

The MasterChef 13-in-1 Digital Pressure Cooker includes the following main components:



Image: The MasterChef 13-in-1 Digital Pressure Cooker, showcasing its sleek design, digital control panel, and included accessories like the rice spoon and measuring cup.

- **Main Unit:** Houses the heating element and control panel.
- **Removable Inner Pot:** Non-stick cooking pot for easy cleanup.
- **Lid:** Features a sealing ring, float valve, and steam release valve.
- **Condensation Collector:** Gathers excess moisture.
- **Rice Spoon:** For serving cooked rice.
- **Measuring Cup:** For precise ingredient measurement.

## 2.2 Control Panel

The digital LED display and intuitive buttons allow for easy selection of cooking functions and adjustments.

# PRESSURE COOKER



Image: Detailed view of the digital control panel, highlighting the various pre-set functions and manual controls for precise cooking.

## Control Panel Functions

Button/Indicator	Description
Digital LED Display	Shows cooking time, pressure level, and status.
White Rice / Brown Rice	Pre-set programs for cooking different types of rice.
Soup / Porridge	Dedicated settings for soups and porridges.
Fish / Poultry / Beef / Stew	Optimized programs for various meats and stews.
Beans / Multigrain	Settings for cooking beans and other grains.
Slow Cook	Allows for extended low-temperature cooking.
Sauté	For browning ingredients before pressure cooking.
Yogurt	Function for making homemade yogurt.
Manual	Allows for custom time and pressure settings.

Button/Indicator	Description
Pressure (+/-)	Adjusts pressure levels (Low/High) or cooking time.
Delay Timer	Sets a delayed start time for cooking.
Start / Keep Warm / Cancel	Initiates cooking, maintains warmth, or cancels a program.

## 3. SETUP

---

### 3.1 Unpacking and Initial Cleaning

1. Carefully remove all packaging materials from the pressure cooker and its accessories.
2. Wash the removable inner pot, lid, and accessories (rice spoon, measuring cup) with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. Ensure all parts are dry before reassembling.

### 3.2 First Use (Water Test)

It is recommended to perform a water test before cooking food to familiarize yourself with the pressure cooker's operation and ensure it is functioning correctly.

1. Add 2-3 cups of water to the inner pot.
2. Place the inner pot into the main unit.
3. Close the lid, ensuring it is properly aligned and locked into place. The steam release handle should be in the 'Sealing' position.
4. Plug in the pressure cooker.
5. Select the 'Manual' function and set the time to 5 minutes. Press 'Start'.
6. The cooker will preheat and then begin pressure cooking. Once complete, allow pressure to release naturally or use the quick release method (refer to Section 4.3).
7. Once pressure is fully released, open the lid and discard the water. The cooker is now ready for use.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Basic Operation

1. Place the inner pot into the main unit.
2. Add your ingredients and liquid to the inner pot. Ensure the liquid level is within the minimum and maximum fill lines.
3. Close the lid, aligning the arrow on the lid with the arrow on the base, then rotate clockwise until it locks. Ensure the steam release handle is in the 'Sealing' position.
4. Plug the power cord into a grounded electrical outlet.
5. Select your desired cooking function from the control panel.
6. Adjust cooking time or pressure level using the '+' and '-' buttons if necessary.
7. Press the 'Start' button to begin cooking. The display will show 'On' or 'Heat' during preheating.
8. Once pressure is reached, the timer will begin counting down.
9. After cooking is complete, the cooker will beep and automatically switch to 'Keep Warm' mode (unless cancelled).

## 4.2 Using Pre-set Functions

The MasterChef pressure cooker features 13 programmable functions for various dishes:



### PRESSURE COOKER

The MasterChef Pressure Cooker comes with automatic pressure control and 14 different functions, perfect for cooking full meals in no time. Add your favorite sweet or savory ingredients, select your mode and time, and sit back and relax while it cooks!

Image: The pressure cooker ready for use, surrounded by fresh ingredients, illustrating its versatility for various meals.

- **Rice (White/Brown):** Ideal for perfectly cooked rice.
- **Fish:** Gentle cooking for delicate fish.
- **Poultry:** For tender chicken or turkey dishes.
- **Beef:** Suitable for tougher cuts of beef, ensuring tenderness.
- **Stew:** Perfect for hearty stews and casseroles.
- **Saute:** Use before pressure cooking to brown meats or vegetables.
- **Yogurt:** For fermenting milk into yogurt.
- **Slow Cook:** For traditional slow-cooked recipes.
- **Soup:** Creates flavorful soups and broths.
- **Porridge:** For creamy porridges and oatmeal.
- **Beans:** Efficiently cooks various types of beans.
- **Multigrain:** For cooking a variety of grains beyond rice.
- **Delay Timer:** Program cooking to start at a later time.

Simply press the button corresponding to your desired function. The cooker will automatically set the optimal pressure and cooking time. You can adjust the time using the '+' and '-' buttons if needed.



Image: A hearty beef stew cooking inside the MasterChef pressure cooker, demonstrating its capability for robust meals.

### 4.3 Steam Release Methods

After pressure cooking, pressure must be released before opening the lid. There are two methods:

- **Natural Release (NPR):** Allow the cooker to cool down naturally. The float valve will drop on its own, indicating pressure has been released. This method is ideal for foamy foods or large cuts of meat.
- **Quick Release (QPR):** Carefully turn the steam release handle from 'Sealing' to 'Venting' position. Steam will rapidly escape. Use caution to avoid contact with hot steam. This method is suitable for vegetables and delicate foods to prevent overcooking.

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your pressure cooker.



Non-stick  
surface for  
easy clean up

Recipe book  
& instruction  
manual  
included



Image: The non-stick inner pot of the pressure cooker, emphasizing its easy-to-clean surface, with a bowl of soup and a plate of chicken in the foreground.

- **Inner Pot:** The non-stick inner pot is easy to clean. Wash with warm, soapy water and a soft sponge. Avoid abrasive cleaners or scouring pads that could damage the non-stick coating.
- **Lid:** Wash the lid with warm, soapy water. Pay attention to the sealing ring and steam release valve. Remove the sealing ring for thorough cleaning if necessary, and ensure it is properly reinstalled before next use.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not submerge in water.
- **Condensation Collector:** Empty and clean the condensation collector after each use.
- **Accessories:** Wash the rice spoon and measuring cup with warm, soapy water.

## 6. TROUBLESHOOTING

If you encounter issues with your MasterChef 13-in-1 Digital Pressure Cooker, refer to the table below for common problems and solutions.

## Common Issues and Solutions

Problem	Possible Cause	Solution
Cooker not building pressure.	Lid not properly sealed; steam release valve in 'Venting' position; sealing ring not installed correctly or damaged; insufficient liquid.	Ensure lid is locked; turn steam release handle to 'Sealing'; check/reinstall/replace sealing ring; add more liquid.
Food is undercooked.	Insufficient cooking time; not enough liquid; power interruption.	Increase cooking time; ensure adequate liquid; check power connection.
Error code on display.	Specific internal issue.	Refer to the full manual for specific error code meanings or contact customer support.
Lid cannot be opened after cooking.	Pressure still inside the cooker.	Ensure all pressure is released (float valve dropped) before attempting to open.

## 7. SPECIFICATIONS

### Product Specifications



Feature	Detail
Brand	MasterChef
Model Number	MTF-PCR-417
Capacity	6 Quarts
Material	Metal (with non-stick inner pot)
Color	White
Finish Type	Titanium
Product Dimensions (DxWxH)	15"D x 12"W x 12"H
Item Weight	12.35 Pounds
Control Method	Touch
Controller Type	Push Button
Operation Mode	Automatic
Dishwasher Safe (Inner Pot)	No (Hand wash recommended for inner pot)

## 8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries regarding your MasterChef 13-in-1 Digital Pressure Cooker, please refer to the warranty card included with your product or visit the official MasterChef website for customer service contact details.

Keep your purchase receipt as proof of purchase for any warranty claims.

## Related Documents - MTF-PCR-417

 <p><b>USER MANUAL</b></p>	<p><a href="#"><u>MasterChef 10-in-1 Multicooker User Manual VRD919102071</u></a></p> <p>Comprehensive user manual for the MasterChef 10-in-1 Multicooker (Model VRD919102071), detailing safety instructions, features, specifications, cooking functions, care, and troubleshooting.</p>
 <p><b>USER MANUAL</b></p>	<p><a href="#"><u>MasterChef 10-in-1 Multicooker User Manual</u></a></p> <p>Comprehensive user manual for the MasterChef 10-in-1 Multicooker (Model VRD919101300), detailing safety precautions, features, operating instructions, and maintenance for this versatile kitchen appliance.</p>
 <p><b>AIR FRYER</b> <b>USER MANUAL</b></p>	<p><a href="#"><u>MasterChef VRD109102023 Air Fryer User Manual</u></a></p> <p>User manual for the MasterChef VRD109102023 Air Fryer, providing essential information on safe operation, setup, cooking functions, cleaning, and maintenance for optimal performance.</p>
 <p><b>STICKBLENDER SET</b> <b>USER MANUAL</b></p>	<p><a href="#"><u>MasterChef VRD919102039 Stick Blender Set User Manual</u></a></p> <p>Comprehensive user manual for the MasterChef VRD919102039 Stick Blender Set, covering important safety instructions, usage guidelines, cleaning, and warranty information.</p>
 <p><b>USER MANUAL</b> Stick Blender</p>	<p><a href="#"><u>MasterChef Stick Blender User Manual - Safety, Usage, and Maintenance Guide</u></a></p> <p>Comprehensive user manual for the MasterChef Stick Blender, covering safety precautions, operating instructions, cleaning, storage, and technical specifications. Essential guide for proper use and maintenance.</p>



### [MasterChef Hand Blender with Cup - User Manual & Safety Instructions](#)

Comprehensive instruction manual for the MasterChef Hand Blender with Cup (Item No. 3005398/ACT919101772), covering safety precautions, usage, cleaning, storage, warranty, and disposal.