

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [QSC](#) /
- › [QSC Q-SYS Core 110f Networked Audio Channels Processor User Manual](#)

QSC Q-SYS Core 110f

QSC Q-SYS Core 110f Networked Audio Channels Processor

Model: Q-SYS Core 110f | Brand: QSC

PRODUCT OVERVIEW

The Q-SYS Core 110f processor represents a significant advancement in integrated audio, video, and control solutions. Designed for versatility, it seamlessly scales from compact, single-room installations to extensive enterprise-level deployments. This powerful processor provides 128x128 networked audio channels, ensuring robust and flexible audio routing and processing capabilities for professional environments.



Image: The QSC Q-SYS Core 110f processor, showcasing its front panel display and the comprehensive array of rear panel connections including Mic/Line Inputs, Flex Channels, Mic/Line Outputs, GPIO, Telephone Line, External Power Input, RS232, HDMI, USB, and Ethernet ports (LAN A, LAN B).

PACKAGE CONTENTS

Upon opening the package, verify that all components are present:

- 2 x Q-SYS Core 110f Processor
- 1 x Patch Panel

If any items are missing or damaged, please contact QSC customer support immediately.

SETUP GUIDE

1. Rack Mounting

The Q-SYS Core 110f is designed for standard rack mounting. Ensure adequate ventilation around the unit. Use appropriate rack screws to secure the processor firmly in place. The unit supports bracket mounting.

2. Power Connection

Connect the provided power cord to the 100-240V~50/60Hz 150W AC inlet on the rear panel of the Core 110f. Plug the other end into a grounded electrical outlet. The unit is a corded electric device.

3. Network Connectivity

Utilize the Ethernet ports (LAN A and LAN B) on the rear panel to connect the Core 110f to your network infrastructure. These connections are crucial for networked audio channels and control. The device uses Ethernet as its connectivity protocol.

4. Audio and Control Connections

Connect your audio sources and destinations to the appropriate Mic/Line Inputs, Flex Channels, and Mic/Line Outputs using the provided Phoenix connectors. For control, utilize the GPIO ports, RS232, and HDMI connections as required by your system design. The unit supports 128x128 networked audio channels.

5. Initial Power On

Once all connections are secure, power on the Q-SYS Core 110f. Observe the front panel display for boot-up status and system information. Refer to the Q-SYS Designer Software documentation for initial configuration and system design loading.

OPERATION

System Control

The Q-SYS Core 110f is primarily controlled via the Q-SYS Designer Software, which allows for comprehensive system design, configuration, and monitoring. The front panel display provides basic status information and navigation using the integrated buttons.

Audio Processing

Leverage the Core 110f's powerful DSP capabilities for audio routing, mixing, equalization, dynamics processing, and more. All audio processing is configured within the Q-SYS Designer Software and deployed to the Core.

Peripheral Integration

The Core 110f integrates seamlessly with a wide range of Q-SYS peripherals and third-party devices. Ensure all connected devices are properly configured within your Q-SYS design for optimal performance. Compatible devices include Projector, Laptop, MP3 Player, Desktop, Television, Tablet, Smartphone.

Monitoring Status

Regularly check the front panel display for system status, device health, and network connectivity. Detailed monitoring and logging are available through the Q-SYS Designer Software.

MAINTENANCE

Cleaning

Keep the unit clean by wiping it with a soft, dry cloth. Do not use liquid cleaners or aerosols directly on the unit. Ensure ventilation openings are free from dust and debris to prevent overheating.

Firmware Updates

Periodically check the QSC website for firmware updates. Keeping the Core 110f's firmware up-to-date ensures optimal performance, security, and access to new features. Follow the instructions provided by QSC for safe firmware updates.

Environmental Considerations

Operate the Core 110f within specified environmental conditions (temperature, humidity) to ensure longevity. Avoid exposing the unit to excessive moisture or extreme temperatures. The unit is not waterproof.

TROUBLESHOOTING

No Power

- Verify the power cord is securely connected to both the Core 110f and a working electrical outlet.
- Check the power source for functionality.

No Network Connectivity

- Ensure Ethernet cables are properly connected to LAN A/B ports and the network switch.
- Verify network settings (IP address, subnet mask) within Q-SYS Designer Software.
- Check network switch status and connectivity.

No Audio Output/Input

- Confirm audio cables are correctly connected to the Mic/Line Inputs, Flex Channels, and Mic/Line Outputs.
- Verify audio routing and gain settings within your Q-SYS design.
- Check the status of connected audio peripherals.

System Errors on Display

- Note the error message displayed.
- Consult the Q-SYS documentation or QSC support with the specific error code for detailed resolution steps.

For issues not covered here, please refer to the comprehensive Q-SYS documentation or contact QSC Technical Support.

TECHNICAL SPECIFICATIONS

Model Name	Q-SYS Core 110f
------------	-----------------

Brand	QSC
Connectivity Technology	Ethernet
Connectivity Protocol	Ethernet
Audio Output Mode	Stereo
Speaker Type	Monitor
Surround Sound Channel Configuration	2.0
Power Source	Corded Electric
Control Method	Touch (via Q-SYS Designer Software)
Mounting Type	Bracket Mount
Is Waterproof	FALSE
Number of Items	2 (Processors in package)
Compatible Devices	Projector, Laptop, MP3 Player, Desktop, Television, Tablet, Smartphone
UPC	684284062345

WARRANTY AND SUPPORT

The QSC Q-SYS Core 110f processor comes with a Full Warranty. For specific terms and conditions of your warranty, please refer to the documentation included with your product or visit the official QSC website.

For technical support, product registration, or to access additional resources such as software downloads and detailed manuals, please visit the official QSC support portal or their Amazon Brand Store:

[Visit the QSC Store on Amazon](#)

When contacting support, please have your product model (Q-SYS Core 110f) and serial number ready.