#### Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- MOTOPOWER /
- MOTOPOWER MP00207A 12V 2Amp Automatic Battery Charger/Maintainer User Manual

## **MOTOPOWER MP00207A**

# MOTOPOWER MP00207A 12V 2Amp Automatic Battery Charger/Maintainer User Manual

Model: MP00207A

## INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your MOTOPOWER MP00207A 12V 2Amp Automatic Battery Charger/Maintainer. This device is designed to charge and maintain both 12V lead-acid batteries and 12V lithium-ion batteries. Please read this manual thoroughly before use and retain it for future reference.

## SAFETY INFORMATION

- Always operate the charger in a well-ventilated area.
- Ensure the charger is disconnected from the AC power outlet before making or breaking connections to the battery.
- Avoid charging frozen batteries. Allow them to warm up to room temperature first.
- Do not expose the charger to rain or excessive moisture.
- Wear eye protection and gloves when working with batteries.
- Keep sparks, flames, and smoking materials away from batteries. Batteries can produce explosive gases.
- This charger is designed for 12V lead-acid and 12V lithium-ion batteries only. Do not use it for other battery types.
- If the battery voltage is below 8 volts, the charger will not initiate charging for safety reasons.

## PRODUCT FEATURES

- Fully Automatic Operation: No manual intervention required. Simply connect and leave the charger to automatically charge and maintain your batteries.
- Microprocessor Controlled 4-Step Charging: The charging process includes Diagnosis, Bulk Charge, Absorption, and Maintenance stages. The microprocessor automatically adjusts the charging rate for optimal battery health.

- **Multi-Level Safety Protections:** Features protection against overcharge, short-circuit, and reverse polarity. The spark-free design enhances safety during connection.
- **LED Indicators:** Four LED indicators display the status of power, charging, charge/maintenance, and reverse connection.
- SAE Quick Release Adapters: Includes both ring terminal connectors (with a 7.5 amp fuse for protection) and alligator clips for versatile connection options.

# **PACKAGE CONTENTS**

The MOTOPOWER MP00207A package typically includes:

- MOTOPOWER MP00207A 12V 2Amp Automatic Battery Charger/Maintainer Unit
- SAE Quick Release Alligator Clip Cable
- SAE Quick Release Ring Terminal Cable (with 7.5 Amp Fuse)



Image: MOTOPOWER MP00207A charger unit with included alligator clip and ring terminal accessories.



Image: Close-up of the SAE quick release alligator clips and ring terminal connectors.

## SETUP AND CONNECTION

- 1. **Prepare the Battery:** Ensure the battery terminals are clean and free of corrosion. If necessary, clean them with a wire brush and a baking soda solution.
- 2. Choose Connection Method:
  - Alligator Clips: Ideal for temporary connections. Connect the RED (+) clip to the positive battery terminal and the BLACK (-) clip to the negative battery terminal.
  - **Ring Terminals:** Suitable for long-term maintenance. Securely attach the RED (+) ring terminal to the positive battery post and the BLACK (-) ring terminal to the negative battery post. The ring terminal harness can be left permanently connected to the battery.
- 3. **Connect to Charger:** Plug the chosen SAE quick release adapter (alligator clips or ring terminals) into the charger's output port. Ensure a secure connection.
- 4. Connect to Power: Plug the charger's AC power cord into a standard 100-240V AC wall outlet.



Image: The MOTOPOWER charger connected to a 12V starter battery using alligator clips.

# **OPERATING INSTRUCTIONS**

Once connected to the battery and AC power, the charger will automatically begin its 4-step charging process.

## **4-Step Charging Process:**

- 1. **Diagnosis:** The charger first analyzes the battery's condition and voltage. If the battery voltage is below 8V, the charger will not proceed for safety.
- 2. Bulk Charge: Charges the battery at its maximum current until it reaches approximately 80% of its capacity.
- 3. **Absorption:** Charges the battery at a decreasing current until it reaches 100% capacity.
- 4. **Maintenance (Float/Pulse):** Once fully charged, the charger switches to maintenance mode, providing a small, constant current or pulse charge to keep the battery at optimal voltage without overcharging.

## **LED Indicators:**

The charger features four LED indicators to display its status:

- Power (Green LED): Illuminates when the charger is connected to AC power.
- Charging (Red LED): Illuminates when the battery is actively charging.

- Charged / Maintenance (Green LED): Illuminates when the battery is fully charged and the charger is in maintenance mode.
- Reverse Polarity Connection (Red LED): Illuminates if the battery connections are reversed. Disconnect immediately and correct the polarity.



Image: Visual guide to the LED indicators on the MOTOPOWER MP00207A charger, showing power on, charging, charged/maintenance, and reverse polarity states.



Image: The charger actively performing its charge and maintain function, indicating spark-free operation.

## MAINTENANCE

- Keep the charger clean and dry. Wipe with a soft, damp cloth if necessary.
- Store the charger in a cool, dry place when not in use.
- Regularly inspect the cables and connectors for any signs of damage. Do not use the charger if cables are frayed or connectors are damaged.
- The 7.5 amp fuse in the ring terminal harness is a safety feature. If it blows, replace it with a fuse of the same rating.



Image: The charger connected to a battery, illustrating its role in optimizing battery performance through pulse current during maintenance.

## **TROUBLESHOOTING**

Problem	Possible Cause	Solution
Charger not turning on (Power LED off)	No AC power; faulty outlet.	Check AC power connection. Try a different outlet.
Charging LED not illuminating	Battery not connected; reverse polarity; battery voltage too low (<8V); battery is already full.	Ensure correct battery connection. Check for reverse polarity (Red Reverse Polarity LED). If battery is below 8V, it may need professional attention or replacement.
Reverse Polarity LED (Red) is on	Battery connections are reversed.	Immediately disconnect the charger from AC power and the battery. Reconnect the RED (+) clip/terminal to the positive battery terminal and the BLACK (-) clip/terminal to the negative battery terminal.

Problem	Possible Cause	Solution
Charger gets warm during operation	Normal operation.	This is normal. Ensure adequate ventilation around the charger.

## **SPECIFICATIONS**

Feature	Detail
Model Number	MP00207A
Input Voltage	100-240V AC
Output Voltage	12V DC
Output Current	2 Amp
Power Output	24 Watts
Compatible Battery Types	12V Lead-Acid (Wet, Gel, MF, AGM, EFB) and 12V Lithium-Ion (LiFePO4)
Dimensions (L x W x H)	10.5 x 5 x 3.8 cm (approximately)
Item Weight	570 grams
Safety Standards	CE, RoHS
UPC	766832212409

## WARRANTY AND SUPPORT

For warranty information or technical support, please contact MOTOPOWER customer service directly. Refer to the product packaging or the official MOTOPOWER website for contact details.

## Related Documents - MP00207A



## MOTOPOWER MP00205A Battery Charger Owner's Manual

Comprehensive owner's manual for the MOTOPOWER MP00205A 12V 800mA automatic battery charger and maintainer. Includes preparation, usage instructions, troubleshooting, and specifications.



## Manuale di Istruzioni Caricabatterie MOTOPOWER MP00205B Optimizer X

Manuale di istruzioni completo per il caricabatterie e manutentore automatico MOTOPOWER MP00205B Optimizer X. Include procedure di sicurezza, preparazione alla carica, posizionamento del caricabatterie, istruzioni per la carica con batteria nel veicolo e fuori dal veicolo, monitoraggio dello stato di carica, risoluzione dei problemi e specifiche tecniche.



## Motopower MP0514A 12V Digital Battery Tester Instruction Manual

Instruction manual for the Motopower MP0514A 12V Digital Battery Tester. This guide provides features, operation instructions, and support information for testing 12V batteries and charging systems.



#### MOTOPOWER MP0515A 12V Battery Tester/Analyzer User's Manual

User's manual for the MOTOPOWER MP0515A 12V Battery Tester/Analyzer, covering safety information, product description, specifications, battery testing, start testing, charging testing, setup, and warranty.



#### MOTOPOWER MP69038 OBD2 Code Reader Scanner FAQ

Frequently Asked Questions for the MOTOPOWER MP69038 OBD2 Code Reader Scanner, covering connection issues, screen not turning on, unsupported systems, VIN reading problems, and compatibility with vehicles with dead batteries.



## MOTOPOWER MP69041 OBD2 Scanner User Manual

Comprehensive user manual for the MOTOPOWER MP69041 5-in-1 Car OBD2 Scanner, detailing its features for reading check engine fault codes and diagnosing vehicle issues.

#### Documents - MOTOPOWER - MP00207A



## [pdf] User Manual

MP00207A 12V 2A Battery Charger Manual Germany DE Manuals — MOTOPOWER DIRECT Maintainer EN FR 748 cdn shopify s files 1 0141 7484 7076 |||

Bedienungsanleitung MP00207A BATTERIELADEGERT / WARTUNG 2000 AUTOMATISCHES LADEGERT / WARTUNGSGERT FR 12V BLEISUREBATTERIEN UND 12V LITHIUM-IONEN-BATTERIEN VOR DER VERWENDUNG, LESEN UND VERSTEHEN VON

PRODUKTSICHERHEITSINFORMATIONEN. DIE NICHTBEACHTUNG DER ANWEISUNGEN KANN ZU STROMSCHLGEN FHREN. EXPL...

lang:de score:46 filesize: 7.69 M page\_count: 1 document date: 2019-10-22



## [pdf] User Manual Accessories

MP00207A 12V 2A Battery Charger Manual Italy IT Manuals — MOTOPOWER DIRECT Maintainer EN FR DE ES 748 cdn shopify s files 1 0141 7484 7076 |||

Manuale di istruzioni **MP00207A** CARICABATTERIA 2000 CARICABATTERIA AUTOMATICO PER ENTRAMBI LE BATTERIE ACIDO AL PIOMBO 12V E LE BATTERIE IONE AL LITIO 12V PRIMA DI UTILIZZARE, LEGGERE E COMPRENDERE LE INFORMAZIONI SULLA SICUREZZA DEL PRODOTTO. LA MANCATA OSSERVANZA DELLE ISTRUZIONI PU PROVOCARE SCOSS...

lang:it score:45 filesize: 7.67 M page\_count: 1 document date: 2019-10-22



## [pdf] User Manual

MP00207A 12V 2A Battery Charger Manual Spain ES Manuals — MOTOPOWER DIRECT Maintainer EN FR DE 748 cdn shopify s files 1 0141 7484 7076 |||

Manual de instrucciones **MP00207A** CARGADOR DE BATERA 2000 CARGADOR AUTOMTICO DE BATERA / MAINTAINER PARA AMBAS BATERAS DE CIDO DE PLOMO DE 12 V Y BATERAS DE IN DE LITIO DE 12 V ANTES DE USAR, LEA Y COMPRENDA LA INFORMACIN DE SEGURIDAD DEL PRODUCTO. EL INCUMPLIMIENTO DE LAS INSTRUCCIONES PUEDE PROVOCA...

lang:es score:45 filesize: 7.67 M page\_count: 1 document date: 2019-10-22



## [pdf] User Manual

MP00207A 12V 2A Battery Charger Manual Japanese JP Manuals — MOTOPOWER DIRECT Maintainer EN FR DE ES IT 748 cdn shopify s files 1 0141 7484 7076 |||

...

lang:es score:25 filesize: 11.24 M page\_count: 1 document date: 2019-10-22



## [pdf]

MANUEL DE CHARGEUR BATTERIE MP00207A 12V 2AMP French FR Manuals — MOTOPOWER DIRECT 2A Battery Charger Maintainer EN 714 cdn shopify s files 1 0141 7484 7076 |||

...

lang:es score:21 filesize: 13.41 M page\_count: 1 document date: 2019-07-31