



Manuals.plus /

› Digipartspower /

› Digipartspower AC DC Adapter Instruction Manual for ProForm Treadmills and Ellipticals

Digipartspower AC DC Adapter

Digipartspower AC DC Adapter Instruction Manual

For ProForm Treadmills and Ellipticals

INTRODUCTION

Thank you for choosing the Digipartspower AC DC Adapter. This adapter is designed to provide reliable power to a range of ProForm fitness equipment, including various treadmill and elliptical models. Please read this manual carefully before use to ensure proper setup, operation, and maintenance, and to maximize the lifespan of your adapter and connected devices.

Compatible Models: This adapter is compatible with ProForm Treadmill XP 400R, 420, 480, 520, 850, Razor ProForm XP 400R, 405, 420, 390, 520, 600, 785, Pro Form 955R, 480CSF, 10.8 ZE5 Elliptical, Upright, and Recumbent Exercise Power units.

SAFETY INFORMATION

Your Digipartspower AC DC Adapter is manufactured with high-quality materials and incorporates multiple safety features to protect both the adapter and your connected equipment. Adhering to these safety guidelines is crucial for safe operation.

- **Over Current Protection (OCP):** Prevents damage from excessive current flow.
- **Over Voltage Protection (OVP):** Safeguards against damage from voltage surges.
- **Over Temperature Protection (OTP):** Shuts down the adapter if it overheats.
- **Short Circuit Protection (SCP):** Protects against damage from short circuits.

General Safety Precautions:

- Ensure the adapter is used in a dry environment. Avoid exposure to water or high humidity.
- Do not disassemble or modify the adapter. This can lead to electric shock or fire.
- Keep the adapter away from heat sources and direct sunlight.
- Always unplug the adapter from the power outlet before cleaning or if it will be unused for an extended period.
- Verify that the voltage and current requirements of your fitness equipment match the adapter's output specifications.

SETUP

Follow these steps to correctly set up your AC DC Adapter with your ProForm fitness equipment.

1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and its cables for any signs of damage. Do not use if damaged.
2. **Identify the Power Port:** Locate the power input port on your ProForm treadmill or elliptical. Refer to your equipment's manual if unsure.
3. **Connect to Equipment:** Insert the adapter's output connector firmly into the power input port of your fitness equipment. Ensure a snug fit.
4. **Connect to Power Outlet:** Plug the adapter's AC input plug into a standard wall power outlet. Ensure the outlet is easily accessible.
5. **Verify Connection:** Once connected, the equipment should receive power. Look for power indicator lights on your fitness machine.



Image 1: The Digipartspower AC DC Adapter showing its 2-pin input plug and the output cable with its connector. This view highlights the compact design.



Image 2: A different perspective of the Digipartspower AC DC Adapter, emphasizing the ribbed casing designed for heat dissipation.

OPERATING INSTRUCTIONS

Once the adapter is correctly connected, operating your fitness equipment is straightforward.

1. **Power On:** Turn on your ProForm fitness equipment using its dedicated power button or switch.
2. **Begin Workout:** Operate your equipment as per its own instruction manual. The adapter will continuously supply the necessary power.
3. **Power Off:** After your workout, turn off your fitness equipment.
4. **Disconnect (Optional):** For extended periods of non-use, it is recommended to unplug the adapter from the wall outlet.

The adapter is designed for continuous use during your workout sessions. Its compact design and low power consumption make it suitable for regular use at home.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your AC DC Adapter.

- **Cleaning:** Disconnect the adapter from both the power outlet and the equipment. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Regularly check the power cable for any cuts, fraying, or kinks. Do not use the adapter if the cable is damaged.
- **Ventilation:** Ensure the adapter is placed in an area with adequate ventilation to prevent overheating. Do not cover the adapter during operation.

TROUBLESHOOTING

If you encounter issues with your Digipartspower AC DC Adapter, refer to the following common problems and solutions:

- **No Power to Equipment:**

- Ensure the adapter is securely plugged into both the wall outlet and the fitness equipment.
- Check if the wall outlet is functional by plugging in another device.
- Inspect the adapter cable for any visible damage.

- **Adapter Overheating:**

- Ensure the adapter is not covered and has sufficient ventilation.
- Unplug the adapter and allow it to cool down. If overheating persists, discontinue use.

- **Intermittent Power:**

- Check all connections for looseness.
- Ensure the adapter's output connector is fully inserted into the equipment's power port.

If these steps do not resolve the issue, please contact customer support for further assistance.

SPECIFICATIONS

Brand	Digipartspower
Connector Type	Plug
Compatible Devices	ProForm Treadmills, Ellipticals, and other compatible exercise equipment
Special Feature	Safe (with OCP, OVP, OTP, SCP)
Color	Black
Input Voltage	240 Volts (AC)
Main Power Connector Type	2 Pin
Item Weight	4 Ounces

WARRANTY AND SUPPORT

This Digipartspower AC DC Adapter is backed by a return policy allowing for refund or replacement within 30 days of purchase. For any product-related inquiries, technical support, or warranty claims, please contact the seller, Digipartspower, directly through the platform where the purchase was made. Please retain your proof of purchase for any warranty or support requests.