

DASH DRCM200GBAQ04

DASH Mini Rice Cooker Steamer User Manual

Model: DRCM200GBAQ04

Brand: DASH

INTRODUCTION

The Dash Mini Rice Cooker with Keep Warm technology is designed for convenient, single-serving cooking. This compact appliance simplifies meal preparation, allowing you to cook various grains, soups, and stews with minimal effort. Its intuitive operation and easy-to-clean components make it an ideal addition to any kitchen, especially for those with limited space.

IMPORTANT SAFEGUARDS

Please read and understand all instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

COMPONENTS

Your DASH Mini Rice Cooker Steamer comes with the following components:

- Mini Rice Cooker Base
- Removable Nonstick Pot
- Glass Lid
- Measuring Cup
- Mixing Paddle
- Recipe Guide



INCLUDES EVERYTHING!

Mixing Paddle, Measuring Cup, and
Recipe Guide to *get started!*

Image: All included components of the DASH Mini Rice Cooker, showing the main unit, glass lid, removable nonstick pot, a measuring cup, and a mixing paddle.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the Removable Nonstick Pot, Glass Lid, Measuring Cup, and Mixing Paddle with warm, soapy water. Rinse thoroughly and dry all parts completely.
3. **Placement:** Place the Mini Rice Cooker Base on a stable, flat, heat-resistant surface. Ensure there is adequate ventilation around the unit.
4. **Insert Pot:** Place the clean, dry Removable Nonstick Pot into the Mini Rice Cooker Base.
5. **Power:** Plug the power cord into a standard 110V electrical outlet. The "Warm" indicator light may illuminate, indicating it is in standby mode.



Image: The DASH Mini Rice Cooker in aqua, ready for use, with a bowl of fluffy white rice beside it, demonstrating its primary function.

OPERATING INSTRUCTIONS

Cooking Rice and Grains

1. **Measure Ingredients:** Use the provided measuring cup to add your desired amount of dry grain (e.g., rice, quinoa, oatmeal) to the Removable Nonstick Pot. Refer to the "Grain Cooking Chart" below for recommended ratios.
2. **Add Water:** Add the appropriate amount of water or broth to the pot according to the "Grain Cooking Chart".
3. **Close Lid:** Place the Glass Lid securely on the pot.
4. **Start Cooking:** Press the "COOK" button down. The "COOK" indicator light will illuminate.
5. **Automatic Keep Warm:** Once the cooking cycle is complete, the appliance will automatically switch to the "WARM" mode, and the "WARM" indicator light will illuminate. This function keeps your food warm until you are ready to serve.

6. **Serve:** Carefully remove the lid (steam will be hot) and use the Mixing Paddle to fluff and serve your cooked grain.

Grain Cooking Chart

Measurements are based on a standard measuring cup, not the included Measuring Scoop, which is $\frac{1}{4}$ cup.

Grain	Dry Grain	Water	Cook Time
White Rice	1 cup	1 $\frac{1}{4}$ cups	25-30 minutes
Long Grain Brown Rice	1 cup	1 $\frac{1}{2}$ cups	45-50 minutes
Short Grain Brown Rice	$\frac{3}{4}$ cup	1 $\frac{1}{2}$ cups	45-50 minutes
Quinoa	$\frac{3}{4}$ cup	1 $\frac{1}{2}$ cups water or broth	15-20 minutes
Sushi Rice	$\frac{1}{2}$ cup	$\frac{3}{4}$ cup	30-35 minutes
Barley	$\frac{1}{2}$ cup	1 $\frac{1}{2}$ cups	30-40 minutes
Oats (steel cut)	$\frac{3}{4}$ cup	2 cups	20-25 minutes
Oats (rolled)	$\frac{3}{4}$ cup	1 $\frac{1}{4}$ cups	15-20 minutes

GRAIN GUIDE

➤ A guide for the *perfect* grain to water ratio. ➤

GRAIN	DRY GRAIN	WATER	COOK TIME
White Rice	1 cup	1¼ cups	25-30 minutes
Long Grain Brown Rice	1 cup	1½ cups	45-50 minutes
Short Grain Brown Rice	¾ cup	1½ cups	45-50 minutes
Quinoa	¾ cup	1½ cups water or broth	15-20 minutes
Sushi Rice	½ cup	¾ cup	30-35 minutes
Barley	½ cup	1½ cups	30-40 minutes
Oats (steel cut)	¾ cup	2 cups	20-25 minutes
Oats (rolled)	¾ cup	1¼ cups	15-20 minutes

Measurements are based on a standard measuring cup, not the included Measuring Scoop, which is ¾ cup.

Image: A detailed grain cooking chart providing recommended dry grain to water ratios and approximate cook times for different types of rice, quinoa, barley, and oats.



KEEP IT WARM!

Keep-warm function preserves heat
without overcooking.

Image: The DASH Mini Rice Cooker with its "Warm" indicator light illuminated, demonstrating the automatic keep-warm function that activates after cooking is complete.

ALL-IN-ONE VERSATILITY

Make soups, stews, mac & cheese, and *more!*



Image: Three bowls showcasing different cooked items - quinoa, pasta, and rice - highlighting the cooker's versatility beyond just rice, suitable for soups, stews, and more.

CARE AND MAINTENANCE

Proper care and cleaning will ensure the longevity and optimal performance of your DASH Mini Rice Cooker.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Remove Pot and Lid:** Carefully remove the Removable Nonstick Pot and Glass Lid from the cooker base.
3. **Hand Wash:** The Removable Nonstick Pot, Glass Lid, Measuring Cup, and Mixing Paddle should be hand washed with warm, soapy water. Avoid abrasive cleaners or scouring pads that could damage the nonstick coating.
4. **Rinse and Dry:** Rinse all washed parts thoroughly and dry them completely before reassembling or storing.
5. **Clean Base:** Wipe the exterior of the Mini Rice Cooker Base with a damp cloth. Do not immerse the base in

water or any other liquid.

6. **Storage:** Store the appliance in a cool, dry place when not in use.

TROUBLESHOOTING

If you encounter any issues with your DASH Mini Rice Cooker, please refer to the following common problems and solutions:

- Appliance does not turn on:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the "COOK" button is fully pressed down.
- Rice is too hard or undercooked:**
 - Ensure the correct water-to-grain ratio was used as per the "Grain Cooking Chart".
 - Make sure the lid was properly sealed during cooking.
 - Do not lift the lid frequently during cooking, as this releases steam and heat.
- Rice is too soft or mushy:**
 - Ensure the correct water-to-grain ratio was used as per the "Grain Cooking Chart".
 - Avoid adding too much water.
- Food boils over:**
 - Do not overfill the pot. Ensure ingredients do not exceed the maximum fill line.
 - Some grains, like steel-cut oats, may foam more. Consider reducing the quantity or adding a small amount of oil to prevent excessive foaming.
- Rice sticks to the bottom of the pot:**
 - Ensure the nonstick coating is intact.
 - Add a small amount of cooking oil or butter to the pot before adding ingredients.
 - Ensure the rice is not left on "Warm" mode for excessively long periods.

SPECIFICATIONS

Brand	DASH
Model Name	Mini Rice Cooker Steamer
Model Number	DRCM200GBAQ04
Capacity	0.5 Quarts
Product Dimensions	6.5"D x 8.5"W x 6.3"H

Power Source	Corded Electric
Wattage	200 watts
Voltage	110 Volts
Product Care Instructions	Hand Wash
Material	Metal, Plastic (Lid: Tempered Glass)
Item Weight	1.39 pounds
Color	Aqua

COMPACT SIZE

Fits *comfortably* on the counter.

2 CUPS = ½ QUART
CAPACITY







Image: The compact size of the DASH Mini Rice Cooker is illustrated with its dimensions (6.5"D x 8.5"W x 6.3"H), emphasizing its suitability for small spaces.

WARRANTY AND SUPPORT

DASH products are manufactured to high quality standards. For information regarding warranty coverage, product registration, or customer support, please refer to the official DASH website or the included physical user manual (PDF) for detailed terms and conditions.

You can also find the User Manual (PDF) online: [DASH Mini Rice Cooker User Manual PDF](#)

Related Documents - DRCM200GBAQ04

<p>User Manual of Product 1: DASH Tasti-Crisp™ Digital Air Fryer with AirCrisp Technology Custom Presets, Temperature Control, and Auto Shut Off Features: 8.5 Quart - Aqua</p> <p>User Manual of Product 2: DASH Mini Rice Cooker Steamer with Removable Nonstick Pot, Keep Warm Function & Recipe Guide, 10 Quart, for Steaks, Stews, Grains & Oatmeal - Aqua</p>	<p>DASH Air Fryer & Rice Cooker User Manual and Recipe Guide</p> <p>Comprehensive user manual and recipe guide for the DASH Tasti-Crisp™ Digital Air Fryer (DCAF260) and the DASH Mini Rice Cooker Steamer (DRCM200), featuring setup, operation, maintenance, troubleshooting, and recipes.</p>
<p>User Manual of Product 1: DASH Compact Air Fryer Cooker with Temperature Control, Non-stick Fry Basket, Recipe Guide - Aqua Shut Off Features: 5.8 Quart - Aqua</p> <p>User Manual of Product 2: DASH Mini Rice Cooker Steamer with Removable Nonstick Pot, Keep Warm Function & Recipe Guide, 10 Quart, for Steaks, Stews, Grains & Oatmeal - Aqua</p>	<p>DASH Compact Air Fryer & Mini Rice Cooker User Manuals and Recipe Guides</p> <p>Comprehensive user manuals and recipe guides for DASH Compact Air Fryer (DCAF150) and DASH Mini Rice Cooker (DRCM200), offering cooking instructions, safety information, and culinary inspiration from StoreBound.</p>
 <p>MINI RICE COOKER Instruction Manual Recipe Guide</p>	<p>Dash Mini Rice Cooker: Instruction Manual & Recipe Guide (DRCM200)</p> <p>Comprehensive instruction manual and recipe guide for the Dash Mini Rice Cooker (Model DRCM200). Learn how to safely operate, clean, and maintain your rice cooker, plus discover delicious recipes for various grains, soups, chili, and more.</p>
 <p>MINI RICE COOKER Instruction Manual Recipe Guide</p>	<p>Dash DRCM200 Mini Rice Cooker: Instruction Manual and Recipe Guide</p> <p>Comprehensive guide to using the Dash DRCM200 Mini Rice Cooker, including setup, operation, cleaning, maintenance, and a collection of delicious recipes. Learn how to prepare various dishes with your mini rice cooker.</p>
 <p>MINI RICE COOKER One Touch Cooking 15 Cup Capacity 2000 Watts</p>	<p>Dash Mini Rice Cooker DRCM200: User Manual, Recipes & Support</p> <p>Your complete guide to the Dash Mini Rice Cooker (DRCM200). Includes setup, operation, safety precautions, cleaning instructions, a grain cooking chart, and a collection of delicious recipes. Find customer support and warranty information.</p>
 <p>DELUXE EVERYDAY GRIDDLE Instruction Manual Recipe Guide</p>	<p>DASH Deluxe Everyday Griddle Instruction Manual and Recipe Guide</p> <p>Comprehensive guide for the DASH Deluxe Everyday Griddle, including important safety information, operating instructions, cleaning and maintenance tips, troubleshooting advice, and a collection of recipes.</p>

