

## Philips GC557/30

# Philips GC557/30 ComfortTouch Garment Steamer Instruction Manual

Model: GC557/30



## 1. INTRODUCTION

Thank you for choosing the Philips GC557/30 ComfortTouch Garment Steamer. This manual provides essential information for the safe and effective use of your appliance. Please read it thoroughly before first use and keep it for future reference.

The Philips ComfortTouch Garment Steamer is designed to quickly remove creases and refresh fabrics, offering a convenient alternative to traditional ironing. Its innovative features, such as FlexHead technology and the StyleBoard, ensure efficient and precise garment care.



Figure 1: Philips GC557/30 ComfortTouch Garment Steamer

This image displays the complete Philips GC557/30 ComfortTouch Garment Steamer. It features a white main unit with a purple base, a flexible hose, a steamer head, and an integrated StyleBoard for support during steaming. The design emphasizes ease of use and stability.

## 2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance and its cord out of reach of children.
- Do not leave the appliance unattended when it is switched on.

- Always unplug the appliance before filling the water tank, cleaning, or when not in use.
- Steam is hot. Never direct steam at people, pets, or electrical appliances.
- Use only distilled or demineralized water to prevent limescale buildup and ensure optimal performance.
- Do not use the appliance if the plug, power cord, or the appliance itself shows visible damage.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Philips ComfortTouch Garment Steamer.

1. Steamer Head with FlexHead technology
2. Steam Hose
3. Main Unit Base
4. Water Tank (removable)
5. Steam Settings Dial
6. Power Button
7. Adjustable Pole
8. Integrated Hanger with Hang&Lock feature
9. StyleBoard (extra-long)
10. Brush Accessory



Figure 2: Steamer Head and Controls

This image provides a close-up view of the steamer head, highlighting its design and steam vents. The ergonomic handle and the flexible connection to the hose are visible, demonstrating the FlexHead technology for easier steaming.

## 4. SETUP

Follow these steps to assemble and prepare your garment steamer for first use.

1. **Assemble the Pole:** Insert the adjustable pole into the main unit base until it clicks into place. Extend the pole to your

desired height.

2. **Attach the Hanger and StyleBoard:** Secure the integrated hanger and StyleBoard to the top of the pole. Ensure they are firmly attached.
3. **Fill the Water Tank:** Remove the water tank from the main unit. Open the filling cap and fill the tank with distilled or demineralized water up to the MAX indication. Close the cap securely and place the water tank back into the main unit.
4. **Connect Power:** Plug the power cord into a grounded wall socket.



Figure 3: Water Tank and Steam Settings

This image shows a hand interacting with the water tank and the steam settings dial on the main unit. The transparent water tank allows for easy monitoring of the water level, and the dial indicates various steam settings.

## 5. OPERATING INSTRUCTIONS

---

Follow these steps for effective garment steaming.

1. **Power On:** Press the power button. The indicator light will illuminate, and the appliance will begin to heat up. This usually takes less than a minute.
2. **Select Steam Setting:** Turn the steam settings dial to choose the appropriate steam level for your fabric. The Philips GC557/30 offers 5 steam settings for various fabric types, from delicate silks to heavy cottons.
3. **Prepare Garment:** Hang your garment on the integrated hanger. For best results, use the Hang&Lock feature to secure the hanger. For more structured steaming, place the garment against the StyleBoard.
4. **Begin Steaming:** Hold the steamer head close to the fabric, ensuring it makes gentle contact. Move the steamer head up and down the garment. The FlexHead technology allows for easy movement and reaching lower parts of the garment without bending.
5. **Using the Brush Accessory:** For thicker fabrics like coats or upholstery, attach the brush accessory to the steamer head. This helps to open the fabric weave for better steam penetration and removes lint.
6. **Finishing:** Once steaming is complete, press the power button to turn off the appliance. Unplug the power cord from the wall socket.





Figure 4: Steaming a Garment

This image shows a user actively steaming a dark dress using the Philips ComfortTouch Garment Steamer. The garment is hung on the integrated hanger, and the user is holding the steamer head, demonstrating the ease of use and the upright steaming process.

## 6. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your garment steamer.

- **Empty Water Tank:** After each use, always empty any remaining water from the tank to prevent mineral buildup.
- **Descaling:** Depending on water hardness and frequency of use, descaling may be required. Refer to the full user manual for detailed descaling instructions. Generally, this involves using a descaling solution or a vinegar-water mixture.
- **Clean Steamer Head:** Wipe the steamer head with a damp cloth to remove any residue. Do not use abrasive cleaners.
- **Storage:** Store the appliance in a dry, safe place. Ensure the pole is retracted and the hose is not kinked.

## 7. TROUBLESHOOTING

If you encounter issues with your garment steamer, consult the following table for common problems and solutions.

Problem	Possible Cause	Solution
No steam or very little steam.	<ul style="list-style-type: none"><li>◦ Water tank is empty.</li><li>◦ Appliance not heated sufficiently.</li><li>◦ Limescale buildup.</li></ul>	<ul style="list-style-type: none"><li>◦ Refill the water tank.</li><li>◦ Wait for the appliance to fully heat up (indicator light stable).</li><li>◦ Perform descaling procedure.</li></ul>
Water leakage from the base or steamer head.	<ul style="list-style-type: none"><li>◦ Water tank not properly seated.</li><li>◦ Overfilling the water tank.</li><li>◦ Excessive condensation in the hose.</li><li>◦ Appliance not fully heated.</li></ul>	<ul style="list-style-type: none"><li>◦ Ensure water tank is correctly inserted.</li><li>◦ Do not fill past the MAX line.</li><li>◦ Hold the steamer head higher than the hose to allow condensation to drain back.</li><li>◦ Allow the appliance to heat up completely before use.</li></ul>
Garment still wrinkled after steaming.	<ul style="list-style-type: none"><li>◦ Incorrect steam setting for fabric.</li><li>◦ Steaming too quickly.</li><li>◦ Fabric too thick.</li></ul>	<ul style="list-style-type: none"><li>◦ Increase steam setting.</li><li>◦ Move the steamer head slower over the fabric.</li><li>◦ Use the brush accessory for better steam penetration.</li></ul>

If the problem persists after trying these solutions, please contact Philips customer support.

## 8. SPECIFICATIONS

- **Brand:** Philips
- **Model Number:** GC557/30
- **Power:** 2000 Watts
- **Voltage:** 230 Volts
- **Water Tank Capacity:** 1800 Milliliters
- **Dimensions (L x W x H):** 33.2 x 37.2 x 58.2 cm
- **Weight:** 8.1 Kilograms
- **Auto Shut-off:** Yes
- **Steam Settings:** 5

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Philips website for your region.



If you require further assistance, have questions about spare parts, or need to report a defect, please contact Philips customer support. Contact details can typically be found on the Philips website or in the product packaging.

**Online Support:** [www.philips.com/support](http://www.philips.com/support)





Related Documents - GC557/30

 <p>PHILIPS GC558</p> <p>01 User manual 02 Maintenance</p> <p>01 Manuel de l'utilisateur 02 Maintenance</p>	<p><a href="#">Philips GC558 ComfortTouch Plus Garment Steamer User Manual</a></p> <p>Official user manual for the Philips GC558 ComfortTouch Plus garment steamer. Learn how to use, maintain, and troubleshoot your device for optimal performance. Includes assembly, operation, and safety information.</p>
 <p>PHILIPS STE3170</p> <p>01 User manual 02 用户手册</p> <p>Please read this instruction carefully before using the appliance. 请务必仔细阅读本使用说明书后再使用本产品。 Please keep this instruction book for future reference. 保留此手册。</p>	<p><a href="#">Philips STE3170 Garment Steamer User Manual</a></p> <p>User manual for the Philips STE3170 Garment Steamer, providing instructions on setup, operation, maintenance, and troubleshooting. Includes product specifications and safety information.</p>
 <p>PHILIPS STE3170</p> <p>01 User manual 02 Maintenance</p> <p>01 Manuel de l'utilisateur 02 Maintenance</p>	<p><a href="#">Philips STE3170 Garment Steamer User Manual - Assembly, Operation, Maintenance</a></p> <p>Get detailed instructions for your Philips STE3170 garment steamer. Learn about assembly, how to fill the water tank, steaming techniques, descaling, cleaning, and support. This manual is optimized for SEO and accessibility.</p>
 <p>PHILIPS STE3160</p> <p>01 User manual 02 User manual 03 User manual 04 User manual 05 User manual 06 User manual 07 User manual 08 User manual 09 User manual 10 User manual 11 User manual 12 User manual 13 User manual 14 User manual 15 User manual 16 User manual 17 User manual 18 User manual 19 User manual 20 User manual 21 User manual 22 User manual 23 User manual 24 User manual 25 User manual 26 User manual 27 User manual 28 User manual 29 User manual 30 User manual 31 User manual 32 User manual 33 User manual 34 User manual 35 User manual 36 User manual 37 User manual 38 User manual 39 User manual 40 User manual 41 User manual 42 User manual 43 User manual 44 User manual 45 User manual 46 User manual 47 User manual 48 User manual 49 User manual 50 User manual 51 User manual 52 User manual 53 User manual 54 User manual 55 User manual 56 User manual 57 User manual 58 User manual 59 User manual 60 User manual 61 User manual 62 User manual 63 User manual 64 User manual 65 User manual 66 User manual 67 User manual 68 User manual 69 User manual 70 User manual 71 User manual 72 User manual 73 User manual 74 User manual 75 User manual 76 User manual 77 User manual 78 User manual 79 User manual 80 User manual 81 User manual 82 User manual 83 User manual 84 User manual 85 User manual 86 User manual 87 User manual 88 User manual 89 User manual 90 User manual 91 User manual 92 User manual 93 User manual 94 User manual 95 User manual 96 User manual 97 User manual 98 User manual 99 User manual 100 User manual</p> <p>01 用户手册 02 用户手册 03 用户手册 04 用户手册 05 用户手册 06 用户手册 07 用户手册 08 用户手册 09 用户手册 10 用户手册 11 用户手册 12 用户手册 13 用户手册 14 用户手册 15 用户手册 16 用户手册 17 用户手册 18 用户手册 19 用户手册 20 用户手册 21 用户手册 22 用户手册 23 用户手册 24 用户手册 25 用户手册 26 用户手册 27 用户手册 28 用户手册 29 用户手册 30 用户手册 31 用户手册 32 用户手册 33 用户手册 34 用户手册 35 用户手册 36 用户手册 37 用户手册 38 用户手册 39 用户手册 40 用户手册 41 用户手册 42 用户手册 43 用户手册 44 用户手册 45 用户手册 46 用户手册 47 用户手册 48 用户手册 49 用户手册 50 用户手册 51 用户手册 52 用户手册 53 用户手册 54 用户手册 55 用户手册 56 用户手册 57 用户手册 58 用户手册 59 用户手册 60 用户手册 61 用户手册 62 用户手册 63 用户手册 64 用户手册 65 用户手册 66 用户手册 67 用户手册 68 用户手册 69 用户手册 70 用户手册 71 用户手册 72 用户手册 73 用户手册 74 用户手册 75 用户手册 76 用户手册 77 用户手册 78 用户手册 79 用户手册 80 用户手册 81 用户手册 82 用户手册 83 用户手册 84 用户手册 85 用户手册 86 用户手册 87 用户手册 88 用户手册 89 用户手册 90 用户手册 91 用户手册 92 用户手册 93 用户手册 94 用户手册 95 用户手册 96 用户手册 97 用户手册 98 用户手册 99 用户手册 100 用户手册</p>	<p><a href="#">Philips STE3160 Garment Steamer User Manual</a></p> <p>User manual for the Philips STE3160 garment steamer, providing instructions on assembly, operation, water usage, maintenance (descaling, cleaning), safety precautions, and support. Learn how to use your garment steamer effectively for wrinkle-free clothes.</p>
 <p>PHILIPS Steam&amp;Go</p> <p>01 User manual 02 Maintenance</p> <p>01 Manuel de l'utilisateur 02 Maintenance</p>	<p><a href="#">Philips Steam&amp;Go Handheld Garment Steamer User Manual</a></p> <p>Comprehensive user manual for Philips Steam&amp;Go Handheld Garment Steamer models GC360, GC361, GC362, GC363. Includes setup, operation, safety, maintenance, and troubleshooting instructions.</p>
 <p>PHILIPS STE3160</p> <p>01 User manual 02 User manual 03 User manual 04 User manual 05 User manual 06 User manual 07 User manual 08 User manual 09 User manual 10 User manual 11 User manual 12 User manual 13 User manual 14 User manual 15 User manual 16 User manual 17 User manual 18 User manual 19 User manual 20 User manual 21 User manual 22 User manual 23 User manual 24 User manual 25 User manual 26 User manual 27 User manual 28 User manual 29 User manual 30 User manual 31 User manual 32 User manual 33 User manual 34 User manual 35 User manual 36 User manual 37 User manual 38 User manual 39 User manual 40 User manual 41 User manual 42 User manual 43 User manual 44 User manual 45 User manual 46 User manual 47 User manual 48 User manual 49 User manual 50 User manual 51 User manual 52 User manual 53 User manual 54 User manual 55 User manual 56 User manual 57 User manual 58 User manual 59 User manual 60 User manual 61 User manual 62 User manual 63 User manual 64 User manual 65 User manual 66 User manual 67 User manual 68 User manual 69 User manual 70 User manual 71 User manual 72 User manual 73 User manual 74 User manual 75 User manual 76 User manual 77 User manual 78 User manual 79 User manual 80 User manual 81 User manual 82 User manual 83 User manual 84 User manual 85 User manual 86 User manual 87 User manual 88 User manual 89 User manual 90 User manual 91 User manual 92 User manual 93 User manual 94 User manual 95 User manual 96 User manual 97 User manual 98 User manual 99 User manual 100 User manual</p> <p>01 用户手册 02 用户手册 03 用户手册 04 用户手册 05 用户手册 06 用户手册 07 用户手册 08 用户手册 09 用户手册 10 用户手册 11 用户手册 12 用户手册 13 用户手册 14 用户手册 15 用户手册 16 用户手册 17 用户手册 18 用户手册 19 用户手册 20 用户手册 21 用户手册 22 用户手册 23 用户手册 24 用户手册 25 用户手册 26 用户手册 27 用户手册 28 用户手册 29 用户手册 30 用户手册 31 用户手册 32 用户手册 33 用户手册 34 用户手册 35 用户手册 36 用户手册 37 用户手册 38 用户手册 39 用户手册 40 用户手册 41 用户手册 42 用户手册 43 用户手册 44 用户手册 45 用户手册 46 用户手册 47 用户手册 48 用户手册 49 用户手册 50 用户手册 51 用户手册 52 用户手册 53 用户手册 54 用户手册 55 用户手册 56 用户手册 57 用户手册 58 用户手册 59 用户手册 60 用户手册 61 用户手册 62 用户手册 63 用户手册 64 用户手册 65 用户手册 66 用户手册 67 用户手册 68 用户手册 69 用户手册 70 用户手册 71 用户手册 72 用户手册 73 用户手册 74 用户手册 75 用户手册 76 用户手册 77 用户手册 78 用户手册 79 用户手册 80 用户手册 81 用户手册 82 用户手册 83 用户手册 84 用户手册 85 用户手册 86 用户手册 87 用户手册 88 用户手册 89 用户手册 90 用户手册 91 用户手册 92 用户手册 93 用户手册 94 用户手册 95 用户手册 96 用户手册 97 用户手册 98 用户手册 99 用户手册 100 用户手册</p>	<p><a href="#">Philips STE3160 Garment Steamer User Manual</a></p> <p>Comprehensive user manual for the Philips STE3160 garment steamer, covering setup, usage, maintenance, and troubleshooting. Includes safety warnings and tips for optimal performance.</p>