

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Gourmia](#) /

› [Gourmia GCMW4750 WIFI Coffee Maker with Built-in Grinder - Instruction Manual](#)

Gourmia GCMW4750

Gourmia GCMW4750 WIFI Coffee Maker with Built-in Grinder

Instruction Manual

INTRODUCTION

Thank you for purchasing the Gourmia GCMW4750 WIFI Coffee Maker with Built-in Grinder. This manual provides important information regarding the safe operation, use, and maintenance of your appliance. Please read all instructions thoroughly before first use and retain for future reference.



Image: The Gourmia GCMW4750 coffee maker on a kitchen counter, accompanied by a freshly brewed cup of coffee and two muffins, showcasing its sleek design.

IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycles.
- The carafe is designed for use with this appliance. It must never be used on a range top.
- Do not set a hot carafe on a wet or cold surface.
- Do not use a cracked carafe or a carafe having a loose or weakened handle.
- Do not clean carafe with cleansers, steel wool pads, or other abrasive materials.

PRODUCT OVERVIEW

Control Panel

CONTROL PANEL



Image: A detailed diagram illustrating the control panel of the Gourmia GCMW4750 coffee maker, highlighting the LED Display, Program/Timer, Hour, Minute, Brewing Indicator, Grind button, Brew button, and Display clock.

- **LED Display:** Shows time and brewing status.
- **Program/Timer Button:** Used to set the programmable brew time.
- **HR (Hour) Button:** Adjusts the hour for time and programming.
- **MIN (Minute) Button:** Adjusts the minute for time and programming.
- **Brewing Indicator:** Illuminates when the coffee maker is actively brewing.
- **Grind Button:** Initiates the grinding process for whole beans.
- **Brew Button:** Starts the brewing cycle.
- **Display Clock:** Shows the current time.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and check for any damage. Ensure all parts are present: coffee maker unit, glass carafe, and filter basket.
2. **Initial Cleaning:** Before first use, wash the glass carafe, lid, and filter basket in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.
3. **First Use Cycle:** To clean the internal components, fill the water tank to the MAX line with fresh water. Do not add coffee beans or ground coffee. Place the empty carafe with its lid on the warming plate. Press the "Brew" button to run a full brewing cycle with just water. Discard the water after the cycle. Repeat this process once more.
4. **Placement:** Place the coffee maker on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.
5. **Power Connection:** Plug the power cord into a standard electrical outlet. The LED display will

illuminate.

OPERATING INSTRUCTIONS

Brewing Coffee (4 Easy Steps)

Just 4 EASY STEPS

1

Fill up the water tank.



2

Pour coffee into the coffee bean container, then close the lid.



3

Press grind for coffee beans or brew for ground coffee on the machine or from our app.



4

The machine will keep the coffee warm for about 30 minutes.



gourmia

Image: A visual guide showing four steps: 1. Filling the water tank. 2. Pouring coffee beans into the container. 3. Pressing the grind or brew button. 4. A cup of coffee with the carafe, indicating the keep warm function.

- 1. Fill Water Tank:** Open the lid and fill the water tank with fresh, cold water up to the desired number of cups indicated on the water level indicator. Do not exceed the MAX fill line.
- 2. Add Coffee:**
 - For Whole Beans:** Pour whole coffee beans into the bean container. Close the lid securely.
 - For Pre-Ground Coffee:** Place a paper filter (or permanent filter if included) into the filter basket. Add the desired amount of pre-ground coffee. Close the lid securely.
- 3. Start Brewing:**
 - Grind & Brew:** If using whole beans, press the "Grind" button. The machine will grind the beans and then automatically begin brewing.
 - Brew Pre-Ground:** If using pre-ground coffee, press the "Brew" button. The machine will begin brewing immediately.

4. **Keep Warm:** After brewing is complete, the coffee maker will automatically switch to a "Keep Warm" mode, maintaining the coffee's temperature for up to 30 minutes.

Programmable Timer

The programmable timer allows you to set a specific time for the coffee maker to start brewing automatically.

1. Prepare the coffee maker with water and coffee (beans or ground) as described in the "Brewing Coffee" section.
2. Press the "Program/Timer" button. The display will show "PROG".
3. Use the "HR" and "MIN" buttons to set your desired start time.
4. Press the "Program/Timer" button again to confirm the setting. The display will return to the current time, and a small clock icon will appear, indicating the timer is set.
5. The coffee maker will automatically start brewing at the programmed time.

App and Voice Control (WIFI Connectivity)



Image: A hand holding a smartphone displaying the Gourmia app interface, remotely controlling the coffee maker.

The coffee maker is shown with Wi-Fi signal icons, emphasizing its app control feature.

The Gourmia GCMW4750 can be controlled remotely via a smartphone app and is compatible with Google Assistant.

1. **Download the App:** Search for the official Gourmia app on your smartphone's app store (iOS or Android).
2. **Pairing:** Follow the in-app instructions to connect your coffee maker to your home Wi-Fi network and

pair it with your device. This typically involves putting the coffee maker into pairing mode (refer to the app for specific steps).

3. **Remote Control:** Once paired, you can use the app to start brewing, set schedules, and adjust settings from anywhere.
4. **Voice Control:** Integrate the coffee maker with Google Assistant. Once linked, you can use voice commands such as "Hey Google, brew coffee" to start the brewing process.

Note: Ensure your coffee maker is filled with water and coffee (beans or ground) before initiating remote or voice commands. Consistent Wi-Fi connectivity is essential for these features to function reliably.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and longevity of your coffee maker.

- **Daily Cleaning:** After each use, unplug the coffee maker. Remove the filter basket and carafe. Wash these parts in warm, soapy water, rinse thoroughly, and dry. Wipe the exterior of the coffee maker with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Grinder Cleaning:** Periodically clean the coffee bean container and grinder components. Refer to the app or Gourmia support for specific instructions on disassembling and cleaning the grinder to prevent clogs and ensure fresh coffee flavor.
- **Descaling:** Mineral deposits from water can build up over time and affect performance. Descaling your coffee maker every 2-3 months, or more frequently if you have hard water.
 - a. Fill the water tank with a mixture of white vinegar and water (1:2 ratio).
 - b. Place the empty carafe on the warming plate.
 - c. Run a full brewing cycle.
 - d. After the cycle, let the coffee maker cool for 15 minutes, then discard the vinegar solution.
 - e. Fill the water tank with fresh water and run 2-3 cycles with just water to rinse thoroughly.
- **Storage:** When not in use for extended periods, ensure the coffee maker is clean and dry. Store it in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee does not brew.	No water in tank; power not connected; carafe not properly placed; lid not closed.	Fill water tank; ensure plug is in outlet; place carafe correctly; close lid securely.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; coffee grind size incorrect.	Adjust coffee amount; ensure proper grind setting for whole beans or use appropriate pre-ground coffee.
Grinder is not working.	Bean container empty; grinder clogged; lid not closed properly.	Add coffee beans; clean grinder components; ensure lid is fully closed.

Problem	Possible Cause	Solution
WIFI connection issues.	Incorrect Wi-Fi password; coffee maker too far from router; temporary network issue.	Verify Wi-Fi password; move coffee maker closer to router; restart router and coffee maker; re-pair via app.
Clock display is incorrect or resets.	Power interruption; Wi-Fi connectivity issues affecting time sync.	Reset the clock manually using HR/MIN buttons; ensure stable Wi-Fi connection for automatic time updates.

SPECIFICATIONS

- **Model:** GCMW4750
- **Brand:** Gourmia
- **Capacity:** 10 Cups
- **Material:** Glass, Stainless Steel
- **Special Features:** Programmable, Thermal (Keep Warm), Built-in Grinder, WIFI App Control, Google Assistant Compatibility
- **Operation Mode:** Fully Automatic
- **Color:** Grey
- **Item Weight:** 8.68 pounds
- **Package Dimensions:** 14.5 x 13.5 x 9.75 inches
- **UPC:** 816425021571



Image: A diagram illustrating the dimensions of the Gourmia GCMW4750 coffee maker, showing a height of 12 inches, width of 7.5 inches, and depth of 11.5 inches.

WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the official Gourmia website or contact their customer support directly. Keep your purchase receipt as proof of purchase for warranty claims.

Gourmia Website: www.gourmia.com