

PerfectPrime TL2300

PerfectPrime TL2300 K-Type Thermocouple Sensor Extension Cable User Manual

Model: TL2300

1. INTRODUCTION

This manual provides essential information for the proper use, setup, and maintenance of your PerfectPrime TL2300 K-Type Thermocouple Sensor Extension Cable. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

2. PRODUCT OVERVIEW

The PerfectPrime TL2300 is a K-Type thermocouple extension cable designed to extend the reach of your K-Type thermocouple sensors to compatible measuring devices. It features standard K-Type flat connectors for reliable and accurate temperature signal transmission.

2.1 Key Features

- **Connector Type:** Female to Male K-Type Flat connector
- **Maximum Temperature Rating:** 300 °C (for the cable insulation)
- **Length:** 3 meters / 9.8 feet
- **Wire Material:** Polytetrafluoroethylene (PTFE) insulated wire
- **Weight:** Approximately 35g

2.2 Components

The TL2300 cable consists of a K-Type thermocouple wire terminated with a male flat pin connector on one end and a female flat socket connector on the other.



Image 1: The PerfectPrime TL2300 K-Type Thermocouple Sensor Extension Cable, showing the full length of the brown PTFE-insulated cable with yellow male and female flat connectors at each end.




Image 2: An angled view of the yellow K-Type male and female flat connectors, highlighting their design and connection points.

3. SETUP

Follow these steps to properly connect your TL2300 extension cable with a K-Type thermocouple sensor and a compatible measuring device.

- 1. Identify Connectors:** The TL2300 cable has a male flat pin connector and a female flat socket connector. K-Type connectors are typically yellow.
- 2. Connect Sensor:** Plug the male flat pin connector of your K-Type thermocouple sensor into the female flat socket connector of the TL2300 extension cable. Ensure a firm connection.
- 3. Connect to Device:** Plug the male flat pin connector of the TL2300 extension cable into the K-Type input port of your compatible temperature measuring device (e.g., thermometer, datalogger). Observe polarity: the wider pin/socket typically corresponds to the positive (+) terminal, and the narrower pin/socket to the negative (-) terminal. K-Type connectors are designed to prevent incorrect polarity connection, but always verify.



Image 3: A close-up view of the yellow K-Type male and female flat connectors, showing the positive (+) and negative (-) polarity markings for correct connection.



Image 4: An example of a compatible K-Type thermometer with multiple probes connected, illustrating how the extension cable would integrate into a measurement setup.

4. OPERATING INSTRUCTIONS

Once the TL2300 extension cable is correctly connected between your K-Type thermocouple sensor and measuring device, operation is straightforward.

- 1. Power On:** Turn on your temperature measuring device.
- 2. Verify Connection:** Ensure the device recognizes the connected thermocouple and displays a temperature reading. If the reading is erratic or shows an error, check all connections.
- 3. Take Measurements:** Position your K-Type thermocouple sensor at the desired measurement point. The extension cable allows for greater flexibility in sensor placement.
- 4. Observe Readings:** Monitor the temperature readings on your device. The TL2300 cable is designed to transmit the thermocouple signal accurately over its length.

Important Considerations:

- Avoid bending the cable sharply, as this can damage the internal wiring.
- Do not exceed the maximum temperature rating of the cable insulation (300 °C).
- Ensure the environment where the cable is used is free from excessive moisture or corrosive substances unless the cable is specifically rated for such conditions.

5. MAINTENANCE

Proper care and maintenance will help prolong the life and accuracy of your TL2300 extension cable.

- Cleaning:** Wipe the cable and connectors with a clean, dry cloth. If necessary, use a slightly damp cloth with mild soap, then dry thoroughly. Do not immerse the connectors in liquid.
- Storage:** Store the cable in a clean, dry environment, away from direct sunlight and extreme

temperatures. Avoid coiling the cable too tightly.

- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, damage, or corrosion. Replace the cable if any damage is observed to prevent inaccurate readings or electrical hazards.
- **Handling:** Always handle the connectors by their plastic housing, not by pulling on the cable itself.

6. TROUBLESHOOTING

If you encounter issues with your TL2300 extension cable, consider the following troubleshooting steps:

- **No Reading or Erratic Readings:**

- Ensure all connections (sensor to cable, cable to device) are secure and fully inserted.
- Verify that the thermocouple sensor itself is functioning correctly by testing it directly with the measuring device if possible.
- Check for any visible damage to the cable or connectors.

- **Incorrect Temperature Reading:**

- Confirm that both the sensor and the measuring device are set to the correct thermocouple type (K-Type).
- Ensure there are no strong electromagnetic fields near the cable, which can interfere with the signal.
- Verify that the cable is not exposed to temperatures exceeding its maximum rating, which could affect its insulation and signal integrity.

If problems persist after following these steps, contact PerfectPrime customer support for further assistance.

7. SPECIFICATIONS


Feature	Specification
Model Number	TL2300
Connector Type	K-Type Flat (Female to Male)
Cable Length	3 meters / 9.8 feet
Wire Insulation Material	Polytetrafluoroethylene (PTFE)
Maximum Operating Temperature	300 °C (for cable insulation)
Weight	35g
Package Dimensions	5.24 x 5.04 x 0.63 inches

8. WARRANTY AND SUPPORT

PerfectPrime products are manufactured to high-quality standards. For warranty information, technical support, or any inquiries regarding your TL2300 K-Type Thermocouple Sensor Extension Cable, please refer to the contact information provided with your purchase or visit the official PerfectPrime website. Please retain your proof of purchase for warranty claims.

© 2023 PerfectPrime. All rights reserved.

Related Documents - TL2300

	<p><u>PerfectPrime TC0520 USB Interface Protocol Guide</u></p> <p>A comprehensive guide to the USB interface protocol for the PerfectPrime TC0520 datalogger thermometer, detailing commands, data output, and error checking.</p>
	<p><u>PerfectPrime AR168 Digital Pressure Gauge Instruction Manual</u></p> <p>Instruction manual for the PerfectPrime AR168 Digital Pressure Gauge, covering product introduction, basic functions, technical performance, measurement ranges, symbol definitions, button operations, precautions, and additional information.</p>