

[Manuals.plus](#) /

› [Standard Motor Products](#) /

› Standard Ignition PC1048 Camshaft Sensor Instruction Manual

Standard Motor Products PC1048

Standard Ignition PC1048 Camshaft Sensor Instruction Manual

Brand: Standard Motor Products | **Model:** PC1048

1. INTRODUCTION

This instruction manual provides essential information for the proper understanding, installation, and maintenance of the Standard Ignition PC1048 Camshaft Sensor. Designed for automotive applications, this sensor plays a critical role in your vehicle's engine management system. Please read this manual thoroughly before proceeding with any installation or diagnostic procedures.

2. PRODUCT OVERVIEW

The Standard Ignition PC1048 Camshaft Sensor is engineered to deliver reliable and consistent performance within your vehicle's engine. It is manufactured using high-quality materials to ensure durability and is designed to meet or exceed strict quality requirements.

Key Features:

- Designed to deliver trouble-free, consistent performance.
- Right for your vehicle and lifestyle.
- Made from high-quality materials for ultimate durability.
- Manufactured to meet or exceed strict quality requirements.

Product Images:



Figure 2.1: Front view of the Standard Ignition PC1048 Camshaft Sensor, showing the main body and electrical connector.



Figure 2.2: Side view of the sensor, highlighting the mounting flange and the sensor tip.



Figure 2.3: Close-up view of the electrical connector pins on the camshaft sensor.

3. SETUP (INSTALLATION)

The installation of a camshaft position sensor requires specific automotive knowledge and tools. It is highly recommended that installation be performed by a qualified automotive technician. If you choose to perform the installation yourself, proceed with caution and consult your vehicle's specific service manual for detailed instructions and safety precautions.

General Installation Guidelines:

1. **Safety First:** Disconnect the vehicle's battery before beginning any work. Ensure the engine is cool to the touch.
2. **Locate the Sensor:** Refer to your vehicle's service manual to identify the exact location of the camshaft position sensor. Locations vary by vehicle make and model.
3. **Disconnect Electrical Connector:** Carefully disconnect the electrical connector from the old sensor. Avoid pulling on the wires.
4. **Remove Old Sensor:** Unscrew or unbolt the old sensor from its mounting point. Be aware of any O-rings or seals that may be present.
5. **Prepare New Sensor:** Ensure the new PC1048 sensor has a new O-ring (if applicable) and apply a small amount of clean engine oil to it for easier installation and proper sealing.
6. **Install New Sensor:** Insert the new sensor into its mounting hole, ensuring it seats correctly. Tighten the retaining bolt or screw to the manufacturer's specified torque. *Do not overtighten.*
7. **Reconnect Electrical Connector:** Firmly connect the electrical connector to the new sensor until it clicks into place.
8. **Reconnect Battery:** Reconnect the vehicle's battery.
9. **Test:** Start the engine and check for proper operation and the absence of any warning lights. It may be necessary to clear any stored diagnostic trouble codes (DTCs) using an OBD-II scanner.

Note: These are general guidelines. Always follow the specific procedures outlined in your vehicle's official service manual.

4. OPERATING PRINCIPLES

The Standard Ignition PC1048 Camshaft Sensor is a critical component of your vehicle's engine control system. It

monitors the rotational speed and position of the camshaft, which is essential for the Engine Control Unit (ECU) to determine the precise timing for fuel injection and ignition. This sensor works in conjunction with the crankshaft position sensor to synchronize engine operations.

Once correctly installed, the sensor operates automatically as part of the vehicle's electronic system. It does not require any direct user interaction for its operation. Its proper functioning is integral to engine performance, fuel efficiency, and emissions control.

5. MAINTENANCE

The Standard Ignition PC1048 Camshaft Sensor is designed to be a maintenance-free component once installed. Regular maintenance of the sensor itself is generally not required. However, ensuring the overall health of your vehicle's engine and electrical system can contribute to the longevity and reliable operation of the sensor.

General Recommendations:

- **Keep Engine Bay Clean:** Periodically inspect the engine bay for excessive dirt, debris, or fluid leaks that could potentially affect electrical connections or sensor integrity.
- **Inspect Wiring:** During routine vehicle inspections, check the wiring harness connected to the sensor for any signs of damage, fraying, or corrosion.
- **Avoid Contaminants:** Prevent oil, coolant, or other automotive fluids from coming into prolonged contact with the sensor body or electrical connector.

Note: If the sensor or its wiring appears damaged, replacement is typically the recommended course of action rather than repair.

6. TROUBLESHOOTING

A malfunctioning camshaft position sensor can lead to various engine performance issues. If you suspect a problem with your PC1048 sensor, consider the following common symptoms and diagnostic steps. Professional diagnosis is always recommended.

Common Symptoms of a Faulty Camshaft Sensor:

- **Check Engine Light (CEL):** Illumination of the Check Engine Light on your dashboard, often accompanied by specific Diagnostic Trouble Codes (DTCs) related to camshaft position.
- **Engine Cranks but Won't Start:** The engine may crank normally but fail to ignite, as the ECU cannot determine proper ignition timing.
- **Rough Idling or Stalling:** Erratic engine speed at idle or the engine stalling unexpectedly.
- **Reduced Engine Performance:** Decreased power, poor acceleration, or reduced fuel economy.
- **Engine Misfires:** Irregular combustion events in one or more cylinders.

Diagnostic Steps (Professional Recommended):

1. **Scan for DTCs:** Use an OBD-II scanner to retrieve any stored trouble codes. Codes like P0340, P0341, P0342, P0343, P0345, P0346, P0347, P0348 typically indicate camshaft position sensor issues.
2. **Inspect Wiring and Connector:** Visually check the sensor's electrical connector and wiring harness for any signs of damage, corrosion, or loose connections.
3. **Check Sensor Resistance/Voltage:** A qualified technician can use a multimeter or oscilloscope to test the sensor's resistance or signal output according to vehicle manufacturer specifications.
4. **Verify Mechanical Alignment:** Ensure the sensor is properly seated and aligned with the camshaft reluctor wheel.

Warning: Attempting repairs without proper knowledge and tools can cause further damage to your vehicle. Always consult a

7. SPECIFICATIONS

The following table details the key specifications for the Standard Ignition PC1048 Camshaft Sensor:

Specification	Value
Brand	Standard Motor Products
Model	PC1048
Manufacturer Part Number	PC1048
Item Model Number	PC1048
UPC	033086186436
Global Trade Identification Number	00033086186436
Item Weight	1 Pounds
Product Dimensions (L x W x H)	1 x 1 x 1 inches
Mounting Type	Flange Mount
Style	Modern
Date First Available	October 4, 2018

8. WARRANTY AND SUPPORT

For specific warranty information regarding the Standard Ignition PC1048 Camshaft Sensor, please refer to the documentation provided with your purchase or contact the seller directly. Warranty terms typically cover manufacturing defects for a specified period.

For technical support, fitment information, or any questions not covered in this manual, please contact Standard Motor Products directly. You can usually find their official contact information, including customer service numbers and website, by searching for "Standard Motor Products" online.

Disclaimer: This manual is for informational purposes only. Standard Motor Products is not responsible for any damage or injury resulting from improper installation or misuse of this product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07J1X13MT>

More documents and user manuals: <https://manuals.plus/>