

[Manuals.plus](#) /

› [Estar](#) /

› Eastar Carburetor Instruction Manual for Ryobi 4-Cycle Engines

Eastar YTL0613

Eastar Carburetor Instruction Manual

For Ryobi 4-Cycle Wheeled Trimmers, Edgers, Gas Powerheads, and Cultivators

1. INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your new Eastar replacement carburetor. This carburetor is designed to be a direct replacement for specific Ryobi 4-cycle outdoor power equipment models. Please read this manual thoroughly before attempting any installation or operation to ensure proper function and safety.

The Eastar carburetor (Manufacturer Part Number: YTL0613) is an aftermarket replacement component. While designed for compatibility and reliable performance, it is not a genuine Ryobi part.

2. PRODUCT COMPATIBILITY

This Eastar carburetor is compatible with the following Ryobi 4-cycle outdoor power equipment models and corresponding manufacturer part numbers:

- **Ryobi Manufacturer Part Numbers:** 309368001, 309368002, 309368003
- **Compatible Ryobi Models:**
 - RY13010 4-Cycle Wheeled Trimmer (30cc)
 - RY13015 30cc 4-Cycle Wheeled Trimmer
 - RY13050A 4-Cycle Wheeled Edger (30cc)
 - RY34000 4-Cycle Gas Powerhead (30cc)
 - RY34420 Gas String Trimmer (30cc)
 - RY34440 (S430) Gas String Trimmer (30cc)
 - RY64400 4-Cycle Cultivator

Please verify your equipment's model number and existing carburetor's part number before installation to ensure proper fitment.

3. SETUP AND INSTALLATION

Carburetor replacement requires mechanical aptitude. If you are unsure about any step, it is recommended to seek assistance from a qualified service technician. Always ensure the engine is cool and disconnected from any power source (e.g., spark plug wire removed) before beginning work.

3.1 Safety Precautions

- Wear appropriate personal protective equipment, including safety glasses and gloves.
- Work in a well-ventilated area.
- Keep flammable materials away from the work area.
- Ensure the engine is completely cool before handling.

3.2 General Installation Steps

1. **Drain Fuel:** Safely drain all fuel from the equipment's fuel tank.
2. **Access Carburetor:** Remove any air filter covers, air filters, and other components obstructing access to the carburetor.
3. **Disconnect Lines:** Carefully disconnect the fuel lines, throttle linkage, and choke linkage from the old carburetor. Note their positions for reassembly.
4. **Remove Old Carburetor:** Unbolt and remove the old carburetor from the engine.
5. **Install New Carburetor:** Place the new Eastar carburetor, ensuring any gaskets are correctly seated. Reattach the mounting bolts and tighten securely.
6. **Reconnect Lines:** Reconnect the fuel lines, throttle linkage, and choke linkage to the new carburetor in their original positions. Ensure fuel lines are properly routed and secured.
7. **Reassemble Components:** Reinstall the air filter, air filter cover, and any other components removed to access the carburetor.
8. **Refill Fuel:** Refill the fuel tank with fresh, appropriate gasoline (unmixed for 4-cycle engines).




Figure 3.1: Front view of the Eastar replacement carburetor, showing the primer bulb and throttle linkage.



Figure 3.2: Side view of the carburetor, highlighting the yellow choke lever and fuel line connections.

4. OPERATING INSTRUCTIONS

After successful installation, follow your equipment's manufacturer's instructions for starting and operating the engine. The carburetor's primary function is to mix air and fuel for combustion; its operation is integrated with the engine's overall system.

4.1 Initial Start-Up

1. **Prime the Carburetor:** Press the primer bulb several times until fuel is visible in the bulb and flows freely.
2. **Choke Setting:** Set the choke lever to the 'FULL CHOKE' position (usually indicated by a symbol or 'START').
3. **Start Engine:** Follow your equipment's specific starting procedure (e.g., pull starter cord, press ignition button).
4. **Adjust Choke:** Once the engine fires or starts to run, gradually move the choke lever to the 'HALF CHOKE' position, then to 'RUN' as the engine warms up and runs smoothly.

If the engine does not start after several attempts, refer to the Troubleshooting section or your equipment's original manual.

5. MAINTENANCE

Proper maintenance extends the life of your carburetor and ensures optimal engine performance. Regular inspection and cleaning are recommended.

5.1 General Carburetor Maintenance Tips

- **Fuel Quality:** Always use fresh, clean gasoline. Stale fuel can cause deposits and clog carburetor passages.
- **Fuel Filter:** Regularly inspect and replace the fuel filter (located in the fuel tank or inline) to prevent contaminants from reaching the carburetor.
- **Air Filter:** Ensure the air filter is clean and free of debris. A clogged air filter can affect the air-fuel mixture.
- **Storage:** Before long-term storage, either run the engine until it runs out of fuel or use a fuel stabilizer to prevent fuel degradation and carburetor gumming.
- **Cleaning:** If performance issues arise due to suspected carburetor clogging, a carburetor cleaner spray can be used. For deeper cleaning, disassembly by a qualified technician may be necessary.

6. TROUBLESHOOTING

If your engine experiences issues after carburetor replacement, consider the following common troubleshooting steps:

- **Engine Not Starting:**
 - Check for proper fuel flow to the carburetor.
 - Ensure the primer bulb is working and fuel is visible.
 - Verify spark plug condition and spark.
 - Confirm choke lever position is correct for starting.
- **Engine Runs Rough or Stalls:**
 - Inspect fuel lines for kinks or leaks.
 - Check air filter for cleanliness.
 - Ensure all linkages (throttle, choke) are connected and moving freely.
 - Verify that the carburetor is securely mounted and gaskets are intact, preventing air leaks.
- **Fuel Leaks:**
 - Tighten all fuel line connections.
 - Inspect fuel lines for cracks or damage.
 - Ensure the carburetor's float bowl is not overflowing (may indicate a stuck float or needle valve).

For persistent issues, consult your equipment's original service manual or a professional repair service.

7. SPECIFICATIONS

Key specifications for the Eastar replacement carburetor (Model YTL0613):

Feature	Detail
Condition	New
Material	Plastic & Metal

Feature	Detail
Manufacturer Part Number	YTL0613 (Replaces 309368001, 309368002, 309368003)
Item Included	1 x Carburetor
Power Source	Gasoline-powered (for 4-cycle engines)

7.1 Dimensions



Figure 7.1: Approximate dimensions of the Eastar carburetor. Length: 6.9 cm, Height: 5.7 cm, Mounting Hole Distance: 3.1 cm.

Note: All dimensions are measured by hand and may have small deviations. Color may vary slightly due to manufacturing processes or individual monitor settings.

8. WARRANTY INFORMATION

Specific warranty details for this Eastar replacement carburetor were not provided in the product information. Please refer to the seller’s return policy or contact the seller directly for any warranty-related inquiries.

9. SUPPORT

For technical assistance or questions regarding this Eastar carburetor, please contact the seller or manufacturer directly through the platform where the product was purchased. Specific contact information for Eastar support was not provided in the product details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question