

Smartby NS-RC4NA-18

User Manual: NS-RC4NA-18 Remote Control

Model: Smartby NS-RC4NA-18 | Brand: Smartby

1. INTRODUCTION

This manual provides comprehensive instructions for the Smartby NS-RC4NA-18 remote control, designed as a direct replacement for various Insignia TV models. This remote requires no programming and is ready for use immediately after battery installation.

Compatible Insignia TV Models include: NS19D220MX16A, NS19D220NA16A, NS19D310NA19, NS24D310NA19, NS32D220NA18, NS39D310NA17, NS40D420MX18, NS40D420NA18, NS49D420NA18, NS50D510MX17, NS50D510MX19, NS50D510NA17, NS50D510NA19, NS55D420MX18, NS55D420NA18, NS55D510NA19.

2. SETUP: BATTERY INSTALLATION

The NS-RC4NA-18 remote control operates on two (2) AAA alkaline batteries. Batteries are not included with the remote and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

No programming or pairing is required for this remote control. It is ready for immediate use with compatible Insignia TVs once batteries are installed.






Figure 2.1: Front view of the NS-RC4NA-18 remote control. The battery compartment is located on the reverse side.

3. OPERATING INSTRUCTIONS

The NS-RC4NA-18 remote control provides full functionality for your compatible Insignia TV. Below is a guide to the primary buttons and their functions:

Button	Function
Power ()	Turns the TV on or off.
INPUT	Cycles through available input sources (HDMI, AV, Component, etc.).
Number Pad (0-9)	Directly enters channel numbers.
MENU	Opens the TV's main menu for settings and options.
Navigation Arrows (▲ ▼ ◀ ▶)	Navigates through menu options and channel lists.
ENTER	Confirms selections in menus.
EXIT	Exits the current menu or on-screen display.
INFO*	Displays information about the current program or input.
FAVORITE	Accesses favorite channels list.
ACC	Accesses audio description or accessibility features.
CC	Toggles Closed Captions on or off.
VOL +/-	Adjusts the volume level up or down.
MUTE	Mutes or unmutes the TV audio.
CH ▲ ▼	Changes the channel up or down.
SLEEP	Sets a sleep timer for the TV.
ASPECT	Changes the screen aspect ratio.
GAME	Activates or deactivates game mode.
PICTURE	Accesses picture settings.
AUDIO	Accesses audio settings or changes audio tracks.
Media Controls (▶ ■)	Controls playback of media (Play, Pause, Stop, Rewind, Fast Forward, Skip Back, Skip Forward).

Ensure there is a clear line of sight between the remote control and the TV's infrared sensor for optimal performance.

4. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.
- **Avoid Extreme Conditions:** Do not expose the remote to extreme temperatures, direct sunlight, or high humidity.

5. TROUBLESHOOTING

Problem	Possible Cause / Solution
Remote is not working at all.	<ul style="list-style-type: none"> ◦ Batteries: Ensure batteries are inserted correctly with correct polarity (+/-). Replace old or dead batteries with new AAA alkaline batteries. ◦ Line of Sight: Ensure there are no obstructions between the remote and the TV's infrared sensor. ◦ Distance: Make sure you are within the effective range of the remote control.
Some buttons are not responding.	<ul style="list-style-type: none"> ◦ Batteries: Low battery power can cause intermittent button response. Replace batteries. ◦ Dirt/Debris: Check if there is any dirt or debris lodged under the unresponsive buttons. Gently clean around the buttons. ◦ Compatibility: Verify that your TV model is listed as compatible with this remote.
Remote works intermittently.	<ul style="list-style-type: none"> ◦ Batteries: Batteries may be low. Replace them. ◦ Interference: Other electronic devices or strong light sources (like direct sunlight) can sometimes interfere with infrared signals. Try using the remote in a different environment.

6. SPECIFICATIONS

- **Model:** Smartby NS-RC4NA-18
- **Product Dimensions:** 7 x 2 x 0.7 inches
- **Item Weight:** 2.4 ounces
- **Power Supply:** 2 x AAA Alkaline Batteries (not included)
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Insignia Televisions (specific models listed in Introduction)
- **Special Feature:** Ergonomic design

7. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support for your Smartby NS-RC4NA-18 remote control, please refer to the original purchase documentation or contact the seller directly.

Specific warranty terms may vary by retailer and region.

For general product inquiries, you may visit the [Smartby Store on Amazon](#).

© 2024 Smartby. All rights reserved. Insignia is a registered trademark of Best Buy and its affiliated companies.

Related Documents - NS-RC4NA-18

 <small>IN SIGNIA</small> USER GUIDE LED TV User Guide <small>Before you begin, please read these instructions to ensure a safe and enjoyable viewing experience.</small>	<p><u>Insignia LED TV User Guide: Setup, Operation, and Troubleshooting</u></p> <p>Comprehensive user guide for the Insignia LED TV, covering setup, connecting devices, operating features, picture and sound adjustments, troubleshooting common issues, and warranty information.</p>
 <small>IN SIGNIA</small> USER GUIDE LED TV User Guide <small>Before you begin, please read these instructions to ensure a safe and enjoyable viewing experience.</small>	<p><u>Insignia LED TV User Guide</u></p> <p>Comprehensive user guide for the Insignia LED TV, covering setup, features, connections, troubleshooting, and warranty information. Learn how to optimize your viewing experience.</p>
 <small>IN SIGNIA</small> USER GUIDE LED TV User Guide <small>Before you begin, please read these instructions to ensure a safe and enjoyable viewing experience.</small>	<p><u>Insignia LED TV User Guide</u></p> <p>Comprehensive user guide for Insignia LED TVs, covering setup, connections, remote control operation, picture and sound adjustments, troubleshooting, and maintenance.</p>
 <small>IN SIGNIA</small> USER GUIDE LED TV User Guide <small>Before you begin, please read these instructions to ensure a safe and enjoyable viewing experience.</small>	<p><u>Insignia LED TV User Guide - Setup, Features, and Troubleshooting</u></p> <p>Comprehensive user guide for Insignia LED TVs, covering setup, connections, picture and sound settings, INlink, troubleshooting, and maintenance for optimal viewing experience. Visit insigniaproducts.com for support.</p>

 USER GUIDE LED TV User Guide <small>Before using this product, please read these instructions in its entirety.</small>	<p>Insignia LED TV User Guide: Setup, Features, and Troubleshooting Comprehensive user guide for Insignia LED TVs, covering setup, connections, picture/sound settings, remote control, and troubleshooting. Learn to optimize your viewing experience.</p>
 USER GUIDE LED TV User Guide <small>Before using this product, please read these instructions in its entirety.</small>	<p>Insignia LED TV User Guide: Setup, Operation, and Troubleshooting Comprehensive user guide for Insignia LED TVs, covering safety precautions, initial setup, connecting devices, operating features, and troubleshooting common issues. Learn how to get the most out of your Insignia television.</p>