

[Manuals.plus](#) /

› [Toastmaster](#) /

› Toastmaster 10-Cup Electric Rice Cooker (Model TM-101RCCN) Instruction Manual

Toastmaster TM-101RCCN

Toastmaster 10-Cup Electric Rice Cooker Instruction Manual

Model: TM-101RCCN

INTRODUCTION

Thank you for purchasing the Toastmaster 10-Cup Electric Rice Cooker. This appliance is designed to simplify your cooking process, providing perfectly cooked rice and other grains with minimal effort. Please read this instruction manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.



A front-facing view of the Toastmaster electric rice cooker. It features a black exterior, a clear tempered glass lid with a black knob, and a black serving spoon resting in a side holder. The control panel has 'WARM/MOYEN' and 'COOK/CUISINIER' indicators.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package:

- Toastmaster Electric Rice Cooker Unit
- Removable Non-Stick Inner Pot
- Tempered Glass Lid
- Measuring Cup
- Mixing/Serving Spoon

Accessories



Mixing spoon



Measuring cup

This image displays the accessories included with the rice cooker: a black mixing spoon with a textured surface and a clear plastic

measuring cup.

PRODUCT FEATURES

The Toastmaster Electric Rice Cooker is designed for convenience and efficiency:

- **10-Cup Capacity:** Prepares 3 to 10 cups of cooked rice, suitable for various meal sizes.
- **Automatic Cooking:** One-touch operation initiates cooking, completing most rice types in under 20 minutes.
- **Keep Warm Mode:** Automatically switches to 'Keep Warm' after cooking to maintain optimal serving temperature and prevent overcooking.
- **Durable Inner Pot:** Features a stainless steel inner pot for even heat distribution and consistent results.
- **Tempered Glass Lid:** Allows monitoring of the cooking process without releasing steam.
- **Versatile Use:** Capable of preparing not only rice but also soups, oatmeal, and other grains.

Thoughtful Design



This image highlights three key features of the rice cooker: 'Simple One-Touch Operation' for ease of use, 'Tempered glass lid' for durability and visibility, and 'Keep warm mode' to maintain food temperature after cooking.

Versatile Use



Rice



Soups



Oatmeal



An illustration demonstrating the versatile applications of the Toastmaster electric rice cooker, indicating its suitability for preparing rice, soups, and oatmeal. The image shows the inner pot removed from the main unit.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the inner pot, glass lid, measuring cup, and mixing spoon in warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the rice cooker unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, level, heat-resistant surface, away from walls or cabinets to allow for proper ventilation. Ensure it is out of reach of children and pets.
4. **Power:** Ensure the power cord is not damaged and the voltage matches your household's electrical supply (120 Volts).

OPERATING INSTRUCTIONS

Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of uncooked rice. One full measuring cup typically yields about 2 cups of cooked rice.
2. **Rinse Rice:** Rinse the rice in a separate bowl until the water runs clear. This helps remove excess starch.
3. **Add to Pot:** Place the rinsed rice into the removable inner pot.
4. **Add Water:** For white rice, a general ratio is 1 measuring cup of rice to 1.5 measuring cups of water. Adjust water levels according to rice type and personal preference. The inner pot has water level markings for convenience.
5. **Place Inner Pot:** Ensure the exterior of the inner pot is dry, then place it into the main rice cooker unit.
6. **Secure Lid:** Place the tempered glass lid securely on the rice cooker.
7. **Plug In:** Plug the power cord into a 120V electrical outlet. The 'WARM' indicator light will illuminate.
8. **Start Cooking:** Press the 'COOK' switch down. The 'COOK' indicator light will illuminate, and cooking will begin.
9. **Automatic Keep Warm:** Once the rice is cooked, the 'COOK' switch will automatically flip up, and the rice cooker will switch to 'WARM' mode. The 'WARM' indicator light will remain on.
10. **Resting Period:** For best results, allow the rice to rest in 'WARM' mode for 5-10 minutes before serving. This allows the steam to distribute evenly.
11. **Serve:** Use the provided mixing spoon to fluff and serve the rice. Avoid using metal utensils that could scratch the non-stick coating.
12. **Unplug:** Always unplug the rice cooker from the outlet when not in use.

Cooking Other Grains or Soups

The rice cooker can also be used for other grains like oatmeal or for preparing soups. Adjust water ratios and cooking times as per the specific recipe or grain type. Monitor the cooking process through the glass lid.

CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and performance of your rice cooker.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Inner Pot and Lid:** Wash the removable inner pot, glass lid, measuring cup, and mixing spoon in warm, soapy water. These parts are generally not dishwasher safe; hand washing is recommended. Rinse thoroughly and dry completely.
- **Exterior:** Wipe the exterior of the rice cooker unit with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water or any other liquid.
- **Storage:** Store the rice cooker in a dry place when not in use.

TROUBLESHOOTING

If you encounter issues with your rice cooker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice is too hard/undercooked	Not enough water; cooking cycle interrupted.	Add slightly more water next time; ensure lid is secure during cooking.
Rice is too soft/mushy	Too much water.	Reduce water slightly next time.

Problem	Possible Cause	Solution
Rice sticks to the bottom	Insufficient water; rice not rinsed; prolonged 'Keep Warm' cycle.	Ensure proper water ratio; rinse rice thoroughly; serve promptly after cooking or reduce 'Keep Warm' time.
Cooker does not turn on	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power supply; try a different outlet.
Steam escaping from lid	Lid not properly seated; lid gasket damaged.	Ensure lid is securely placed; inspect lid gasket for damage.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Specification	Detail
Brand	Toastmaster
Model Number	TM-101RCCN
Capacity	10 Cups (cooked rice)
Power	400 Watts
Voltage	120 Volts
Material	Stainless Steel (inner pot)
Color	Black
Product Dimensions (LxWxH)	23.9 cm x 28.3 cm x 21.2 cm (9.41 in x 11.14 in x 8.35 in)
Product Weight	3.31 Pounds (1.5 kg)
Care Instructions	Hand Wash

Electric Rice Cooker



3.31 POUNDS



400 WATTS



120 VOLTS

An image showing the dimensions of the Toastmaster electric rice cooker: 11.14 inches wide, 9.41 inches deep, and 8.35 inches high. Below the cooker, icons indicate its weight (3.31 pounds), power consumption (400 watts), and voltage (120 volts).

WARRANTY AND SUPPORT

This product is covered by a limited manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact the manufacturer directly.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Toastmaster customer service. Contact information can typically be found on the manufacturer's website or on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question