

[manuals.plus](#) /› [Marathon](#) /› [Marathon CL030050P Digital Desk Clock User Manual](#)**Marathon CL030050P**

# Marathon CL030050P Digital Desk Clock User Manual

## 1. INTRODUCTION

Thank you for purchasing the Marathon CL030050P Digital Desk Clock. This compact and versatile clock is designed for convenience, offering a clear digital display with a soft blue backlight, an alarm with snooze function, temperature display, and multi-language day of the week display. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.



Figure 1: Front view of the Marathon CL030050P Digital Desk Clock.

## 2. PACKAGE CONTENTS

- Marathon CL030050P Digital Desk Clock
- User Manual (this document)
- Batteries (pre-installed or included separately)

## 3. SETUP

### 3.1 Battery Installation

The clock operates on batteries. If batteries are not pre-installed, open the battery compartment cover on the back of the clock and insert the required batteries, ensuring correct polarity (+/-). Close the cover securely.

### 3.2 Initial Settings (Time, Date, Language, Temperature Unit)

The back of the clock features several buttons for configuration:



Figure 2: Rear view of the clock with control buttons.

1. **Set Time and Date:** Press and hold the **MODE** button to enter time setting mode. Use the **UP (▲)** and **DOWN (▼)** buttons to adjust the flashing value (e.g., hour, minute, year, month, day). Press **MODE** again to confirm and move to the next setting.
2. **12/24 Hour Format:** While in time setting mode, press the **UP (▲)** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.
3. **Day of Week Language:** The day of the week can be displayed in 7 languages (English, Dutch, French, Spanish, Italian, Danish, German). This setting is typically adjusted within the date setting sequence. Use **UP (▲)** or **DOWN (▼)** to select your preferred language when the day of the week is flashing.
4. **Temperature Unit (C/F):** Press the **C/F** button on the back of the clock to switch between Celsius (°C) and Fahrenheit (°F) temperature display.

## 4. OPERATING INSTRUCTIONS

### 4.1 Display Modes

The clock continuously displays time, date, and temperature. The large, high-contrast display ensures readability.

### 4.2 Backlight Activation

The clock features a soft blue Nightglow Super Glow backlight. To activate the backlight, press any button on the

clock. The backlight will illuminate for a few seconds, providing temporary visibility in low-light conditions.

### 4.3 Alarm Setting

1. Press the **ALARM ( )** button once to view the current alarm time.
2. Press and hold the **ALARM ( )** button to enter alarm setting mode. The hour digit will flash.
3. Use the **UP (▲)** and **DOWN (▼)** buttons to adjust the hour. Press **ALARM ( )** to confirm and move to the minute setting.
4. Adjust the minute using the **UP (▲)** and **DOWN (▼)** buttons. Press **ALARM ( )** to confirm and exit alarm setting mode.
5. To activate/deactivate the alarm, press the **ALARM ( )** button briefly outside of setting mode. An alarm icon will appear/disappear on the display.

### 4.4 Snooze Function

When the alarm sounds, press any button (except **RESET**) to activate the snooze function. The alarm will temporarily stop and sound again after a few minutes (snooze duration is typically fixed and cannot be adjusted). To turn off the alarm completely, press the **RESET** button or let it ring for its full duration.



Figure 3: The clock is compact and fits comfortably in hand.

## 5. MAINTENANCE

---

### 5.1 Cleaning

Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the display or casing.

### 5.2 Battery Replacement

When the display becomes dim or the clock functions erratically, it is time to replace the batteries. Open the battery compartment on the back, remove the old batteries, and insert new ones, observing correct polarity. Dispose of old batteries responsibly.

## 6. TROUBLESHOOTING

---

- **Display is blank or dim:** Check battery installation. Replace batteries if necessary.
- **Incorrect time/date:** Re-enter time and date settings as described in Section 3.2.
- **Alarm not sounding:** Ensure the alarm is activated (alarm icon visible on display). Check alarm volume if adjustable (this model may not have adjustable volume).
- **Clock unresponsive:** Press the **RESET** button on the back of the clock using a pointed object (e.g., a paperclip). This will reset the clock to factory defaults, and you will need to set the time and date again.

## 7. SPECIFICATIONS

---

<b>Model</b>	CL030050P
<b>Brand</b>	Marathon
<b>Color</b>	French Blue
<b>Size</b>	Small
<b>Material</b>	Plastic
<b>Display Type</b>	Digital
<b>Features</b>	Alarm, Temperature Display
<b>Power Source</b>	Battery Powered
<b>Product Dimensions</b>	9.4 x 3.81 x 9.4 cm (3.7 x 1.5 x 3.7 inches)
<b>Item Weight</b>	0.1 Kilograms (100 g)
<b>Indoor/Outdoor Use</b>	Indoor

**3.7 inches  
9.4 cm**



**3.7 inches  
9.4 cm**

Figure 4: Product dimensions for the Marathon CL030050P Digital Desk Clock.

## 8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit

the official Marathon website. If you encounter any issues not covered in this manual, please contact customer service for assistance.