

[Manuals.plus](#) /

› [Icon Health & Fitness, Inc.](#) /

› Icon Health & Fitness Main Wire Harness 60" (Part 327254) Instruction Manual

Icon Health & Fitness, Inc. 327254

Icon Health & Fitness Main Wire Harness 60" (Part 327254) Instruction Manual

For Epic, FreeMotion, and Reebok Upright Bikes

1. PRODUCT OVERVIEW

This document provides essential information for the Icon Health & Fitness Main Wire Harness, Part Number 327254. This 60-inch wire harness is designed for specific fitness equipment models to ensure proper electrical connectivity.

- **Part Number:** 327254
- **Part Name:** WIRE,HRNS,60",WHITE HT SHRINK
- **Length:** 60 inches




Image 1.1: The 60-inch main wire harness (Part 327254) with red connectors, coiled for packaging.

1.1. Compatible Models

This wire harness is compatible with the following fitness equipment models:

- **Epic:** A17U - EPEX139122, A17U - EPEX139123, A17U - EPEX139124, A17U - EPEX139125
- **FreeMotion:** 250u Upright - SFEX040120, 250u Upright - SFEX040121, 250u Upright - SFEX040122, 250u Upright - SFEX040124, 350 U - SFEVEX807130
- **Hydra Fitness Exchange:** GX 4.2 Pro - NTEX050123, GX4.2 Pro - NTEX050120, GX4.2 Pro - NTEX050121, U100 - NTEVEX789130
- **Reebok (Icon):** 410 - RBEX049130

2. INSTALLATION AND SETUP

Replacing a wire harness requires careful attention to detail. It is recommended to consult your equipment's specific assembly manual or a qualified fitness technician if you are unsure about the installation process.

2.1. Identifying the Correct Part

Before installation, ensure you have the correct replacement part. Locate your equipment's model name and model number (for Icon products) or serial number (for other manufacturers). The first 2-5 characters of the serial number are often sufficient for identification.

2.2. General Installation Steps

1. **Safety First:** Always unplug the fitness equipment from the power source before beginning any repair or installation.
2. **Access the Wiring:** Carefully remove any covers or panels necessary to access the existing wire harness.
3. **Document Connections:** Take photos or make diagrams of how the old wire harness is connected before disconnecting it. Note the routing of the wires.
4. **Disconnect Old Harness:** Gently disconnect the old wire harness from all connection points.
5. **Install New Harness:** Route the new 327254 wire harness exactly as the old one was, ensuring no wires are pinched or strained. Connect all plugs securely.
6. **Secure Components:** Reattach any covers or panels removed earlier.
7. **Test Functionality:** Plug the equipment back in and test its functionality to ensure the new harness is working correctly.




Image 2.1: An exploded diagram of an upright exercise bike, indicating the general location of a wire harness (highlighted by the red arrow, item 81) within the frame. This diagram serves as a general reference for component placement.

3. OPERATING PRINCIPLES

The Main Wire Harness 327254 serves as the primary electrical conduit within your fitness equipment, transmitting power and data signals between various components such as the console, motor, sensors, and power supply. Its proper function is critical for the overall operation of the exercise bike.

Once correctly installed, the harness operates passively, facilitating the electrical communication required for the equipment to power on, display information, and respond to user input.

4. MAINTENANCE

Regular maintenance of the wire harness is not typically required, as it is an internal component. However, periodic inspection during other equipment maintenance can help identify potential issues.

- **Visual Inspection:** If accessible, visually inspect the harness for any signs of wear, fraying, cuts, or damage to the insulation.
- **Connection Integrity:** Ensure all connectors are firmly seated and free from corrosion.
- **Proper Routing:** Verify that the harness remains properly routed and is not pinched by moving parts or sharp edges.

If any damage is observed, the harness should be replaced to prevent electrical malfunctions or safety hazards.

5. TROUBLESHOOTING

Issues related to the wire harness often manifest as complete power failure, intermittent operation, or incorrect display readings. Before troubleshooting, always ensure the equipment is unplugged.

- **No Power:** If the equipment does not power on, check the main power cord, outlet, and then inspect the wire harness for any disconnections or visible damage.
- **Intermittent Functionality:** Loose connections within the harness or damaged wires can cause components to work sporadically. Carefully check all plug connections.
- **Incorrect Readings:** If the console displays incorrect speed, distance, or heart rate, the issue might be with a sensor connection or a specific wire within the harness.

If basic checks do not resolve the issue, it is advisable to consult a professional fitness equipment technician. Attempting complex electrical repairs without proper knowledge can be hazardous.

6. SPECIFICATIONS

Specification	Detail
Part Number	327254
Part Name	WIRE,HRNS,60",WHITE HT SHRINK
Brand	Icon Health & Fitness, Inc.
Item Weight	1 pounds
Product Dimensions	6 x 8 x 1 inches (packaged)
UPC	826736610524

7. SUPPORT AND ASSISTANCE

If you require further assistance with diagnosing issues or installing replacement parts, it is recommended to contact the seller or a certified fitness equipment technician. They can provide guidance or recommend a professional in your area.

For general inquiries or to locate a technician, you may refer to the [Hydra Fitness Exchange Store](#) on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07ND5DJM2>

More documents and user manuals: <https://manuals.plus/>