

## Baby Jogger 2083081

# Baby Jogger City Select Double Stroller User Manual

Model: 2083081

## INTRODUCTION

This manual provides essential information for the safe and effective use of your Baby Jogger City Select Double Stroller. Please read all instructions carefully before assembly and use. Keep this manual for future reference.

The Baby Jogger City Select Double Stroller is designed for versatility, converting from a single to a double stroller with ease. It offers multiple configurations to adapt to your family's needs.

## SAFETY INFORMATION

- Always use the 5-point harness system to secure your child.
- Ensure the stroller is fully open and locked before placing children in it.
- Always engage the parking brake when the stroller is stationary.
- Do not overload the storage basket; refer to the maximum weight recommendations.
- Do not hang bags on the handlebar as this can cause the stroller to tip.
- Never leave children unattended in the stroller.
- This stroller is designed for children up to 45 pounds per seat.

## SETUP AND ASSEMBLY

Your Baby Jogger City Select Double Stroller comes with the main frame, two seats, and removable adapters. Follow these steps for initial setup:

1. **Unfolding the Stroller Frame:** Release the folding latch and lift the handlebar until the frame locks into place. Ensure all locking mechanisms are engaged.
2. **Attaching the Wheels:** Insert the front and rear wheels into their respective slots until they click securely.
3. **Attaching the Seats:** Align the seat mounts with the frame's attachment points and push down until they click. The seats can be attached facing forward or backward.

4. **Attaching the Second Seat:** Use the included removable adapters to attach the second seat to the designated lower attachment points on the frame.



*Image: The Baby Jogger City Select Double Stroller fully assembled with two seats.*



*Image: Visual representation of various seating configurations possible with the City Select Double Stroller, including single and double setups.*

## OPERATING THE STROLLER

### Folding the Stroller

1. Remove any children and items from the stroller.
2. Ensure seats are in the correct position for folding (refer to specific seat instructions for optimal fold).
3. Locate the folding straps/handles and pull them upwards firmly until the stroller frame collapses.
4. Secure the auto-lock latch to keep the stroller folded.



*Image: The Baby Jogger City Select Double Stroller shown in its compact folded state, highlighting its portability.*

## Adjusting Seats and Handlebar

- **Seat Recline:** Use the recline lever on the back of each seat to adjust the recline angle.
- **Footrest:** Adjust the footrest position for child comfort.
- **Handlebar:** The telescoping handlebar can be adjusted to different heights for parent comfort. Locate the adjustment buttons on the sides of the handlebar.

## Brake System

The stroller features a hand-operated parking brake located near the handlebar. Push the lever down to engage the

brake and lift it up to release. Always ensure the brake is fully engaged when the stroller is stationary.

## MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safety of your stroller.

- **Fabric Care:** Machine wash seat fabrics in cold water with mild detergent on a delicate cycle and drip dry. *Do not use bleach, solvents, or abrasive cleaning materials. Do not press, iron, dry clean, or tumble dry.* Always remove the metal frame and PE boards from the seat before washing.
- **Frame and Plastic Parts:** Surface wash plastic and metal parts using warm water and mild soap; towel dry.
- **Wheels:** Clean wheels using a damp cloth and dry completely with a soft towel or cloth before use.
- **Storage:** Do not store outside or near a direct heat source such as a radiator or fire. Always store in a dry and safe environment.
- **Replacement Parts:** If the seat cover requires replacing, only use parts from a Baby Jogger authorized dealer.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller is difficult to fold.	Seats may not be in the optimal position for folding, or the folding mechanism might be stiff.	Ensure seats are adjusted to the most compact position. Apply light lubricant to moving parts if stiffness persists. Refer to folding instructions carefully.
Stroller feels heavy or hard to push.	Overloaded, uneven weight distribution, or debris in wheels.	Check weight limits. Distribute weight evenly. Clean wheels and axles of any debris. Ensure tires are properly inflated (if applicable, though these are rubber, not air-filled).
Wheels squeak or do not turn smoothly.	Dirt or lack of lubrication.	Clean wheels thoroughly. Apply a silicone-based lubricant to the wheel axles.
Harness is difficult to buckle/unbuckle.	Debris in buckle or misaligned components.	Inspect the buckle for any obstructions. Ensure all harness straps are correctly aligned.

## SPECIFICATIONS

Brand	Baby Jogger
-------	-------------

<b>Model Number</b>	2083081
<b>Color</b>	Jet
<b>Material</b>	Polyester (Fabric), Aluminum (Frame), Rubber (Tires)
<b>Item Weight</b>	28 Pounds
<b>Item Dimensions (L x W x H)</b>	38.5" L x 25.75" W x 43.5" H
<b>Folded Size</b>	38.5*25.75*43.5 Inches
<b>Maximum Weight Recommendation</b>	45 Pounds per seat
<b>Seating Capacity</b>	2
<b>Harness Type</b>	5 Point
<b>Included Components</b>	Second seat, removable adapters



*Image: Dimensions of the Baby Jogger City Select Double Stroller, including length, width, and height.*

## **WARRANTY AND SUPPORT**

For information regarding product warranty, please refer to the warranty documentation included with your purchase or visit the official Baby Jogger website. Protection plans are also available for extended coverage.

For customer support, replacement parts, or further assistance, please contact Baby Jogger customer service or visit their official brand store:

**[Visit the Baby Jogger Store on Amazon](#)**

© 2024 Baby Jogger. All rights reserved.