

Geepas GRC4330N

Geepas Electric Rice Cooker GRC4330N Instruction Manual

Model: GRC4330N | Capacity: 1.8 Liters | Power: 762W

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Geepas Electric Rice Cooker GRC4330N. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed for cooking rice, steaming food, and keeping food warm.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.
- Ensure the power supply matches the voltage specified on the appliance.

3. PRODUCT OVERVIEW

3.1 Components

Your Geepas Electric Rice Cooker GRC4330N includes the following components:

- Main Rice Cooker Unit (Stainless Steel Outer Body)
- Non-stick Inner Pot
- Steamer Basket (Plastic)
- Measuring Cup
- Serving Spoon
- Detachable Power Cord



Image: Front view of the Geepas Electric Rice Cooker GRC4330N, showing the stainless steel exterior and control panel.



Image: The Geepas Rice Cooker with its lid open, revealing the interior and the removable non-stick inner pot placed beside it.



Image: The included accessories: a steamer basket, a measuring cup, and a serving spoon.

3.2 Key Features

- **3-in-1 Functions:** Cook, Steam, and Keep Warm modes for versatile meal preparation.
- **1.8 Liter Capacity:** Suitable for cooking up to 4 servings of rice.
- **Non-stick Inner Pot:** Ensures easy food release and simplifies cleaning.
- **Stainless Steel Outer Body:** Durable and aesthetically pleasing design.
- **Automatic Keep Warm:** Switches to keep warm mode automatically after cooking.
- **Cool-touch Handles:** Designed for safe handling during and after operation.
- **Single Switch Operation:** Simple and intuitive control.

**GEEPAS®**

COOK, STEAM & KEEP WARM

This pot features three different functions namely cook, steam, and keep warm. It allows you to choose how you prepare your rice. After cooking, you can also keep your food warm using the 'Keep Warm' function.



Image: Graphic illustrating the three functions: Cook, Steam, and Keep Warm.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the inner pot, steamer basket, measuring cup, and serving spoon with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from water and direct heat sources. Ensure adequate ventilation around the appliance.
4. **Power Connection:** Connect the detachable power cord to the rice cooker, then plug it into a suitable electrical outlet (AC 220-240V, 50/60Hz).

5. OPERATING INSTRUCTIONS

5.1 Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. One cup of uncooked rice typically yields about 2-3 cups of cooked rice.
2. **Rinse Rice:** Rinse the rice in a separate bowl until the water runs clear. This helps remove excess starch.
3. **Add to Inner Pot:** Place the rinsed rice into the non-stick inner pot.
4. **Add Water:** Add the appropriate amount of water. A common ratio is 1 cup of rice to 1.5-2 cups of water, but this can vary based on rice type and desired consistency. Refer to the water level markings inside the inner pot for guidance.
5. **Place Inner Pot:** Ensure the exterior of the inner pot is dry, then place it into the main rice cooker unit. Rotate it slightly to ensure good contact with the heating element.
6. **Close Lid:** Close the lid securely.
7. **Start Cooking:** Plug in the rice cooker. Press the control lever down to the **"COOK"** position. The **"COOK"** indicator light will illuminate.

8. **Automatic Switch-off:** Once the rice is cooked, the cooker will automatically switch to the **"KEEP WARM"** mode, and the "WARM" indicator light will illuminate.
9. **Resting Period:** For best results, allow the rice to rest in the "KEEP WARM" mode for 10-15 minutes before serving. This allows the rice to fully absorb moisture and become fluffier.
10. **Serve:** Use the provided serving spoon to fluff and serve the rice.



Image: The Geepas Rice Cooker on a kitchen counter with a plate of cooked rice and a serving spoon, demonstrating its use.

5.2 Steaming Food

1. **Add Water:** Pour approximately 2-3 cups of water into the inner pot. Ensure the water level is below the steamer basket.
2. **Prepare Food:** Place the food to be steamed (e.g., vegetables, dumplings) into the steamer basket.
3. **Assemble:** Place the steamer basket into the inner pot, ensuring it sits securely above the water.
4. **Close Lid:** Close the lid securely.
5. **Start Steaming:** Plug in the rice cooker. Press the control lever down to the **"COOK"** position. The "COOK" indicator light will illuminate.
6. **Monitor:** Steaming times vary depending on the type and quantity of food. Monitor the food for desired doneness.

7. **Finish:** Once steaming is complete, switch the control lever to the "OFF" position or unplug the unit. Carefully open the lid, avoiding steam.



Image: The Geepas Rice Cooker with the lid open, showing vegetables like broccoli, potatoes, and carrots being steamed in the steamer basket.

5.3 Keep Warm Function

The "KEEP WARM" function activates automatically after the cooking cycle is complete. This function maintains the food at an optimal serving temperature without overcooking. The "WARM" indicator light will be illuminated when this function is active. Do not keep food in the "KEEP WARM" mode for extended periods (more than 4-6 hours) to maintain food quality and safety.



Image: Close-up view of the control panel on the Geepas Rice Cooker, showing the "WARM" and "COOK" indicator lights and the control lever.

6. CLEANING AND MAINTENANCE

1. **Unplug:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot and Accessories:** Remove the inner pot, steamer basket, measuring cup, and serving spoon. Wash them with warm, soapy water using a soft sponge or cloth. Rinse thoroughly and dry completely. Do not use abrasive cleaners or metal scouring pads, as these can damage the non-stick coating.
3. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. For stubborn stains, use a mild detergent. Ensure no water enters the electrical components. Never immerse the main unit in water or any other liquid.
4. **Lid:** Clean the inside of the lid with a damp cloth. Ensure the steam vent is clear of any food debris.
5. **Storage:** Once all parts are clean and dry, reassemble the rice cooker or store the components separately in a dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------





Problem	Possible Cause	Solution
Rice is too hard/undercooked	Insufficient water; lid not properly closed; power interruption.	Add more water next time; ensure lid is sealed; check power connection.
Rice is too soft/mushy	Too much water; rice not rinsed properly.	Reduce water next time; rinse rice thoroughly before cooking.
Rice sticks to the bottom	Not enough water; inner pot not properly seated; non-stick coating damaged.	Ensure correct water ratio; rotate inner pot to seat properly; avoid using metal utensils.
Cooker does not turn on	Not plugged in; power outlet malfunction; damaged power cord.	Check power cord connection; test outlet with another appliance; contact customer support if cord is damaged.
Steam escaping from lid edges	Lid not properly closed; lid seal damaged.	Ensure lid is securely closed; inspect lid seal for damage.

8. SPECIFICATIONS

Brand	Geepas
Model Number	GRC4330N (also listed as RIV001)
Capacity	1.8 Liters
Power / Wattage	762 Watts
Voltage	AC 220-240V
Frequency	50/60 Hz
Material	Stainless Steel (Outer Body), Non-stick (Inner Pot)
Color	Silver/Black
Dimensions (LxBxH)	29.4 x 26.8 x 28.8 cm
Item Weight	2.45 Kilograms
Special Features	Automatic Keep Warm, Auto Shutoff

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or contact Geepas customer service directly. Keep your purchase receipt as proof of purchase.

 <p>1.5 LITRE ESPRESSO COFFEE MACHINE WITH MILK</p>	<p>Geepas 1.5 Litre Espresso Coffee Machine with Milk - User Manual</p> <p>Instruction manual and user guide for the Geepas 1.5 Litre Espresso Coffee Machine with Milk (Model No. GCM41521UK), covering safety guidelines, product overview, operation, cleaning, and warranty.</p>
	<p>Geepas GK38050 Electric Turkish Coffee Maker User Manual</p> <p>Comprehensive user manual for the Geepas GK38050 Electric Turkish Coffee Maker, including safety guidelines, operating instructions, care tips, and troubleshooting.</p>
	<p>PPDA: Common User Items and Average Prices List FY 2019/20</p> <p>Public Procurement and Disposal of Public Assets Authority (PPDA) report detailing common user items and their average prices for the Financial Year 2019/20. A guide for public entities to benchmark prices and ensure value for money.</p>
	<p>عروض أنصار جاليري: أقل من سعر التكلفة من 15 إلى 24 سبتمبر 2024</p> <p>اكتشف عروض "أقل من سعر التكلفة" من أنصار جاليري، التي تشمل مجموعة واسعة من المنتجات من 15 إلى 24 سبتمبر 2024. تسوق الإلكترونيات، الأجهزة المنزلية، البقالة، الملابس، وغيرها بأسعار مميزة.</p>