

## Emjoi UEFP-355

# Emjoi 22-Function Food Processor and Blender

Models: UEFP-355 / UECM-351

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Emjoi 22-Function Food Processor and Blender. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed to simplify various food preparation tasks, offering versatility with its multiple functions and attachments.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions before operating the appliance.
2. Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
3. Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
4. Avoid contact with moving parts. Keep hands and utensils away from blades during operation to prevent injury.
5. Ensure the safety lock mechanism is engaged before operating the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
7. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
8. Do not use outdoors.
9. Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
10. This appliance is for household use only.

## PRODUCT OVERVIEW AND COMPONENTS

Your Emjoi Food Processor and Blender system includes a powerful motor base and various attachments for diverse kitchen tasks. Familiarize yourself with the main components:

- **Motor Base:** The main unit housing the 600W motor and control dial.
- **Food Processor Bowl:** Large capacity bowl for chopping, slicing, shredding, and kneading.
- **Blender Jug:** For blending liquids, making smoothies, and purees.
- **Small Chopper/Grinder:** Ideal for smaller quantities, grinding coffee beans, or making dressings.
- **Citrus Juicer Attachment:** For extracting juice from citrus fruits.
- **Blades and Discs:** Various blades for chopping, kneading, and discs for slicing, shredding, and grating.
- **Lid:** With a feeding chute for adding ingredients during operation.



Figure 1: Emjoi Food Processor and Blender with various attachments, including the main unit, blender jug, food processor bowl, and multiple blades/discs.



## Assembling the Blender

1. Ensure the blender blade assembly is securely attached to the bottom of the blender jug.
2. Place the blender jug onto the motor base, aligning the tabs and rotating clockwise until it locks into place.
3. Secure the blender lid onto the jug.

## Assembling the Small Chopper/Grinder

1. Place the small chopper blade into the small chopper bowl.
2. Add ingredients to the bowl.
3. Attach the small chopper lid/motor unit onto the bowl, ensuring it is securely locked.
4. Place the assembled small chopper onto the motor base, aligning and locking it.

## Assembling the Citrus Juicer

1. Place the juicer bowl onto the motor base.
2. Place the sieve and reamer onto the juicer bowl.

---

## OPERATING INSTRUCTIONS

Always ensure the appliance is correctly assembled and locked before plugging it in and operating.

### Control Dial

The appliance features a control dial with multiple speed settings and a pulse function:

- **'0' (Off):** The appliance is off.
- **'1' (Low Speed):** Suitable for lighter tasks like mixing and gentle blending.
- **'2' (High Speed):** For heavier tasks such as chopping hard vegetables, blending thick mixtures, or kneading dough.
- **'P' (Pulse):** Provides short bursts of maximum power. Hold the dial in the 'P' position for desired duration, then release. Ideal for controlled chopping, grinding, or quick blending.

### Using the Food Processor

1. Assemble the food processor with the appropriate blade or disc.
2. Add ingredients to the bowl. For slicing/shredding discs, use the feeding chute and pusher.
3. Select the desired speed (1 or 2) or use the pulse function (P).
4. Process until desired consistency is achieved.
5. Turn the dial to '0' and unplug before disassembling and removing processed food.

### Using the Blender

1. Assemble the blender jug onto the motor base.
2. Add liquids and ingredients to the jug. Do not exceed the maximum fill line.

3. Select the desired speed (1 or 2) or use the pulse function (P).
4. Blend until smooth.
5. Turn the dial to '0' and unplug before pouring.

## Using the Small Chopper/Grinder

1. Assemble the small chopper with its blade.
2. Add small quantities of ingredients, such as herbs, nuts, or coffee beans.
3. Place the assembled chopper onto the motor base.
4. Use the pulse function (P) for controlled grinding or chopping.
5. Turn the dial to '0' and unplug before disassembling.

## Using the Citrus Juicer

1. Assemble the citrus juicer attachment onto the motor base.
2. Cut citrus fruits in half.
3. Place a fruit half onto the reamer and press down gently. The motor will activate.
4. Continue until all juice is extracted.
5. Turn the dial to '0' and unplug before disassembling.

---

## CLEANING AND MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

- Always unplug the appliance before cleaning.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse it in water or any other liquid.
- **Removable Parts:** All bowls, blades, lids, and attachments are dishwasher safe. Alternatively, wash them in warm, soapy water, rinse thoroughly, and dry immediately.
- **Blades:** Handle blades with extreme care as they are very sharp. Use a brush for cleaning if necessary.
- Store the appliance and its attachments in a dry place.

---

## TROUBLESHOOTING

If you encounter issues with your Emjoi Food Processor and Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; safety lock not engaged; power outage.	Ensure the appliance is plugged in. Check that the bowl/jug and lid are correctly assembled and locked. Check power supply.

Problem	Possible Cause	Solution
Motor stops during operation.	Overload; motor overheating.	Unplug the appliance. Remove some ingredients. Let the motor cool down for 15-20 minutes before restarting.
Ingredients not processing evenly.	Too many ingredients; insufficient liquid (for blending); incorrect speed.	Process in smaller batches. Add more liquid if blending. Use the pulse function for better control.
Loud noise or vibration.	Improper assembly; unstable surface.	Ensure all parts are correctly assembled and locked. Place the appliance on a stable, flat surface.

If the problem persists after trying these solutions, please contact customer support.

## SPECIFICATIONS

- **Model Numbers:** UEFP-355 / UECM-351
- **Power Consumption:** 600 Watts
- **Voltage:** (Typically 220-240V for Saudi Arabia, but not specified in data)
- **Material:** Plastic
- **Blender Jug Capacity:** Up to 1.75 Liters
- **Food Processor Bowl Capacity:** (Not explicitly stated, but implied large capacity)
- **Attachments:** 22 functions/attachments (including various blades, discs, juicer, small chopper)
- **Control:** Variable speed settings (1, 2) and Pulse function (P)
- **Safety Feature:** Safety lock mechanism
- **Care Instructions:** Dishwasher safe parts (bowls, blades, attachments)
- **Dimensions (Shipping):** 40.4 x 38.8 x 22.6 cm
- **Item Weight:** 4.02 kg

## WARRANTY AND SUPPORT

For warranty information, service, or technical support, please refer to the warranty card included with your product or contact Emjoi customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

**Customer Service Contact:** Refer to your product packaging or the official Emjoi website for the most current contact information.