

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Karlsson](#) /

> [Karlsson KA5753WH LCD Backlit Digital Alarm Clock User Manual](#)

Karlsson KA5753WH

Karlsson KA5753WH LCD Backlit Digital Alarm Clock User Manual

Model: KA5753WH

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Karlsson KA5753WH LCD Backlit Digital Alarm Clock. Please read this manual thoroughly before using the device to ensure proper function and longevity.

SAFETY INFORMATION

- Use only the specified battery type (3 x AAA batteries).
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the clock will not be used for an extended period to prevent leakage.
- Keep the device away from water and high humidity.
- Avoid exposing the clock to extreme temperatures or direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Contact qualified personnel for service.

PRODUCT OVERVIEW

The Karlsson KA5753WH is a compact digital alarm clock featuring an LCD display with backlighting and a rubberized ABS finish. It includes an alarm function and a snooze/light button for convenience.



Figure 1: Front view of the alarm clock, displaying the time and the 'SNOOZE-LIGHT' button on top.



Figure 2: Back view of the alarm clock, showing the battery compartment cover and the 'TIME SET' button.

Controls and Features:

- **LCD Display:** Shows the current time and alarm status.
- **SNOOZE-LIGHT Button:** Located on top, activates snooze function when alarm sounds, or illuminates the display briefly.
- **H Button:** Hour setting button.

- **M Button:** Minute setting button.
- **TIME SET Button:** Located on the back, used to enter time setting mode.
- **Battery Compartment:** Located on the back, requires 3 x AAA batteries.

SETUP

1. Battery Installation

1. Locate the battery compartment cover on the back of the alarm clock (refer to Figure 2).
2. Slide or gently pry open the cover.
3. Insert 3 new AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover securely.

Note: The clock requires 3 x AAA batteries, which are not included.

2. Initial Time Setting

1. After installing batteries, the display may show a default time or flash.
2. Press and hold the **TIME SET** button on the back of the clock until the hour digits begin to flash.
3. Press the **H** button (Hour) on the top of the clock to adjust the hour. Press repeatedly to advance the hour.
4. Press the **M** button (Minute) on the top of the clock to adjust the minute. Press repeatedly to advance the minute.
5. Once the desired time is set, press the **TIME SET** button again to confirm and exit the time setting mode.

OPERATING INSTRUCTIONS

Setting the Alarm

1. Press the **TIME SET** button once to enter time setting mode.
2. Press the **TIME SET** button a second time to enter alarm setting mode. The alarm time digits will begin to flash.
3. Press the **H** button to adjust the alarm hour.
4. Press the **M** button to adjust the alarm minute.
5. Press the **TIME SET** button a third time to confirm the alarm time and exit alarm setting mode.
6. Ensure the alarm is activated. A small icon (e.g., a bell) on the display typically indicates the alarm is active.

Using the Snooze/Light Function

- **To activate backlight:** Press the large **SNOOZE-LIGHT** button on the top of the clock. The display will illuminate for a few seconds.
- **To snooze the alarm:** When the alarm sounds, press the **SNOOZE-LIGHT** button. The alarm will temporarily stop and sound again after a few minutes (typically 5-10 minutes).
- **To turn off the alarm:** To completely turn off the alarm for the day, press any other button (e.g., H or M) or the dedicated alarm ON/OFF switch if available. The alarm will reset for the next day.

MAINTENANCE

Cleaning

- Wipe the clock with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the rubberized finish or the LCD display.

Battery Replacement

- When the display dims or the clock functions become erratic, it is time to replace the batteries.
- Follow the battery installation steps outlined in the "Setup" section.
- Always replace all 3 AAA batteries at the same time with new ones.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Batteries are low or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure the alarm time is set and the alarm function is turned ON. Check battery level.
Time is incorrect.	Time was not set correctly or batteries were removed.	Reset the current time following the "Initial Time Setting" instructions.
Snooze/Light button not working.	Low batteries or button malfunction.	Replace batteries. If the issue persists, contact customer support.

SPECIFICATIONS

- **Model:** KA5753WH (PTG-KA5753WH)
- **Brand:** Karlsson
- **Display Type:** Digital LCD, Backlit
- **Material:** Rubberized ABS, Silicone
- **Color:** White
- **Dimensions (L x H x D):** 14 cm x 7 cm x 5 cm (approximately 5.51 x 2.76 x 1.97 inches)
- **Power Source:** 3 x AAA batteries (not included)
- **Special Features:** Alarm function, Snooze/Light button
- **Item Weight:** Approximately 2.11 ounces (60 grams)

WARRANTY AND SUPPORT

Specific warranty information for the Karlsson KA5753WH LCD Backlit Digital Alarm Clock is not provided in this manual. Please refer to the product packaging or the retailer's website for warranty details. For technical support or further assistance, please contact Karlsson customer service through their official website or the point of purchase.



