

WINGONEER 41961

WINGONEER TA2024 Digital Amplifier Board Instruction Manual

Model: 41961 (TA2024)

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your WINGONEER TA2024 Digital Amplifier Board. Please read this manual thoroughly before use to ensure optimal performance and safety.

The WINGONEER TA2024 Digital Amplifier Board is designed to provide audio amplification. It features a wide operating voltage range and configurable gain settings, making it suitable for various audio projects. Note that this board functions as a component and requires additional accessories for a complete audio system.




Figure 1: Top view of the WINGONEER TA2024 Digital Amplifier Board. This image displays the main components, including the TA2024 chip, capacitors, input/output terminals, and the volume control potentiometer.

2. PACKAGE CONTENTS

- 1 x WINGONEER 20W Digital Amplifier Board (Model: 41961)

Note: Additional components such as a power supply, speakers, audio source, and wiring are required for operation and are not included.

3. SETUP INSTRUCTIONS

Follow these steps to set up your digital amplifier board:

1. **Power Supply Connection:** Connect a DC power supply within the 9-14V range to the designated power input terminals on the board. Ensure correct polarity (+ and -). An appropriate power supply is crucial for stable operation.
2. **Audio Input Connection:** Connect your audio source (e.g., smartphone, MP3 player, pre-amplifier) to the audio input terminals or jack. The board supports standard audio input.
3. **Speaker Output Connection:** Connect your speakers to the speaker output terminals. This board is designed for 4-ohm speakers with an output of up to 20W per channel. Ensure speaker impedance matches the board's requirements to prevent damage.
4. **Gain Mode Configuration:** The board features 4-group gain mode settings. Refer to the board's markings or specific documentation for jumper or switch configurations to adjust the gain according to your audio source and desired output level.




Figure 2: Angled view of the amplifier board, highlighting the audio input jack and speaker output terminals for connection.

4. OPERATING INSTRUCTIONS

Once all connections are securely made:

1. **Power On:** Apply power to the board. Ensure the volume potentiometer is set to a low level before powering on.
2. **Adjust Volume:** Slowly turn the volume potentiometer clockwise to increase the audio output to your desired level.
3. **Audio Playback:** Begin playing audio from your connected source.
4. **Power Off:** To power off, first reduce the volume, then disconnect the power supply.




Figure 3: Close-up of the board, showing the potentiometer used for adjusting the output volume.

5. MAINTENANCE

To ensure the longevity and proper functioning of your amplifier board:

- Keep the board in a dry environment, away from moisture and extreme temperatures.
- Avoid exposing the board to direct sunlight or excessive dust.
- Clean the board gently with a soft, dry cloth. Do not use liquid cleaners or solvents.
- Handle the board by its edges to avoid touching components, which can cause damage from static electricity.



Figure 4: Bottom view of the amplifier board, illustrating the solder points and circuit traces. Proper handling is essential to prevent damage to these components.

6. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound output	<ul style="list-style-type: none"> Incorrect power connection Audio source not playing or improperly connected Speakers not connected or faulty Volume too low 	<ul style="list-style-type: none"> Verify power supply (9-14V DC) and polarity. Check audio input cables and ensure the source is active. Confirm speaker connections and test speakers with another device. Increase volume using the potentiometer.
Distorted sound	<ul style="list-style-type: none"> Input signal too strong (clipping) Speaker impedance mismatch Faulty wiring or components Power supply issues 	<ul style="list-style-type: none"> Reduce the volume from the audio source or adjust gain settings on the board. Ensure speakers are 4-ohm. Inspect all wiring for damage or loose connections. Verify the power supply is stable and within the specified voltage range.

Problem	Possible Cause	Solution
Board not powering on	<ul style="list-style-type: none"> No power supply Incorrect power supply voltage or polarity Faulty power supply 	<ul style="list-style-type: none"> Connect a compatible 9-14V DC power supply. Double-check voltage and polarity. Test the power supply with another device if possible.

7. SPECIFICATIONS

Feature	Detail
Brand	WINGONEER
Model Number	41961
Amplifier Chip	TA2024
Input Voltage	DC 9-14V
Output Power	20W (into 4 ohms)
Gain Modes	4-group configurable
Dimensions (approx.)	8.7 x 4.9 x 1.4 cm
UPC/GTIN	723466661713

8. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For warranty claims or technical support, please contact your retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase.