

[Manuals.plus](#) /

› [i-Life](#) /

› i-Life ZED AIR 2 Laptop User Manual, Model IL.1406.332BC

i-Life IL.1406.332BC

i-Life ZED AIR 2 Laptop User Manual

Model: IL.1406.332BC

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your i-Life ZED AIR 2 Laptop, model IL.1406.332BC. Please read this manual thoroughly before operating your device and retain it for future reference.

2. PRODUCT OVERVIEW

2.1 Package Contents

- i-Life ZED AIR 2 Laptop
- Power Adapter
- User Manual (this document)

2.2 Laptop Components

Familiarize yourself with the key components of your i-Life ZED AIR 2 Laptop.



Figure 1: Top-down view of the i-Life ZED AIR 2 Laptop, showing the keyboard, trackpad, and screen with Windows 10 interface.



Figure 2: Close-up of the i-Life ZED AIR 2 Laptop screen, illustrating the Windows 10 Start menu and a prominent battery charging indicator.



Figure 3: The i-Life ZED AIR 2 Laptop in a closed position, showcasing its sleek design.

2.3 Ports and Connectors

The i-Life ZED AIR 2 Laptop includes various ports for connectivity. These typically include USB ports, an audio jack, and a power input. Refer to the physical device for exact port locations.

3. SETUP

3.1 Initial Charging

1. Connect the power adapter to the laptop's charging port.
2. Plug the power adapter into a wall outlet.
3. Allow the laptop to charge for at least 30 minutes before initial use, or until the battery indicator shows sufficient charge.

3.2 First Power On and Windows Setup

1. Press and hold the power button until the screen illuminates.
2. Follow the on-screen instructions to complete the Windows 10 initial setup, including language selection, network connection, and user account creation.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Press the power button.
- **Shut Down:** Click the Start button, then Power, then Shut down.
- **Restart:** Click the Start button, then Power, then Restart.
- **Sleep:** Click the Start button, then Power, then Sleep, or close the laptop lid.

4.2 Using the Keyboard and Touchpad

The laptop features a standard QWERTY keyboard and a multi-touch touchpad.

- **Keyboard:** Standard typing input. Function keys (F1-F12) often have secondary functions accessed with the **Fn** key.
- **Touchpad:**
 - **Single Tap:** Left-click.
 - **Two-Finger Tap:** Right-click.
 - **Two-Finger Scroll:** Scroll up or down.
 - **Pinch-to-Zoom:** Zoom in or out.

4.3 Connecting to Wi-Fi

1. Click the Wi-Fi icon in the system tray (bottom right of the screen).
2. Select your desired network from the list.
3. Click **Connect** and enter the network password if prompted.

4.4 Using External Devices

Connect USB devices (e.g., mouse, external hard drive) to the available USB ports. The laptop will typically install necessary drivers automatically.

5. MAINTENANCE

5.1 Cleaning the Laptop

- Use a soft, lint-free cloth to clean the screen and exterior.
- For stubborn marks, slightly dampen the cloth with water or a screen-safe cleaner.
- Avoid harsh chemicals, abrasives, or spraying liquids directly onto the laptop.

5.2 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods.
- Use only the original i-Life power adapter.

5.3 Software Updates

Regularly check for and install Windows updates to ensure optimal performance and security.

1. Go to **Settings > Update & Security > Windows Update**.
2. Click **Check for updates**.

6. TROUBLESHOOTING

6.1 Laptop Does Not Power On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Verify the power outlet is functional by plugging in another device.
- Try holding the power button for 10-15 seconds to perform a hard reset.

6.2 No Wi-Fi Connection

- Check if Wi-Fi is enabled in Windows settings.
- Restart your router and modem.
- Ensure you are entering the correct Wi-Fi password.
- Update or reinstall Wi-Fi drivers via Device Manager.

6.3 Slow Performance

- Close unnecessary applications running in the background.
- Run a disk cleanup and defragmentation (for HDD, not SSD).
- Check for malware or viruses.
- Ensure Windows is up to date.

7. SPECIFICATIONS

Feature	Detail
Brand	i-Life
Model Number	IL.1406.332BC
Form Factor	Laptop
Screen Size	14 Inches
Screen Resolution	1366 x 768 pixels

Feature	Detail
Processor Brand	Intel
Processor Type	Celeron
Processor Speed	1.6 GHz
Processor Count	2
RAM Size	3 GB
Memory Technology	DDR3
Hard Drive Size	32 GB
Hard Disk Type	Solid State Drive (SSD)
Graphics Chipset Brand	Intel
Wireless Type	2.4 GHz Radio Frequency, 802.11ab, 802.11b, Bluetooth
Operating System	Windows
Average Battery Life	8 Hours
Item Weight	2.28 Kilograms
Color	Silver
Connectivity Technology	USB

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official i-Life website. Keep your proof of purchase for warranty claims.

Manufacturer: I-Life

© 2023 i-Life. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question