

## Philips HD9241/44

# Philips Kitchen HD9241/44 Avance XL Digital Airfryer User Manual

Model: HD9241/44

## 1. INTRODUCTION

This user manual provides essential information for the safe and effective operation of your Philips Kitchen HD9241/44 Avance XL Digital Airfryer. This appliance utilizes Rapid Air Technology to fry, grill, roast, and bake food with little to no oil, offering a versatile cooking solution. Please read this manual thoroughly before first use and retain it for future reference.

## 2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Avoid placing the appliance against a wall or other appliances. Leave at least 10 cm (4 inches) free space on the back and sides and 10 cm (4 inches) free space above the appliance.
- Hot steam is released through the air outlet openings during air frying. Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- The outer surfaces may become hot during use.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Philips Avance XL Digital Airfryer.



**Image 1:** The Philips Avance XL Digital Airfryer shown on a kitchen counter with various cooked dishes, demonstrating its versatility. The digital display is visible, showing temperature settings.

#### Main Parts:

1. **Digital Touchscreen Interface:** For setting temperature, time, and selecting cooking modes.
2. **Air Inlet:** Located at the top of the appliance.
3. **Air Outlet Openings:** Located at the back of the appliance.
4. **Removable Nonstick Drawer:** Holds the food basket.
5. **Food Basket:** Where food is placed for cooking. Features a non-stick coating.
6. **Power Cord:** For connecting to an electrical outlet.
7. **Patented Starfish Design:** Located at the bottom of the appliance for optimal air circulation.

### 4. BEFORE FIRST USE

---

1. **Unpack:** Remove all packaging materials from the appliance.
2. **Clean:** Wash the food basket and the removable nonstick drawer in hot water with some dishwashing liquid

and a non-abrasive sponge. You can also clean these parts in a dishwasher. Wipe the inside and outside of the appliance with a moist cloth.

3. **Placement:** Place the appliance on a stable, horizontal, and level surface. Ensure there is at least 10 cm (4 inches) of free space around the appliance for proper ventilation.

## 5. OPERATING INSTRUCTIONS

---

### General Operation:

1. **Plug In:** Insert the main plug into a grounded wall outlet.
2. **Prepare Food:** Place the ingredients into the food basket. Do not fill the basket beyond the MAX indication.
3. **Insert Drawer:** Slide the drawer with the food basket back into the Airfryer.
4. **Power On:** Press the power button on the digital touchscreen.
5. **Set Temperature and Time:** Use the temperature and time control buttons to set the desired cooking temperature and time. Refer to the cooking guide in the recipe booklet for recommended settings.
6. **Start Cooking:** Press the start/pause button to begin the cooking process.
7. **Shake Basket (Optional):** For some recipes, you may need to shake the basket halfway through the cooking time to ensure even cooking. Pull out the drawer, shake the basket, and then slide the drawer back in. The appliance will resume cooking automatically.
8. **Check Doneness:** When the cooking time has elapsed, the appliance will beep. Pull out the drawer and carefully check if the food is cooked to your preference.
9. **Serve:** Empty the food from the basket into a bowl or onto a plate.
10. **Power Off:** Press the power button to turn off the appliance. Unplug it from the wall outlet.

### Digital Touchscreen Functions:

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts cooking temperature (e.g., 180°C - 200°C / 350°F - 400°F).
- **Time Control:** Adjusts cooking time (e.g., 1-60 minutes).
- **Start/Pause Button:** Starts or pauses the cooking cycle.
- **Preset Programs:** The appliance may feature preset programs for common dishes. Refer to the display icons for specific functions.

## 6. COOKING TIPS

---

- **Oil Usage:** For crispier results, lightly brush or spray a small amount of oil (a tablespoon or less) onto fresh ingredients.
- **Capacity:** The 2.65lb/3.5Qt cooking capacity is suitable for meals for up to 4 people. Do not overload the basket to ensure even cooking.
- **Even Cooking:** The patented starfish design promotes optimal air circulation. Shaking the basket for smaller items like fries or nuggets helps ensure all sides are evenly cooked and crispy.
- **Versatility:** Beyond frying, use your Airfryer to grill vegetables, roast meats, or bake desserts.
- **Preheating:** While not always necessary, preheating the Airfryer for 3-5 minutes at the desired temperature can improve cooking results for some foods.

## 7. CLEANING AND MAINTENANCE

---

Clean the appliance after every use.

1. **Unplug and Cool:** Always unplug the Airfryer and allow it to cool down completely before cleaning.
2. **Clean Drawer and Basket:** The removable nonstick drawer and food basket are dishwasher safe. Alternatively, wash them in hot water with dish soap and a non-abrasive sponge. For stubborn food residue, soak the basket and drawer in hot water for about 10 minutes.
3. **Clean Interior:** Wipe the inside of the appliance with a hot water and non-abrasive sponge.
4. **Clean Exterior:** Wipe the outside of the appliance with a moist cloth. Do not use abrasive cleaning agents.
5. **Heating Element:** Clean the heating element with a cleaning brush to remove any food residues.

## 8. STORAGE

Unplug the appliance and let it cool down completely. Ensure all parts are clean and dry before storing. Store the Airfryer in a dry, safe place, preferably in its original packaging or a covered area to protect it from dust.

## 9. TROUBLESHOOTING

| Problem                                 | Possible Cause                                                                                                                | Solution                                                                                                                                                             |
|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The Airfryer does not work.             | The appliance is not plugged in.                                                                                              | Make sure the main plug is properly inserted into a grounded wall outlet.                                                                                            |
| Food is not cooked evenly.              | The basket is overloaded. / Food items are stacked.                                                                           | Reduce the amount of food in the basket. Shake the basket halfway through cooking.                                                                                   |
| White smoke comes out of the appliance. | Fat from fatty ingredients is dripping into the drawer. / The basket or drawer contains grease residues from previous use.    | Clean the drawer and basket thoroughly after each use. For very fatty foods, you may place a piece of aluminum foil at the bottom of the drawer to catch excess fat. |
| Fresh fries are not crispy.             | You did not use the right potato type. / You did not rinse the potato sticks properly before frying. / Too much oil was used. | Use fresh potatoes suitable for frying. Rinse potato sticks thoroughly to remove starch. Add only a small amount of oil (1/2 tablespoon) for crispiness.             |

## 10. SPECIFICATIONS

- **Model Number:** HD9241/44
- **Capacity:** 1.2 Liters (Basket), 2.65lb/3.5Qt (Cooking)
- **Wattage:** 2100 Watts
- **Voltage:** 110 Volts (AC)
- **Control Method:** Touch Control
- **Material:** Plastic (Exterior), Non-stick coated metal (Inner)
- **Item Weight:** 15.4 Pounds
- **Special Features:** Programmable, Rapid Air Technology

- **Dishwasher Safe Parts:** Removable nonstick drawer and food basket

## 11. WARRANTY AND SUPPORT

---

For detailed warranty information or if you require support, please refer to the warranty card included with your purchase or visit the official Philips website. Do not attempt to repair the appliance yourself, as this will void the warranty.

**Philips Customer Service:** For assistance, please contact Philips customer support through their official channels.