

Bergner BG-51186-CP

Bergner COPPERLY 1800W 6.9L Air Fryer User Manual

Model: BG-51186-CP

INTRODUCTION

Thank you for purchasing the Bergner COPPERLY 1800W 6.9L Air Fryer. This appliance is designed to cook your favorite foods with little to no oil, providing a healthier alternative to traditional frying. Please read this manual thoroughly before use to ensure safe and optimal operation. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- This appliance is for household use only.

PRODUCT OVERVIEW

The Bergner COPPERLY Air Fryer is designed for efficient and healthy cooking. Familiarize yourself with its components:



Image: The Bergner COPPERLY Air Fryer, showcasing its sleek black and copper design with the cooking basket partially open, revealing crispy fries.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch controls for programs, temperature, and timer.
- **Frying Basket:** The main cooking compartment with a handle.
- **Roasting Rack/Grid:** Removable insert for the frying basket, featuring Ceratech non-stick coating.
- **Air Outlet Vent:** Located at the back of the unit.
- **Power Cord:** For connecting to an electrical outlet.



Image: A detailed view of the air fryer's interior, showing the removable basket and the Ceratech-coated roasting rack, designed for easy cleaning and non-stick performance.

SETUP

1. Unpacking

1. Remove all packaging materials from the air fryer.

2. Check that all components are present and undamaged.

2. Initial Cleaning

1. Wipe the exterior of the appliance with a damp cloth.
2. Clean the frying basket and roasting rack with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher safe.
3. Rinse thoroughly and dry all parts before use.

3. Placement

1. Place the air fryer on a stable, heat-resistant surface.
2. Ensure there is at least 10 cm (4 inches) of free space on the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
3. Do not place the appliance against a wall or other appliances.

OPERATING INSTRUCTIONS

Control Panel Overview



Image: The digital control panel of the air fryer, featuring touch icons for various cooking programs, temperature adjustment, and timer settings.

The digital control panel allows you to easily select cooking programs, adjust temperature, and set the timer. The display shows the current temperature and remaining time.

Basic Operation

1. Plug the air fryer into a grounded wall outlet.
2. Carefully pull the frying basket out of the air fryer.
3. Place the roasting rack inside the basket.
4. Place the ingredients into the frying basket. Do not exceed the MAX fill line.
5. Slide the frying basket back into the air fryer. Ensure it clicks into place.
6. Press the Power button to turn on the appliance.

Using Predefined Programs (8 Intuitive Programs)

The air fryer comes with 8 intuitive predefined programs for common dishes:

1. After turning on the appliance, press the 'M' (Mode) button repeatedly to cycle through the 8 predefined programs. Each program has a specific icon (e.g., fries, chicken, fish).
2. Once you select the desired program, the display will show the default temperature and time for that program.
3. Press the Start/Pause button to begin cooking.

Manual Temperature and Time Adjustment

For custom cooking, you can manually set the temperature and time:

1. After turning on the appliance, use the temperature control buttons (+ / -) to set the desired temperature between 80°C and 200°C.
2. Use the timer control buttons (+ / -) to set the desired cooking time, up to 30 minutes.
3. Press the Start/Pause button to begin cooking.

Shaking Ingredients

Some recipes require shaking the ingredients halfway through the cooking time to ensure even cooking and crispiness.

1. Carefully pull the frying basket out of the appliance by the handle. The air fryer will automatically pause.
2. Gently shake the basket.
3. Slide the frying basket back into the air fryer. The cooking will resume automatically.

End of Cooking

When the set cooking time has elapsed, the air fryer will beep, indicating that cooking is complete.

1. Carefully pull the frying basket out of the appliance.
2. Empty the contents into a serving dish. Use tongs to remove larger items.
3. Unplug the appliance from the wall outlet and allow it to cool down before cleaning.

CLEANING AND MAINTENANCE

Clean the air fryer after every use.

1. Cleaning the Basket and Roasting Rack

1. Allow the basket and roasting rack to cool completely.
2. Wash them in hot water with dish soap and a non-abrasive sponge. The Ceratech non-stick coating makes cleaning easy.
3. For stubborn food residue, soak the basket and rack in hot water with some dish soap for about 10 minutes.
4. Alternatively, the basket and roasting rack are dishwasher safe.

2. Cleaning the Exterior

1. Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.
2. Clean the heating element inside the appliance with a cleaning brush to remove any food residue.

3. Storage

Ensure the appliance is clean and dry before storing. Store it in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Too much food in the basket; food not shaken.	Cook in smaller batches; shake the basket halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and heating element thoroughly; remove excess fat from ingredients.
Fries are not crispy.	Not enough oil; wrong potato type; too much moisture.	Use fresh potatoes and pat them dry; add a little oil; cook in smaller batches.

TECHNICAL SPECIFICATIONS

Model Number	BG-51186-CP
Brand	Bergner
Capacity	6.9 Liters
Power	1800 Watts
Voltage	230 Volts (AC)
Temperature Range	80°C - 200°C
Timer	Up to 30 minutes
Material	Stainless Steel, Plastic
Dimensions (L x W x H)	36 x 40 x 36 cm
Special Features	8 cooking programs, adjustable temperature control, dirt repellent (Ceratech coating)

WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please refer to the warranty card included with your product or visit the official Bergner website. Keep your purchase receipt as proof of purchase.

You can also visit the [Bergner Store on Amazon](#) for more information.

