

[Manuals.plus](#) /

› [GJS Gourmet](#) /

› GJS Gourmet Pressure Valve Instruction Manual for Harvest Coppertech Pressure Pro Electric Pressure Cooker (Model YBW60LH)

GJS Gourmet YBW60LH

GJS Gourmet Pressure Valve Instruction Manual

For 6-Quart Harvest Coppertech Pressure Pro Electric Pressure Cooker (Model YBW60LH)

1. INTRODUCTION

This manual provides detailed instructions for the GJS Gourmet replacement pressure valve, specifically designed for compatibility with the 6-Quart Harvest Coppertech Pressure Pro Electric Pressure Cooker, Model YBW60LH. This component is crucial for maintaining the correct internal pressure and ensuring the safe operation of your electric pressure cooker.

Proper installation and maintenance of the pressure valve are essential for optimal performance and safety. Please read these instructions carefully before attempting to install or use the valve.

2. IMPORTANT SAFETY INFORMATION

- Always ensure the pressure cooker is unplugged from the power outlet and completely depressurized before handling any parts, especially the pressure valve.
- Allow the pressure cooker to cool down completely before attempting to install, remove, or clean the pressure valve. Hot surfaces and steam can cause severe burns.
- Never operate the pressure cooker with a damaged, worn, or improperly installed pressure valve. This can lead to unsafe pressure levels and potential hazards.
- Regularly inspect the pressure valve for any signs of wear, cracks, or blockages. Replace the valve immediately if any damage is observed.
- Refer to your original Harvest Coppertech Pressure Pro Electric Pressure Cooker manual for comprehensive safety guidelines and operating procedures.
- Keep all pressure cooker components, including the valve, out of reach of children.

3. PACKAGE CONTENTS

Upon opening the package, verify that all components are present and undamaged:

- 1 x GJS Gourmet Pressure Valve (Model YBW60LH)

4. SETUP AND INSTALLATION

Follow these steps to properly install the GJS Gourmet Pressure Valve:

1. **Preparation:** Ensure your Harvest Coppertech Pressure Pro Electric Pressure Cooker is completely cool, unplugged, and empty. Remove the lid from the cooker body.
2. **Locate Old Valve:** Identify the existing pressure valve on the lid of your pressure cooker. It is typically a small, cylindrical component that protrudes from the top of the lid.
3. **Remove Old Valve:** Carefully remove the old pressure valve. Depending on your cooker's design, this may involve gently twisting and pulling it upwards, or it might simply lift out. If you encounter resistance, consult your pressure cooker's original manual for specific removal instructions.
4. **Inspect Opening:** Clean the opening on the lid where the valve sits, ensuring no food debris or residue is present.
5. **Install New Valve:** Take the new GJS Gourmet Pressure Valve. Align the base of the valve with the opening on the pressure cooker lid and gently push it down until it is securely seated. You may feel a slight click or resistance as it locks into place.
6. **Verify Installation:** Once installed, gently wiggle the valve to ensure it is secure but can still move freely up and down. The internal pin should be visible and unobstructed.



Figure 4.1: Top-down view of the GJS Gourmet Pressure Valve, illustrating its design and internal components.



Figure 4.2: Side view of the GJS Gourmet Pressure Valve, showing the overall structure and sealing components.

5. OPERATING INSTRUCTIONS

The pressure valve operates automatically to regulate the internal pressure of your electric pressure cooker. No manual intervention is typically required during cooking, beyond ensuring it is clean and properly installed.

- **Pressure Build-Up:** As the pressure cooker heats up and pressure begins to build inside, the pressure valve will rise and seal the cooker. This indicates that the cooker is reaching its operating pressure.
- **Pressure Release:** After the cooking cycle is complete, the pressure inside the cooker will naturally decrease. The pressure valve will drop back down once the internal pressure has safely dissipated. This signifies that the lid can be safely opened.
- **Manual Release:** If your pressure cooker has a manual steam release valve, operating it will also cause the pressure valve to drop as steam is vented.

- **Important:** Never attempt to force the pressure valve down while the cooker is pressurized. Always wait for the valve to drop naturally or use the manual steam release function of your pressure cooker.

6. MAINTENANCE

Regular maintenance of your pressure valve ensures its longevity and the safe operation of your pressure cooker:

- **Cleaning:** After each use, remove the pressure valve from the lid and rinse it thoroughly under warm running water. Ensure all food particles and residue are removed from both the exterior and interior mechanisms.
- **Inspection:** Periodically inspect the valve for any signs of wear, such as cracks in the rubber seal, corrosion on metal parts, or deformation. Ensure the internal pin moves freely without sticking.
- **Replacement:** If the pressure valve shows any signs of damage, excessive wear, or does not operate smoothly, it must be replaced immediately to prevent safety hazards.
- **Dishwasher Safety:** This pressure valve is **not dishwasher safe**. Hand wash only.

7. TROUBLESHOOTING

If you encounter issues with your pressure valve, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Pressure valve does not rise during cooking.	<ul style="list-style-type: none">◦ Insufficient liquid in the cooker.◦ Lid not properly sealed.◦ Pressure valve is obstructed by food debris.◦ Pressure valve is damaged or worn.	<ul style="list-style-type: none">◦ Add more liquid according to recipe.◦ Ensure lid is correctly closed and locked.◦ Remove and thoroughly clean the pressure valve.◦ Replace the pressure valve.
Steam leaks from around the pressure valve.	<ul style="list-style-type: none">◦ Pressure valve not seated correctly.◦ Pressure valve is damaged or worn.◦ Sealing ring on the pressure cooker lid is damaged or improperly installed.	<ul style="list-style-type: none">◦ Remove and re-seat the pressure valve firmly.◦ Replace the pressure valve.◦ Inspect and properly install or replace the lid's sealing ring.
Pressure valve is stuck in the up or down position.	<ul style="list-style-type: none">◦ Food debris or mineral deposits.◦ Internal mechanism is damaged.	<ul style="list-style-type: none">◦ Thoroughly clean the valve.◦ Replace the pressure valve.

If troubleshooting steps do not resolve the issue, or if you suspect a more serious problem, discontinue use of the pressure cooker and contact GJS Gourmet customer support or a qualified technician.

8. SPECIFICATIONS

- **Brand:** GJS Gourmet
- **Model Number:** YBW60LH
- **Compatibility:** 6-Quart Harvest Coppertech Pressure Pro Electric Pressure Cooker

- **Dishwasher Safe:** No
- **Material:** Food-grade silicone and durable metal components

9. WARRANTY AND SUPPORT

For specific warranty information regarding your GJS Gourmet Pressure Valve, please refer to the product packaging or contact GJS Gourmet customer service directly. Contact details can typically be found on the manufacturer's website or product documentation.

For support related to the Harvest Coppertech Pressure Pro Electric Pressure Cooker itself, please consult the original manual provided with your appliance or contact the manufacturer of the pressure cooker.

© 2023 GJS Gourmet. All rights reserved.

This manual is for informational purposes only. GJS Gourmet is not affiliated with Harvest Coppertech.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question