

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Daewoo](#) /

› [Daewoo 1.6L Soup Maker SDA1714 Instruction Manual](#)

Daewoo SDA1714

Daewoo 1.6L Soup Maker SDA1714 Instruction Manual

Model: SDA1714

INTRODUCTION

Thank you for purchasing the Daewoo 1.6L Soup Maker SDA1714. This appliance is designed to simplify the preparation of various dishes, including smooth soups, chunky soups, refreshing smoothies, and delicious jams. Please read this manual thoroughly before first use to ensure safe and efficient operation. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. This includes:

- Read all instructions carefully before use.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Always ensure the lid is securely in place before operating the appliance.
- Exercise extreme caution when handling hot liquids and steam. The appliance surface will become hot during operation.
- Keep hands and utensils out of the jug during operation to prevent injury and damage to the blades.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is equipped with dry-burn prevention, which protects the motor from damage if operated without sufficient liquid.
- Note: This appliance may be supplied with a UK plug. An appropriate adapter will be required for use in other regions.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Daewoo Soup Maker.



Image: The Daewoo 1.6L Soup Maker, shown with a bowl of freshly made tomato soup and cherry tomatoes, highlighting its sleek design and digital control panel.

- **Main Unit:** Stainless steel jug with integrated heating element and motor.
- **Lid:** Safety interlocking lid with a measuring cup insert.
- **Control Panel:** Digital display with program selection buttons (Smooth, Chunky, Juice/Smoothie, Blend, Mode, Select/On/Off).
- **Blades:** Durable, rust-proof stainless steel blending blades.
- **Handle:** Ergonomically designed easy-lift handle.



Image: A side view of the Daewoo 1.6L Soup Maker, showcasing its stainless steel body and black handle.

SETUP

- Unpacking:** Carefully remove all packaging materials and ensure all components are present.
- Initial Cleaning:** Before first use, clean the inside of the jug and the lid with warm, soapy water. Wipe the exterior of the main unit with a damp cloth. Dry all parts thoroughly.
- Placement:** Place the soup maker on a stable, flat, heat-resistant surface, away from the edge of the countertop. Ensure there is adequate ventilation around the appliance.

4. **Power Connection:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches your local power supply.





Image: The rear view of the Daewoo 1.6L Soup Maker, illustrating the power cord connection point at the base of the unit.

OPERATING INSTRUCTIONS

The Daewoo Soup Maker offers various programs for different preparations. Always ensure ingredients are chopped into small pieces (approximately 2-3 cm) before adding them to the jug.



Image: Chopped vegetables, including carrots, peas, broccoli, and bell peppers, being added from a cutting board into the Daewoo Soup Maker.

General Operation Steps:

1. Add your prepared ingredients and liquid (water, stock, milk) to the soup maker jug. Do not exceed the maximum fill line.
2. Secure the lid firmly onto the jug. Ensure it clicks into place for safety.
3. Plug in the appliance. The digital display will illuminate.
4. Press the 'Mode' button to cycle through the available programs.
5. Once your desired program is selected, press the 'Select/On/Off' button to start. The appliance will begin its cycle, indicated by a countdown timer.
6. When the program finishes, the appliance will beep, and the display will show 'End'. Unplug the appliance and carefully remove the lid.

Specific Programs:

- **Smooth Soup:** This program cooks and blends ingredients to a smooth consistency. Ideal for creamy soups.
- **Chunky Soup:** This program cooks ingredients without blending, resulting in a soup with visible chunks of vegetables.
- **Juice/Smoothie:** This program blends raw ingredients to create refreshing juices or smoothies. No heating is involved.



Image: The Daewoo 1.6L Soup Maker positioned next to a glass of strawberry smoothie and fresh strawberries, demonstrating its smoothie function.

- **Jam:** This program cooks and blends ingredients suitable for jam making. Refer to specific recipes for best results.
- **Blend:** Use this function for manual blending if you require a specific consistency or to blend ingredients after a chunky soup program.
- **Keep Warm:** After certain programs, the appliance may automatically switch to a 'Keep Warm' function to maintain the temperature of your food.

CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your soup maker.

1. **Unplug:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Jug Cleaning:** Add a small amount of warm, soapy water to the jug. You can use the 'Blend' function for a few seconds to help dislodge food residue. Carefully scrub the inside of the jug with a non-abrasive sponge or brush. Pay special attention to the blades, exercising caution due to their sharpness. Rinse thoroughly.
3. **Lid Cleaning:** Wash the lid and its components in warm, soapy water. Rinse and dry thoroughly.
4. **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water.
5. **Storage:** Ensure all parts are completely dry before storing the appliance. Store in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your soup maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; lid not secured.	Check power connection; ensure lid is correctly fitted; check household power.
Ingredients sticking to the base.	Insufficient liquid; too many solid ingredients (e.g., red lentils, dried pasta).	Ensure adequate liquid is added; reduce the amount of solid ingredients; stir manually if possible during cooking (with caution).
Dry-burn prevention activated.	Liquid level too low.	Add more liquid, ensuring it is above the minimum fill line. Allow the appliance to cool before restarting.
Loud noise during blending.	Normal operation; hard ingredients.	Some noise is normal during blending. Ensure ingredients are chopped into small pieces.

SPECIFICATIONS

- **Model Number:** SDA1714
- **Brand:** Daewoo
- **Capacity:** 1.6 Litres (approximately 6 portions per blend)
- **Power:** 1000 Watts
- **Material:** Stainless Steel
- **Dimensions (L x W x H):** 26 x 18.5 x 36 cm
- **Weight:** 2.66 Kilograms
- **Features:** Digital control, rust-proof stainless steel blades, dry-burn prevention, safety interlocking lid, easy-lift handle, keep warm function.

WARRANTY AND SUPPORT

This Daewoo Soup Maker comes with a 3-year warranty, subject to online registration. Please visit the official Daewoo website for warranty registration and further support. Keep your proof of purchase for warranty claims.