

[Manuals.plus](#) /

› [Copper Chef](#) /

› Copper Chef 2 QT Air Fryer User Manual

Copper Chef 2 QT Air Fryer

Copper Chef 2 QT Air Fryer User Manual

Model: 2 QT Air Fryer (ASIN: B07T8JTN22)

INTRODUCTION

The Copper Chef 2 QT Air Fryer utilizes Rapid Air Technology to circulate super-heated air up to 400°F, providing a healthier alternative to traditional deep frying. This appliance allows you to roast, air fry, bake, steam, sauté, and grill your favorite foods with significantly less oil. Its compact design is ideal for preparing 1-2 servings, making it perfect for individuals or small households. The non-stick basket and easy-to-use digital controls ensure a convenient and efficient cooking experience.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- This appliance is for household use only.

PRODUCT OVERVIEW



Front view of the Copper Chef 2 QT Air Fryer, showcasing its red exterior, silver accents, and the digital control panel with temperature and time settings.



The air fryer with its non-stick basket partially pulled out, revealing food inside. This image demonstrates the easy access to the cooking chamber.

Components:

- Main Unit with Digital Control Panel
- Easy Load Basket with Non-Stick Coating
- Cool-to-the-Touch Easy Grip Handle
- Air Intake Vent (top)
- Hot Air Outlet Vent (rear)

Digital Control Panel:

- **Temperature Display:** Shows current or set temperature (up to 400°F).
- **Time Display:** Shows current or set cooking time.
- **Power Button:** Turns the unit on/off.
- **Temperature Control Buttons (+/-):** Adjusts cooking temperature.

- **Time Control Buttons (+/-):** Adjusts cooking time.

SETUP AND FIRST USE

1. **Unpack:** Remove all packaging materials, stickers, and labels from the unit.
2. **Clean Components:** Wash the basket and any removable accessories in warm, soapy water. Rinse and dry thoroughly. Wipe the inside and outside of the main unit with a clean, damp cloth.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from water sources and other appliances. Ensure there is at least 6 inches of space around the back and sides for proper air circulation.
4. **Pre-Heat (Initial Run):** Before first use, it is recommended to run the air fryer for 10-15 minutes at 350°F (175°C) without any food inside. This helps to burn off any manufacturing residue and eliminate initial odors. A slight odor may be present during this process; this is normal.
5. **Cool Down:** Allow the unit to cool completely after the initial run.

OPERATING INSTRUCTIONS

General Operation:

1. **Prepare Food:** Place your desired food items into the non-stick basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the basket firmly into the main unit until it clicks into place.
3. **Power On:** Plug the power cord into a grounded wall outlet. The digital display will illuminate. Press the Power Button to turn the unit on.
4. **Set Temperature:** Use the Temperature Control Buttons (+/-) to set the desired cooking temperature (e.g., 400°F).
5. **Set Time:** Use the Time Control Buttons (+/-) to set the desired cooking time.
6. **Start Cooking:** The air fryer will automatically begin the cooking cycle after a few seconds.
7. **Shake/Flip Food (Optional):** For best results with certain foods (e.g., fries, chicken wings), pull out the basket halfway through the cooking time and gently shake or flip the food. Reinsert the basket to resume cooking.
8. **Automatic Shut-Off:** The air fryer will automatically shut off and beep when the set cooking time has elapsed.
9. **Remove Food:** Carefully pull out the basket using the cool-to-the-touch handle. Use tongs to remove cooked food from the basket.
10. **Cool Down:** Allow the unit to cool completely before cleaning or storing.



The Copper Chef 2 QT Air Fryer positioned on a kitchen counter, surrounded by a variety of air-fried dishes such as onion rings, waffle fries, and curly fries, demonstrating its versatility.

Cooking Tips:

- For crispier results, lightly spray or toss food with a small amount of oil before air frying.
- Smaller food items typically require shorter cooking times than larger ones.
- Preheating the air fryer for 3-5 minutes before adding food can improve cooking results.
- Refer to a reliable air fryer recipe guide for specific cooking times and temperatures for various foods.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Copper Chef Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Basket and Tray:** The non-stick basket and any removable accessories are dishwasher safe. Alternatively, wash them in warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry completely.

- 3. **Clean Main Unit:** Wipe the exterior of the air fryer with a damp cloth. For stubborn stains, use a mild detergent. Do not immerse the main unit in water or any other liquid.
- 4. **Clean Heating Element:** If necessary, gently clean the heating element inside the air fryer with a soft brush to remove any food residue. Do not use abrasive materials.
- 5. **Storage:** Ensure all parts are clean and dry before storing. Store the air fryer in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; Basket not inserted correctly; Power button not pressed.	Ensure the power cord is securely plugged into a grounded outlet. Push the basket firmly into the unit until it clicks. Press the Power Button.
Food is not cooked evenly.	Basket is overfilled; Food not shaken/flipped.	Do not overfill the basket. Cook in smaller batches if necessary. Shake or flip food halfway through cooking.
Food is not crispy.	Not enough oil (for certain foods); Temperature too low; Cooking time too short.	Lightly spray or toss food with a small amount of oil. Increase temperature or cooking time as needed.
White smoke coming from the unit.	Grease residue from previous use; High-fat food cooking.	Clean the basket and inside of the unit thoroughly after each use. For high-fat foods, consider placing a small amount of water in the bottom of the outer pan to catch grease.
Appliance smells during first use.	Manufacturing residue burning off.	This is normal. Run the air fryer empty for 10-15 minutes at 350°F (175°C) before first use. Ensure good ventilation.

SPECIFICATIONS

- Model:** 2 QT Air Fryer
- Brand:** Copper Chef
- Capacity:** 2 Quarts (1.89 Liters)
- Power:** 1000 Watts
- Temperature Range:** Up to 400°F
- Control Type:** Digital Touch Control
- Material:** Plastic with Non-Stick Coated Basket
- Color:** Red
- Dimensions (Approx.):** 12.8 x 10.1 x 9.7 inches (Package Dimensions)
- Weight (Approx.):** 6.39 pounds
- Dishwasher Safe Parts:** Basket and removable accessories
- Manufacturer:** Tristar Products Inc

UPC: 752356829346
ASIN: B07T8JTN22

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Copper Chef website. You may also contact Tristar Products Inc., the manufacturer, for assistance. For additional resources and recipes, visit the [Copper Chef Store on Amazon](#).

© 2024 Copper Chef. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question