

[Manuals.plus](#) /

› [i-Life](#) /

› i-Life ZED NOTE Prime Laptop User Manual

i-Life ZED NOTE Prime IL.1106.232

i-Life ZED NOTE Prime Laptop User Manual

Model: IL.1106.232

1. INTRODUCTION

Welcome to the user manual for your new i-Life ZED NOTE Prime laptop. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your device. The i-Life ZED NOTE Prime is a versatile 360-degree convertible laptop designed for productivity and entertainment, featuring an 11.6-inch Full HD IPS touchscreen display and running on Windows 10.

Please read this manual thoroughly to ensure proper use and to maximize the performance and lifespan of your laptop.

2. PRODUCT OVERVIEW

Familiarize yourself with the components and features of your i-Life ZED NOTE Prime laptop.



Figure 2.1: i-Life ZED NOTE Prime Laptop in traditional laptop mode, displaying the keyboard and screen.



Figure 2.2: Side view of the i-Life ZED NOTE Prime Laptop, highlighting various ports for connectivity.

2.1 Package Contents

- i-Life ZED NOTE Prime Laptop
- Power Adapter
- User Manual (this document)

2.2 Device Features

- 11.6-inch Full HD (1920x1080) IPS Touchscreen Display
- 360-degree Convertible Design (Laptop, Tent, Stand, Tablet modes)
- Intel Celeron N3350 Processor
- 2GB RAM
- 32GB eMMC Storage
- Windows 10 Operating System
- Long Battery Life (up to 8 hours)
- USB Charging Capability

3. SETUP

3.1 Charging the Laptop

1. Connect the power adapter to the charging port on your laptop.
2. Plug the power adapter into a wall outlet.
3. Allow the laptop to charge fully before initial use. The charging indicator light will typically change color or turn off

when fully charged.

3.2 Powering On for the First Time

1. Open the laptop lid.
2. Press and hold the power button for a few seconds until the screen lights up.
3. Follow the on-screen instructions to complete the Windows 10 initial setup, including language selection, network connection, and user account creation.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off/Sleep

- **Power On:** Press the power button.
- **Sleep Mode:** Briefly press the power button or close the lid. Press again or open the lid to wake.
- **Shut Down:** Click the Windows Start button, then select Power > Shut down.
- **Restart:** Click the Windows Start button, then select Power > Restart.

4.2 Using the Touchscreen and Convertible Modes

Your i-Life ZED NOTE Prime features a responsive touchscreen and a 360-degree hinge, allowing for multiple usage modes.



Figure 4.1: The i-Life ZED NOTE Prime Laptop configured in tent mode, ideal for presentations or media viewing.

- **Laptop Mode:** Traditional laptop setup for typing and productivity.
- **Tent Mode:** Fold the screen back to form a 'tent' shape, suitable for watching videos or presentations.
- **Stand Mode:** Fold the screen back further, using the keyboard as a stand, for touch-based interactions.
- **Tablet Mode:** Fold the screen completely back against the base for a full tablet experience. Windows 10 will automatically switch to Tablet Mode for optimized touch interaction.

4.3 Connecting Peripherals

The laptop includes various ports for connecting external devices:

- **USB Ports:** For connecting USB drives, mice, keyboards, and other USB devices.
- **Audio Jack:** For connecting headphones or external speakers.
- **MicroSD Card Slot:** For expanding storage with a MicroSD card.

5. MAINTENANCE

5.1 Cleaning the Device

- Use a soft, lint-free cloth to clean the screen and chassis.
- For stubborn marks, dampen the cloth slightly with water or a screen-cleaning solution. Avoid harsh chemicals.
- Ensure the laptop is powered off and unplugged before cleaning.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place when not in use for extended periods.
- Do not expose the battery to extreme temperatures.

5.3 Software Updates

Regularly check for and install Windows updates to ensure your system has the latest security patches and performance improvements. Go to **Settings > Update & Security > Windows Update**

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your i-Life ZED NOTE Prime laptop.

Problem	Possible Solution
Laptop does not power on.	Ensure the laptop is charged. Connect the power adapter and try again. If the battery is completely drained, it may take a few minutes before it can power on.
Screen is blank or unresponsive.	Try restarting the laptop. If in tablet mode, ensure the screen is clean and free of obstructions. Check display settings in Windows.
Wi-Fi connection issues.	Check if Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Ensure you are within range of the Wi-Fi network.
Slow performance.	Close unnecessary applications. Check for Windows updates. Consider running a disk cleanup or antivirus scan.

If you encounter issues not covered here, please refer to the support section or contact customer service.

7. SPECIFICATIONS

Detailed technical specifications for the i-Life ZED NOTE Prime Laptop (Model IL.1106.232).

Feature	Detail
Brand	i-Life
Item Model Number	IL.1106.232
Color	Gold
Screen Size	11.6 inches
Screen Resolution	1920 x 1080 Pixels (Full HD IPS)
Processor Brand	Intel
Processor Type	Celeron N3350
Number of Processors	2 (Dual Core)
RAM Size	2 GB
Memory Technology	DDR4 (Computer Memory Type: DDR3 SDRAM)
Hard Drive Size	32 GB (eMMC)
Audio Details	Headphones
Graphics Chipset Brand	Intel
Graphics Card Description	Integrated
Graphics RAM Size	2 GB
Voltage	5 Volts
Front Webcam Resolution	2 Megapixels
Operating System	Windows 10
Average Battery Life	8 hours
Item Weight	1.58 Kilograms
Package Dimensions	37.6 x 22.4 x 5.8 cm
Special Feature	Touchscreen
Date First Available	July 29, 2019

8. SAFETY INFORMATION

Please observe the following safety guidelines to prevent damage to your device or personal injury:

- Do not expose the laptop to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Keep liquids away from the laptop to prevent electrical shock or damage.
- Use only the original power adapter or a certified replacement.
- Do not attempt to disassemble or repair the laptop yourself. Refer to qualified service personnel.
- Keep out of reach of children.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official i-Life website. For technical support or service inquiries, please contact i-Life customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question