

AmazonBasics BM1349DB-GS

AmazonBasics Bread Maker BM1349DB-GS User Manual

Model: BM1349DB-GS

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your AmazonBasics Bread Maker. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed for household use only.

Important Safety Instructions

- Always ensure the appliance is unplugged before cleaning or when not in use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep hands, hair, clothing, and utensils away from moving parts during operation.
- Do not touch hot surfaces. Use oven mitts when handling hot parts like the bread pan or baked bread.
- Ensure the appliance is placed on a stable, heat-resistant surface, away from flammable materials.
- Supervise children closely when the appliance is in use.

PRODUCT OVERVIEW

Familiarize yourself with the components of your bread maker for optimal use.



Image: Front view of the AmazonBasics Bread Maker. This image displays the overall design of the appliance, including the control panel and viewing window on the lid.

Main Components:

- **Main Unit:** Houses the motor, heating element, and control panel.
- **Lid:** Features a viewing window to monitor the baking process.
- **Control Panel:** Includes display, menu buttons, and function buttons.
- **Bread Pan:** Removable non-stick pan where ingredients are mixed and baked.
- **Kneading Paddle:** Detachable paddle inside the bread pan for mixing and kneading dough.
- **Measuring Cup and Spoon:** For accurate ingredient measurement (usually included).



Image: Top-down view of the AmazonBasics Bread Maker with the lid open, revealing the interior cavity where the bread pan is placed.



Image: Close-up of the removable bread pan with its handle, showing the non-stick interior and the shaft for the kneading paddle.

SETUP

Unpacking and First Use

1. Carefully remove the bread maker and all accessories from the packaging.
2. Wash the bread pan and kneading paddle with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaners.
4. Before first use, it is recommended to run the BAKE program (Program 14) for 10 minutes without ingredients to burn off any manufacturing residues. Ensure good ventilation during this process.

Placement

Place the bread maker on a stable, level, and heat-resistant surface. Ensure there is adequate ventilation around the appliance, with at least 10-15 cm of clear space on all sides and above. Do not place it near heat sources or in direct sunlight.

OPERATING INSTRUCTIONS

Control Panel



Image: Close-up view of the control panel on the AmazonBasics Bread Maker, showing the digital display and various function buttons like MENU, TIME, LOAF, COLOR, CYCLE, and START/STOP.

- **MENU:** Selects one of the 15 available programs.
- **TIME (+/-):** Adjusts the delay timer for delayed baking.
- **LOAF:** Selects loaf size (700g or 900g).
- **COLOR:** Selects crust color (Light, Medium, Dark).
- **CYCLE:** Used for custom program settings (Program 15).
- **START/STOP:** Starts, pauses, or cancels a program.
- **LCD Display:** Shows program number, time remaining, loaf size, and crust color.

Adding Ingredients

Always add ingredients in the order specified by your recipe. Typically, liquids are added first, followed by dry ingredients, with yeast placed last, away from liquids and salt.

1. Attach the kneading paddle to the shaft inside the bread pan.
2. Add all liquid ingredients to the bread pan.
3. Add dry ingredients, ensuring the yeast is placed in a small well on top of the flour, away from liquids

and salt.

4. Place the bread pan into the bread maker and close the lid.

Selecting a Program

The AmazonBasics Bread Maker offers 15 programs:

1. **BASIC:** For white and mixed breads.
2. **FRENCH:** For light breads made from fine flour.
3. **WHOLE WHEAT:** For breads with whole wheat flour.
4. **QUICK:** For quick preparation of white bread.
5. **SWEET:** For sweet breads with additives like fruit or sugar.
6. **GLUTEN FREE:** For gluten-free recipes.
7. **DOUGH:** For preparing dough for rolls, pizza, etc., without baking.
8. **KNEADING:** For kneading dough only.
9. **CAKE:** For cakes and quick breads using baking powder/soda.
10. **SANDWICH:** For light, fluffy sandwich bread.
11. **SPECIALITY:** For specific recipes not covered by other programs.
12. **JAM:** For making homemade jams and marmalades.
13. **YOGURT:** For preparing yogurt.
14. **BAKE:** For baking pre-made dough or adding extra baking time.
15. **HOMEMADE:** Allows custom setting of kneading, rising, and baking times.

Press the **MENU** button repeatedly to cycle through the programs until the desired program number appears on the display.

Loaf Size and Crust Color

- Press the **LOAF** button to select between 700g and 900g loaf sizes, depending on your recipe.
- Press the **COLOR** button to choose your preferred crust darkness: Light, Medium, or Dark.

Delay Timer Function

To delay the start of a program, use the **TIME (+/-)** buttons. Set the desired delay time, including the baking cycle duration. For example, if a program takes 3 hours and you want the bread ready in 8 hours, set the delay timer to 8:00. Do not use the delay timer with recipes containing perishable ingredients like milk, eggs, or fresh fruit.

Starting and Stopping

- Press the **START/STOP** button once to begin the selected program. The colon on the display will flash, indicating operation.
- To pause a program, press **START/STOP** once. To resume, press it again.
- To cancel a program, press and hold the **START/STOP** button for approximately 3 seconds until a beep sounds and the display returns to the default setting.

Removing Baked Bread

Once the program is complete, the bread maker will beep and may enter a 'Keep Warm' cycle. Unplug the appliance. Using oven mitts, carefully remove the bread pan by twisting it counter-clockwise and lifting it out. Invert the pan to release the bread onto a wire rack to cool. If the kneading paddle remains in the bread, remove it carefully with a non-metallic utensil after the bread has cooled slightly.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and performance of your bread maker.

Cleaning the Bread Pan and Kneading Paddle

- After each use, allow the bread pan and kneading paddle to cool completely.
- Fill the bread pan with warm, soapy water and let it soak for 10-15 minutes to loosen any stuck-on dough or residue.
- Remove the kneading paddle and clean both the pan and paddle with a soft sponge or cloth. Do not use abrasive materials or metal utensils, as this can damage the non-stick coating.
- Rinse thoroughly and dry completely before storing or next use.

Cleaning the Exterior

- Unplug the bread maker and allow it to cool.
- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or immerse the main unit in water.
- Clean the viewing window with a soft, damp cloth.

Storage

Ensure the bread maker is clean, dry, and completely cool before storing. Store it in a dry place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Bread does not rise or rises too much.	Incorrect yeast amount, old yeast, incorrect water temperature, wrong ingredient ratio.	Check yeast freshness and quantity. Ensure water is lukewarm (not too hot or cold). Verify ingredient measurements.
Bread is too dense or heavy.	Too much flour, too little liquid, insufficient kneading, wrong program selected.	Accurately measure flour and liquid. Ensure the correct program is selected for the recipe.
Kneading paddle stuck in bread.	Common occurrence.	Allow bread to cool slightly, then carefully remove the paddle with a non-metallic utensil.
Bread pan difficult to remove.	Residue buildup or pan not properly seated.	Ensure pan is clean. Twist firmly counter-clockwise to unlock.
Appliance not starting.	Not plugged in, power outage, START/STOP not pressed correctly.	Check power connection. Ensure START/STOP button is pressed firmly.

SPECIFICATIONS

Technical details for the AmazonBasics Bread Maker BM1349DB-GS.

- **Model Number:** BM1349DB-GS
- **Power:** 550W
- **Loaf Sizes:** 700g, 900g
- **Number of Programs:** 15
- **Item Weight:** 3 kg 630 g
- **Item Dimensions (LxWxH):** 29.7 x 14.2 x 29.2 Centimeters
- **Product Care Instructions:** Wipe with Dry Cloth

WARRANTY AND SUPPORT



Warranty Information





This AmazonBasics Bread Maker comes with a **1 Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accident, alteration, or unauthorized repair.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact AmazonBasics customer support through the Amazon website or your local Amazon customer service channels. Provide your model number (BM1349DB-GS) and purchase details when contacting support.

Related Documents - BM1349DB-GS

<div><p>AmazonBasics Bread Maker with 15 Baking Programs including Gluten Free, 700g/900g, 550W</p><p>Model: BM1349DB-GS</p><p>Power: 550W</p><p>Loaf Sizes: 700g, 900g</p><p>Number of Programs: 15</p><p>Item Weight: 3 kg 630 g</p><p>Item Dimensions (LxWxH): 29.7 x 14.2 x 29.2 Centimeters</p><p>Product Care Instructions: Wipe with Dry Cloth</p></div>	<p>AmazonBasics Bread Maker User Manual</p> <p>Comprehensive user manual for the AmazonBasics Bread Maker, detailing its features, operation, safety instructions, and recipes for various bread types.</p>
<div><p>AmazonBasics Line-Interactive UPS 1000VA 550W, 9 Outlets</p><p>Model: BM1349DB-GS</p><p>Power: 550W</p><p>Loaf Sizes: 700g, 900g</p><p>Number of Programs: 15</p><p>Item Weight: 3 kg 630 g</p><p>Item Dimensions (LxWxH): 29.7 x 14.2 x 29.2 Centimeters</p><p>Product Care Instructions: Wipe with Dry Cloth</p></div>	<p>AmazonBasics Line-Interactive UPS 1000VA 550W User Manual</p> <p>User manual for the AmazonBasics Line-Interactive UPS 1000VA 550W, covering safety, operation, troubleshooting, and specifications. Features 9 outlets for power backup and surge protection.</p>

	<p>AmazonBasics 10W Qi Wireless Charging Stand: User Guide, Safety & Specifications (B0874YN8B9)</p> <p>Get detailed safety instructions, operating procedures, specifications, and disposal information for the AmazonBasics 10W Qi Certified Wireless Charging Stand (Model B0874YN8B9). This guide ensures proper and safe use of your wireless charger.</p>
	<p>AmazonBasics CR2032 Lithium Coin Cell Battery: Safety and Disposal Guide</p> <p>Essential safety instructions, usage guidelines, and disposal information for AmazonBasics CR2032 Lithium Coin Cell Batteries. Learn how to handle and dispose of batteries responsibly.</p>
	<p>AmazonBasics Book Safe with Combination Lock: Quick Start Guide</p> <p>Step-by-step instructions for using the AmazonBasics Book Safe with Combination Lock, covering opening, closing, and setting a new combination.</p>
	<p>AmazonBasics Portable Bluetooth Speaker Instruction Manual</p> <p>AmazonBasics Portable Bluetooth Speaker manual: Learn setup, pairing, music playback, speakerphone use, and troubleshooting for model BTV1. Includes multiple languages.</p>