

HiLetgo NTC 3950 Thermistors

HiLetgo 10pcs 3D Printer 100K ohm NTC 3950 Thermistors Sensors User Manual

Model: NTC 3950 Thermistors | Brand: HiLetgo

1. INTRODUCTION

This user manual provides comprehensive instructions for the HiLetgo 10pcs 3D Printer 100K ohm NTC 3950 Thermistors Sensors. These thermistors are designed for accurate temperature measurement in 3D printing applications, such as monitoring hotend and heated bed temperatures. Please read this manual thoroughly before installation and operation to ensure proper use and optimal performance.

2. PRODUCT OVERVIEW

Key Features

- Temperature sensor 100K Ω accuracy of $\pm 1\%$
- Wiring length: 1 meter
- NTC 3950 B-value for common 3D printer firmware configurations

Package Contents

- 10 x 100K ohm NTC 3950 Thermistors with 1m Cable



Image 1: Overview of the HiLetgo 10pcs NTC 3950 Thermistors package.

3. SPECIFICATIONS

Specification	Value
Sensor Type	NTC 3950 Thermistor
Resistance	100K ohm at 25°C
Accuracy	± 1%
B-Value	3950K
Cable Length	1 meter (approx. 39.37 inches)
Wire Diameter	1.0 mm (approx.)
Manufacturer	HiLetgo
ASIN	B07V6YBFSY

Specification	Value
Package Dimensions	4.41 x 4.17 x 0.43 inches
Item Weight	1.41 ounces




Image 2: Detailed view of the NTC 3950 thermistor and wire specifications.

4. SETUP AND INSTALLATION

Proper installation of the thermistor is crucial for accurate temperature readings and safe operation of your 3D printer. Always refer to your specific 3D printer's documentation for detailed instructions on thermistor replacement or installation.

General Installation Steps:

1. **Safety First:** Ensure your 3D printer is powered off and unplugged from the mains before beginning any installation or maintenance.
2. **Locate Connection Point:** Identify the thermistor connection points on your 3D printer's hotend or heated bed. These are typically small wires leading to a glass bead or cartridge.
3. **Remove Old Thermistor (if applicable):** Carefully disconnect and remove the existing thermistor.

Note how it was secured (e.g., with a screw, kapton tape, or silicone sock).

4. **Connect New Thermistor:** The NTC 3950 thermistors are non-polar, meaning the orientation of the wires does not matter. Connect the two wires of the new thermistor to the designated thermistor input on your printer's control board. This may involve crimping connectors or soldering, depending on your board.
5. **Secure Thermistor Bead:** The thermistor bead must be securely placed to ensure good thermal contact and prevent movement. For hotends, it is often inserted into a small hole in the heater block and secured with a set screw. For heated beds, it might be taped underneath or inserted into a designated slot.
6. **Cable Management:** Route the 1-meter cable carefully, ensuring it does not interfere with moving parts of the printer and is protected from heat and abrasion. Use cable ties or sleeves as needed.
7. **Firmware Configuration:** After physical installation, you may need to configure your 3D printer's firmware (e.g., Marlin, Klipper, RepRapFirmware) to correctly recognize the NTC 3950 thermistor type. This typically involves selecting the correct thermistor table or B-value (3950) in the firmware settings. Consult your printer's firmware documentation for specific instructions.



Image 3: Close-up view of the thermistor ends, ready for connection.

5. OPERATING INSTRUCTIONS

Once installed and configured, the NTC 3950 thermistors operate automatically to provide temperature feedback to your 3D printer's control system. They are essential for maintaining stable temperatures for the hotend and heated bed, which is critical for successful 3D prints.

- **Temperature Monitoring:** The thermistors continuously measure the temperature of the hotend and heated bed. This data is used by the printer's firmware to regulate heating elements and maintain target temperatures.
- **Thermal Runaway Protection:** Modern 3D printer firmware includes thermal runaway protection, which relies on accurate thermistor readings. If the thermistor fails or becomes disconnected, the printer should detect an unexpected temperature drop and shut down to prevent overheating.
- **Calibration:** While these thermistors are factory calibrated, minor offsets in temperature readings can occur due to installation or environmental factors. If you suspect inaccurate readings, you can use an external thermometer to verify and apply a temperature offset in your printer's firmware if supported.

6. MAINTENANCE

Regular inspection and proper maintenance can extend the lifespan of your thermistors and ensure consistent print quality.

- **Visual Inspection:** Periodically check the thermistor wires and bead for any signs of damage, such as fraying, cuts, or melted insulation. Ensure the bead is still securely seated and has good thermal contact.
- **Cleaning:** If the thermistor bead becomes covered in melted plastic or debris, carefully clean it using a soft brush or cotton swab. Avoid using harsh chemicals or abrasive materials that could damage the thermistor. Ensure the printer is cool before cleaning.
- **Connection Check:** Verify that all connections to the control board and the hotend/heated bed are secure. Loose connections can lead to intermittent readings or complete failure.
- **Replacement:** Thermistors are wear-and-tear components. If you experience inconsistent temperature readings, frequent thermal runaway errors, or visible damage, it is recommended to replace the thermistor.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your NTC 3950 thermistors.

- **Issue: Incorrect Temperature Readings**
 - **Solution:** Check all wiring connections for looseness or damage. Verify that the correct thermistor type (NTC 3950) is selected in your 3D printer's firmware. Ensure the thermistor bead has good thermal contact with the heating element.
- **Issue: "Thermal Runaway" Error**
 - **Solution:** This error indicates an unexpected temperature drop or inability to reach target temperature. It often points to a loose thermistor connection, a faulty thermistor, or a problem with the heating element. Inspect connections, replace the thermistor if damaged, and check the heater cartridge/resistor.
- **Issue: No Temperature Reading (0°C or -15°C)**
 - **Solution:** This usually means the thermistor is disconnected or short-circuited. Check the wiring from the thermistor to the control board. Ensure the wires are not pinched or broken. Replace the thermistor if the wiring is intact but no reading is obtained.
- **Issue: Temperature Fluctuations**

- **Solution:** Minor fluctuations are normal, but large, erratic changes may indicate a loose connection, interference, or a failing thermistor. Re-secure connections and consider replacing the thermistor.

8. WARRANTY AND SUPPORT

HiLetgo products are designed for reliability and performance. While specific warranty details are not provided in this manual, customers are encouraged to contact HiLetgo directly for any product-related inquiries or support needs.

For technical support or if you encounter any issues with your product, please contact us:

- **Email:** support@hiletgo.com
- **Website:** www.hiletgo.com



Image 4: Example of HiLetgo product packaging.