

[Manuals.plus](#) /

› [Black+Decker](#) /

› Black+Decker FX1075 Food Processor User Manual

Black+Decker FX1075

Black+Decker FX1075 Food Processor User Manual

Model: FX1075 | Brand: Black+Decker

1. INTRODUCTION AND OVERVIEW

The Black+Decker FX1075 Food Processor is a versatile kitchen appliance designed to simplify your food preparation tasks. With its powerful 1000-watt motor and 5-in-1 functionality, it offers 32 different features, making it an indispensable tool for any kitchen.

Key features include:

- 5-in-1 functionality with various attachments for 32 different features.
- Powerful 4-blade dual-fixed system for efficient chopping.
- Family-sized 1.5-liter food processing bowl.
- 1-liter blender jar with stainless steel blades, ideal for smoothies and purees.
- 5 stainless steel discs for slicing, shredding, and grating.
- Grinder attachment for coffee, herbs, and spices.
- Kneading blade for dough preparation.
- Whisk attachment for eggs and cream.
- Two speed settings plus pulse function.
- Interlocking safety system for secure operation.
- Dishwasher-safe parts for easy cleaning.



Figure 1.1: The Black+Decker FX1075 Food Processor with its main unit, food processing bowl, blender jar, grinder, and various blades and discs.

2. SAFETY INSTRUCTIONS

Please read all safety warnings and instructions carefully before using this appliance to prevent electric shock, fire, and/or serious injury.

- Always unplug the appliance from the power supply before assembling, disassembling, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils away from moving blades or discs while processing food to prevent injury.
- Ensure the lid is securely locked in place before operating the appliance. The interlocking safety system prevents operation if not properly assembled.
- Do not process hot liquids in the blender or food processor bowl, as this may cause scalding.
- Avoid overloading the appliance. Refer to the maximum fill lines on the bowls.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Regularly inspect the power cord and plug for any damage. If damaged, do not use the appliance.

3. PRODUCT COMPONENTS

The Black+Decker FX1075 Food Processor comes with several components designed for various functions:

- **Motor Unit:** The main base containing the 1000W motor and control dial.
- **Food Processing Bowl:** 1.5-liter capacity bowl for chopping, slicing, shredding, and grating.
- **Blender Jar:** 1-liter capacity jar with stainless steel blades for blending liquids and soft foods.
- **Grinder Attachment:** Small cup with a blade for grinding coffee beans, spices, and herbs.
- **Chopping Blade:** Four-blade system for efficient chopping of various ingredients.
- **Stainless Steel Discs (5x):**
 - Slicing disc
 - Shredding disc
 - Grating disc
 - Other specialized discs for various textures.
- **Kneading Blade:** For mixing and kneading dough.
- **Whisk Attachment:** For whisking eggs and cream.
- **Pusher/Feeding Tube:** Used to guide ingredients into the food processing bowl.
- **Measuring Cup:** For precise ingredient measurement.



Figure 3.1: All components of the Black+Decker FX1075 Food Processor, including the main unit, bowls, blades, and discs.

4. SETUP

Before first use, wash all detachable parts in warm soapy water, rinse thoroughly, and dry. Wipe the motor unit with a damp cloth.

4.1 Assembling the Food Processor

1. Place the motor unit on a stable, flat surface.
2. Fit the food processing bowl onto the motor unit, aligning the arrow on the bowl with the arrow on the motor unit, and twist clockwise until it locks into place.
3. Insert the desired blade (chopping, kneading, or whisk) or disc onto the central shaft inside the bowl. Ensure it is securely seated.
4. Place the lid onto the food processing bowl, aligning the tab on the lid with the slot on the handle, and twist clockwise until it locks. The safety interlock will engage.
5. Insert the pusher into the feeding tube opening on the lid.

4.2 Assembling the Blender

1. Ensure the blender blade assembly is securely attached to the bottom of the blender jar.
2. Place the blender jar onto the motor unit, aligning the base with the motor unit's coupling, and twist clockwise until it locks.
3. Place the lid onto the blender jar and secure it.



Figure 4.1: The food processor bowl assembled with ingredients ready for processing.

5. OPERATING INSTRUCTIONS

Always ensure the appliance is properly assembled and locked before plugging it in and operating.

5.1 Using the Food Processor

1. Prepare ingredients: Cut large ingredients into smaller pieces that fit through the feeding tube.
2. Place ingredients into the food processing bowl. Do not exceed the maximum fill line.
3. Secure the lid and pusher.
4. Plug the appliance into a suitable power outlet.
5. Turn the control dial to the desired speed setting (1 or 2) or to the 'Pulse' setting for short bursts of power.
6. Process until desired consistency is achieved. For slicing/shredding, feed ingredients through the feeding tube using the pusher.
7. Once finished, turn the dial to '0' and unplug the appliance.
8. Carefully unlock and remove the lid, then the blade/disc, and finally the processed food.

5.2 Using the Blender

1. Add liquids and solid ingredients to the blender jar. Do not exceed the maximum fill line (1 liter).
2. Secure the blender lid.
3. Place the blender jar onto the motor unit and lock it.
4. Plug the appliance into a suitable power outlet.
5. Turn the control dial to the desired speed setting (1 or 2) or 'Pulse' for quick blending.
6. Blend until smooth.
7. Once finished, turn the dial to '0' and unplug the appliance.
8. Carefully remove the blender jar and pour out the contents.



Figure 5.1: The blender jar filled with fruits, ready for blending smoothies.

5.3 Using the Grinder

1. Place a small amount of coffee beans, spices, or herbs into the grinder cup.
2. Attach the grinder blade assembly to the cup.
3. Invert the grinder cup and place it onto the motor unit, twisting to lock.
4. Plug in the appliance.
5. Use the 'Pulse' setting for short bursts until desired fineness is achieved.
6. Unplug, carefully remove the grinder, and empty contents.



Figure 5.2: The grinder attachment with various spices, demonstrating its use for grinding.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Black+Decker FX1075 Food Processor.

- **Always unplug the appliance before cleaning.**
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Detachable Parts:** The food processing bowl, blender jar, grinder cup, lids, blades, and discs are dishwasher-safe. Alternatively, wash them in warm soapy water, rinse thoroughly, and dry immediately.
- **Blades and Discs:** Handle blades and discs with extreme care as they are very sharp. Use a brush for cleaning if necessary.
- **Storage:** Store the appliance and its accessories in a dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

If you encounter any issues with your food processor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; safety interlock not engaged; power outage.	Ensure power cord is securely plugged in. Check if bowl/lid is correctly locked. Check power supply.
Motor stops during operation.	Overloaded; motor overheating.	Unplug, remove some ingredients, let motor cool down for 15-20 minutes before restarting.
Ingredients not processing evenly.	Too many ingredients; ingredients too large; incorrect blade/disc.	Process in smaller batches. Cut ingredients into uniform, smaller pieces. Ensure correct attachment is used.
Leakage from bowl/jar.	Lid not properly sealed; bowl/jar not correctly assembled; overfilled.	Ensure lid is securely locked. Reassemble bowl/jar correctly. Do not exceed maximum fill lines.

8. SPECIFICATIONS

Detailed technical specifications for the Black+Decker FX1075 Food Processor:

Feature	Detail
Brand	Black+Decker
Model Number	FX1075
Color	White/Grey
Power	1000 Watts
Voltage	240V
Material	Stainless Steel (Blades/Discs)
Number of Speeds	2 + Pulse
Food Processor Bowl Capacity	1.5 Liters (Total), 1.2 Liters (Working)
Blender Jar Capacity	1 Liter
Special Features	Safety Lock
Item Weight	3.97 Kilograms
Product Dimensions (DxWxH)	40.5 x 30 x 29.3 cm

9. WARRANTY AND SUPPORT

The Black+Decker FX1075 Food Processor comes with a two-year warranty from the date of purchase, covering manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims. For technical support, service, or warranty claims, please contact Black+Decker customer service through their official website or authorized service centers in your region. Do not attempt to repair the appliance yourself, as this will void the warranty.

For more information, visit the official Black+Decker website:www.blackanddecker.com

