

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OXELO](#) /

› [OXELO Kids' Scooter B1 500 - User Manual](#)

OXELO B1 500 (8502693)

OXELO Kids' Scooter B1 500 - User Manual

Model: B1 500 (8502693)

1. INTRODUCTION

Welcome to the user manual for your new OXELO Kids' Scooter B1 500. This scooter is designed to provide a fun and safe riding experience for children, promoting balance and coordination. Please read this manual thoroughly before assembly and use to ensure proper operation and safety.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in serious injury.

- Always wear a helmet, knee pads, and elbow pads when riding the scooter.
- Adult supervision is required at all times for young riders.
- Do not ride the scooter on public roads, near motor vehicles, or on steep inclines.
- Ride on smooth, paved surfaces away from traffic. Avoid water, sand, gravel, dirt, leaves, and other debris.
- Ensure all locking mechanisms and fasteners are securely tightened before each use.
- Do not exceed the maximum weight capacity (refer to specifications).
- Braking can cause the scooter to skid. Practice braking in a safe, open area.
- Check wheels and bearings regularly for wear and tear. Replace worn parts immediately.
- Keep fingers and other body parts clear of moving parts.

3. PRODUCT OVERVIEW

The OXELO B1 500 scooter features a stable three-wheel design, an adjustable handlebar, and a rear braking system for enhanced control and safety.



Figure 3.1: Overall view of the OXELO B1 500 Kids' Scooter, showcasing its blue and red color scheme and three-wheel design.



Figure 3.2: Side profile of the scooter, highlighting the low deck for easy foot placement and the rear wheel.



Figure 3.3: Front view of the scooter, showing the two front wheels and the handlebar.



Figure 3.4: Detail of the adjustable handlebar with ergonomic grips, designed for comfortable handling.



Figure 3.5: View of the rear wheel and the integrated foot brake mechanism.



Figure 3.6: Top-down perspective of the scooter's deck, showing the wide foot platform.



Figure 3.7: Detail of the light-up wheels, which illuminate during motion for added fun and visibility.

4. SETUP AND ASSEMBLY

The OXELO B1 500 scooter is designed for quick and easy assembly.

- 1. Unpack:** Carefully remove all components from the packaging. Ensure all parts are present: scooter deck with wheels, handlebar stem.
- 2. Attach Handlebar:** Insert the handlebar stem into the opening on the front of the scooter deck. Push down firmly until it clicks into place. Ensure the locking mechanism engages securely.
- 3. Adjust Handlebar Height:** Locate the height adjustment clamp on the handlebar stem. Open the clamp, adjust the handlebar to the desired height (ensure it's appropriate for the rider's height, typically hip-level), and securely close the clamp. Ensure the handlebar is firmly locked and does not wobble.
- 4. Final Check:** Before first use, double-check all connections, bolts, and the handlebar locking mechanism to ensure

they are tight and secure.

5. OPERATING INSTRUCTIONS

5.1 Riding the Scooter

- Place one foot firmly on the scooter deck.
- Use the other foot to push off the ground, gaining momentum.
- Once moving, place both feet on the deck, one behind the other.
- **Steering:** The B1 500 uses a lean-to-steer mechanism. To turn, lean your body in the direction you wish to go. The front wheels will pivot accordingly.

5.2 Braking

- To slow down or stop, gently press your heel down on the rear fender brake located above the back wheel.
- Apply gradual pressure to avoid sudden stops or skidding.
- Practice braking at low speeds in a safe area before riding faster.

6. MAINTENANCE

Regular maintenance will extend the life of your scooter and ensure safe operation.

- **Cleaning:** Wipe the scooter with a damp cloth to remove dirt and dust. Do not use harsh chemicals or abrasive cleaners. Avoid direct water spray on bearings.
- **Wheels and Bearings:** Regularly check the wheels for wear and tear. If the wheels do not spin freely, the bearings may need cleaning or replacement. Avoid riding through water or sand, as this can damage bearings.
- **Fasteners:** Periodically check all bolts, nuts, and screws to ensure they are tight. Over time, vibrations can loosen fasteners.
- **Storage:** Store the scooter in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|----------------------------|--|---|
| Handlebar is wobbly. | Height adjustment clamp is loose. | Open clamp, ensure handlebar is fully inserted and aligned, then close clamp securely. |
| Wheels do not spin freely. | Dirt/debris in bearings, or worn bearings. | Clean wheels and bearings. If problem persists, bearings may need replacement. |
| Brake is not effective. | Brake mechanism is worn or misaligned. | Inspect the brake for wear. Ensure it makes full contact with the wheel. Contact support if worn. |

8. SPECIFICATIONS

| Feature | Detail |
|---------|--------|
| Brand | OXELO |

| Feature | Detail |
|-----------------------|---|
| Model Name | B1 500 |
| Item Model Number | 8502693 |
| Colour | Blue/Red |
| Number of Wheels | 3 |
| Wheel Material | Polyurethane |
| Frame Material | Aluminium |
| Handlebar Type | Adjustable |
| Handle Height | Up to 13.8 Centimetres (adjustable range) |
| Brake Style | Rear Braking |
| Recommended Age Range | Designed for young children (Note: "Adult" in some specifications may refer to supervision) |

9. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact OXELO customer service or refer to the official OXELO website. Keep your proof of purchase for warranty claims.

Manufacturer: DECATHLON