

[manuals.plus](#) /› [ANENG](#) /› [ANENG V7 Digital Multimeter Instruction Manual](#)

ANENG V7

ANENG V7 Digital Multimeter Instruction Manual

Model: V7

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of the ANENG V7 Digital Multimeter. The ANENG V7 is a versatile, high-accuracy digital multimeter featuring a 6000-count HD LCD display with backlight, making readings clear in various lighting conditions. It offers a wide range of measurements including AC/DC voltage, AC/DC current, resistance, capacitance, frequency, temperature, diode, and continuity. Key advantages include True RMS measurement, auto-ranging, non-contact voltage (NCV) detection, data hold, backlight, and auto power-off, making it a reliable tool for electrical testing in various environments.

2. SAFETY INFORMATION

WARNING: To avoid possible electric shock, fire, or personal injury, please read all safety information before using the product.

- Always ensure the multimeter is in the correct function and range before making measurements.
- Do not apply more than the rated voltage, as marked on the meter, between the terminals or between any terminal and earth ground.
- Use caution when working with voltages above 30V AC RMS, 42V peak, or 60V DC. These voltages pose a shock hazard.
- Before measuring current, ensure the circuit is de-energized and the meter is connected in series with the load.
- Never measure resistance, continuity, or diode on a live circuit.
- Inspect test leads for damaged insulation or exposed metal before use. Replace if damaged.
- Do not operate the meter if it appears damaged or if the case is open.
- Remove test leads from the meter before opening the battery cover or fuse cover.
- Replace the battery as soon as the low battery indicator appears to ensure accurate readings.
- Adhere to local and national safety codes.

3. PRODUCT OVERVIEW

The ANENG V7 Digital Multimeter is designed for ease of use and reliability. Below is an overview of its main components and display features.



Figure 3.1: Front view of the ANENG V7 Digital Multimeter, showing the display, rotary dial, and input jacks.

PANEL DISPLAY



Figure 3.2: Detailed view of the multimeter's panel display, indicating various measurement functions and indicators such as capacitance, resistance, on-off detection, temperature, DC/AC voltage, and current.

MAX/MIN: maximum and minimum values,

REL: relative value measurement

SELECT: function switching

NCV:Non-contact detection

Flashlight:Back flashlight

HOLD: data retention/ Screen brightness



Figure 3.3: Explanation of button functions including MAX/MIN for maximum and minimum values, REL for relative value measurement, SELECT for function switching, NCV for non-contact detection, Flashlight, and HOLD for data retention/screen brightness.



Figure 3.4: Side view of the multimeter highlighting physical features such as the test line pen slot, a hole for hanging on a wall, and the integrated flashlight.

4. SETUP

4.1 Battery Installation

The ANENG V7 Multimeter typically uses standard batteries (e.g., AA or 9V, check the battery compartment for specifics). To install or replace batteries:

1. Ensure the multimeter is turned OFF and disconnect all test leads from the input terminals.
2. Locate the battery compartment cover on the back of the unit.
3. Use a screwdriver to open the battery compartment.
4. Insert new batteries, observing the correct polarity (+ and -).
5. Replace the battery compartment cover and secure it with the screw.

4.2 Connecting Test Leads

Always connect the black test lead to the "COM" (common) jack. Connect the red test lead to the appropriate

input jack based on the measurement you intend to make:

- For Voltage, Resistance, Capacitance, Frequency, Diode, Continuity, and Temperature measurements: Connect the red lead to the "VΩHz-II+" jack.
- For Current (mA/µA) measurements: Connect the red lead to the "mAµA" jack.
- For High Current (A) measurements: Connect the red lead to the "20A" jack.

5. OPERATING INSTRUCTIONS

The ANENG V7 features both auto-ranging and manual mode capabilities. The intelligent recognition function simplifies operation for common measurements.



Figure 5.1: The intelligent anti-burn feature with smart recognition helps prevent damage from incorrect settings, especially when the rotary dial is set to 'AUTO'.

5.1 Basic Measurement Steps

1. Turn the rotary dial to the desired function (e.g., V~ for AC Voltage, V- for DC Voltage, Ω for Resistance, etc.). For most common measurements, the "AUTO" setting will automatically detect the type of measurement.
2. Connect the test leads to the circuit or component you wish to measure, ensuring correct polarity and

connection points.

3. Read the measurement value on the LCD display.
4. After measurement, disconnect the test leads from the circuit, then from the multimeter.
5. Turn the rotary dial to "OFF" when not in use to conserve battery life.

5.2 Specific Measurement Functions

- **DC/AC Voltage Measurement (V-, V~):**

Set the rotary dial to V- (DC) or V~ (AC) or AUTO. Connect test leads in parallel to the circuit. The meter will display the voltage value.

- **DC/AC Current Measurement (A, mA, μ A):**

Set the rotary dial to the appropriate current range (A, mA, or μ A). Connect the meter in series with the circuit. Ensure the circuit is de-energized before connecting the meter.

- **Resistance Measurement (Ω):**

Set the rotary dial to Ω or AUTO. Ensure the circuit is de-energized. Connect test leads across the component. The meter will display the resistance value.

- **Capacitance Measurement (F):**

Set the rotary dial to F or AUTO. Ensure the capacitor is discharged before measurement. Connect test leads across the capacitor terminals.

- **Frequency Measurement (Hz):**

Set the rotary dial to Hz or AUTO. Connect test leads to the signal source. The meter will display the frequency.

- **Diode Test (\rightarrow |):**

Set the rotary dial to the diode symbol. Connect the red lead to the anode and the black lead to the cathode. The meter displays the forward voltage drop.

- **Continuity Test (|):**

Set the rotary dial to the continuity symbol. Connect test leads across the circuit or component. A built-in buzzer will sound if the resistance is below a certain threshold (typically $<50\Omega$).

- **Temperature Measurement ($^{\circ}\text{C}/^{\circ}\text{F}$):**

Set the rotary dial to TEMP. Connect the temperature probe (thermocouple) to the input jacks. Place the probe on the object to be measured.

- **Non-Contact Voltage (NCV) Detection:**

Set the rotary dial to NCV. Bring the top of the meter near a live AC voltage source. The meter will indicate the presence of AC voltage through an audible beep and/or visual indicator.

TEST SHOWS




Figure 5.2: Examples of various measurements being performed with the ANENG V7 Multimeter, including intelligent identification, capacitance, battery, and temperature measurements.

5.3 Special Functions

- **Data Hold (HOLD):** Press the "HOLD" button to freeze the current reading on the display. Press again to release.
- **Backlight/Flashlight:** The meter features a backlight for the display and an integrated flashlight for illuminating the work area. Refer to Figure 3.4 for flashlight location.
- **MAX/MIN:** Press the "MAX/MIN" button to record the maximum and minimum values during a measurement session.
- **REL (Relative Value Measurement):** This function allows you to measure a value relative to a stored reference value.
- **Auto Power Off:** To conserve battery, the meter will automatically power off after a period of inactivity.

6. MAINTENANCE

6.1 Cleaning

Wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents. Keep the input terminals free of dirt and moisture.

6.2 Battery Replacement

When the low battery indicator appears on the display, replace the batteries immediately to ensure accurate readings. Refer to Section 4.1 for battery installation instructions.

6.3 Fuse Replacement

If the current measurement function stops working, the fuse may need replacement. Refer to the specifications for the correct fuse type and rating. Fuse replacement should only be performed by qualified personnel.

7. TROUBLESHOOTING

- **No Display / Power On Issue:**

Check battery installation and ensure batteries are not depleted. Replace if necessary. Ensure the rotary dial is not in the "OFF" position.

- **Incorrect Readings:**

Verify the correct function and range are selected. Check test lead connections. Ensure batteries are not low. Calibrate if necessary (advanced users only).

- **Current Measurement Not Working:**

Check if the fuse for the current input is blown. Replace if necessary (refer to Section 6.3).

- **Continuity Buzzer Not Sounding:**

Ensure the circuit is de-energized. Check for open circuits or high resistance. The buzzer typically activates for resistance below 50Ω.

8. SPECIFICATIONS

ANENG V7 Digital Multimeter Specifications

Feature	Specification
Display	6000 Counts
DC Voltage	600mV/6.000V/60.00V/600.0V/1000V
AC Voltage	600mV/6.000V/60.00V/600.0V/750V
DC Current	600µA/6.000mA/60.00mA/600.0mA/6.000A/20.00A
AC Current	600µA/6.000mA/60.00mA/600.0mA/6.000A/20.00A
Temperature	-20°C to 1000°C / -4°F to 1832°F
Capacitance	9.999nF/99.99nF/999.9nF/9.999µF/99.99µF/999.9µF/9.999mF
Resistance	600.0Ω/6.000kΩ/60.00kΩ/600.0kΩ/6.000MΩ/60.00MΩ
Frequency	9.999Hz/99.99Hz/999.9Hz/9.999kHz/99.99kHz/999.9kHz/9.999MHz
Ranging	Auto
Material	ABS/PVC

Feature	Specification
Update Rate	3 times/second
True RMS	Yes
Data Hold	Yes
Backlight/Flashlight	Yes
Low Battery Alert	Yes
Auto Power Off	Yes
Model Number	V7
UPC	630282714434

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the seller directly. The manufacturer, ANENG, typically provides support for their products. Keep your purchase receipt as proof of purchase for any warranty claims.