

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Technicolor](#) /
- › [Technicolor DOCSIS 3.1 Cable Modem E31T2V1 Instruction Manual](#)

Technicolor E31T2V1

Technicolor DOCSIS 3.1 Cable Modem E31T2V1 Instruction Manual

Model: E31T2V1 | Brand: Technicolor

1. INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Technicolor DOCSIS 3.1 Cable Modem, model E31T2V1. This device is designed to deliver high-speed internet and voice services over your cable network. Please read these instructions carefully before setting up your modem to ensure optimal performance and safety.

2. PRODUCT OVERVIEW

The Technicolor E31T2V1 is a DOCSIS 3.1 certified cable modem, engineered for reliable and fast internet connectivity. It features a robust design and essential ports for connecting to your home network and voice services.



Image: Technicolor DOCSIS 3.1 Cable Modem E31T2V1 shown with its power adapter. The modem is black with a textured, perforated side panel, designed for vertical placement. The power adapter is also black with a standard US plug.

Key Features:

- **DOCSIS 3.1 Certified:** Supports the latest cable internet standard for high-speed data transfer.
- **Voice Service Support:** Includes 2 x RJ-11 ports for voice services, compatible with 1.5 (NCS) or 2.0 (IMS/SIP) standards.
- **Gigabit Ethernet Port:** Equipped with 1 x GB RJ-45 port for high-speed wired connections to a router or computer.
- **F-Connector:** Standard female F-connector for coaxial cable input.
- **Compact Design:** Black, sleek design suitable for various home or office environments.

3. SETUP

Follow these steps to set up your Technicolor E31T2V1 cable modem:

1. **Connect Coaxial Cable:** Connect one end of the coaxial cable (not included) to the F-connector on the back of the modem and the other end to your cable wall outlet. Ensure the connection is finger-tight.
2. **Connect Ethernet Cable:** Connect one end of an Ethernet cable (not included) to the GB RJ-45 port on the back of the modem. Connect the other end to the WAN (Internet) port of your Wi-Fi router or directly to your computer's Ethernet port.
3. **Connect Voice Lines (Optional):** If you subscribe to voice services, connect your telephone(s) to the RJ-11 ports on the back of the modem using standard telephone cables.
4. **Connect Power Adapter:** Plug the power adapter into the modem's power port and then into an electrical outlet. The modem will begin its startup sequence.
5. **Activate Service:** Once the modem's indicator lights stabilize (Power and Connected lights should be solid), contact your Internet Service Provider (ISP) to activate your new modem. You will need the modem's MAC address, usually found on a label on the device.

4. OPERATING

The Technicolor E31T2V1 modem features indicator lights on its front panel to show its operational status:

- **Power Light:** Indicates the modem is powered on.
- **Connected Light:** Indicates a successful connection to your ISP's network.

A solid light typically indicates a stable connection, while a blinking light may indicate an ongoing connection process or an issue. Refer to your ISP's documentation for specific light behavior interpretations.

5. MAINTENANCE

To ensure the longevity and optimal performance of your modem:

- **Placement:** Place the modem in a well-ventilated area, away from direct sunlight, heat sources, and moisture.
- **Cleaning:** Keep the modem clean and free of dust. Use a soft, dry cloth for cleaning. Avoid using liquid or aerosol cleaners.
- **Power Cycle:** If you experience connectivity issues, try power cycling the modem by unplugging it from the power outlet for 30 seconds and then plugging it back in.

6. TROUBLESHOOTING

If you encounter problems with your modem, try the following:

- **No Internet Connection:**

- Check all cable connections (coaxial, Ethernet, power) to ensure they are secure.
- Power cycle the modem and your router.
- Verify that your service is active with your ISP.

- **Slow Internet Speed:**

- Ensure your computer or router is capable of supporting high speeds.
- Temporarily connect a computer directly to the modem via Ethernet to rule out router issues.
- Contact your ISP to check your service plan and line quality.

- **Voice Service Issues:**

- Check telephone cable connections to the RJ-11 ports.
- Ensure your voice service is activated with your ISP.

If problems persist, contact your Internet Service Provider for further assistance.

7. SPECIFICATIONS

Feature	Detail
Model	E31T2V1
Brand	Technicolor
DOCSIS Standard	3.1 Certified
Cable Connector	F-Connector, female
Ethernet Ports	1 x GB RJ-45 port
Voice Ports	2 x RJ-11 ports
Voice Compatibility	1.5 (NCS) or 2.0 (IMS/SIP) compatible
Connectivity Technology	Ethernet
Compatible Devices	Personal Computer, Router, Laptop
Color	Black
Item Weight	1 pounds
Package Dimensions	11.26 x 7.8 x 6.1 inches
Date First Available	October 26, 2019

8. WARRANTY AND SUPPORT

This Technicolor modem is covered by the manufacturer's standard warranty. For specific warranty details, please refer to the documentation included with your product or visit the Technicolor website. For technical support, troubleshooting, or service activation, please contact your Internet Service Provider directly.

