

Knowtek UVR6

Knowtek UVR6 Automatic Voltage Regulator Instruction Manual

INTRODUCTION

The Knowtek UVR6 is an advanced electronic automatic voltage regulator (AVR) designed to ensure optimal performance of brushless alternators during both operation and startup. It incorporates a comprehensive protection system to safeguard the machine from potentially hazardous operating conditions. This regulator is suitable for use with all alternators and is a standard component for power outputs equal to or exceeding 85 KVA, supporting both three-phase and single-phase applications.

The UVR6 utilizes modern solid-state integrated circuit technology, selected for maximum durability and reliability. The entire unit is housed within a compact, resin-impregnated box, providing protection against vibrations and water ingress.

KEY FEATURES

- Advanced electronic design for excellent alternator performance during running and starting.
- Integrated protection system against dangerous operating conditions.
- Compatible with all alternators, standard for power outputs above or equal to 85 KVA (both three-phase and single-phase).
- Utilizes modern solid-state integrated circuit technology for durability and reliability.
- Compact, resin-impregnated housing for protection against vibrations and water.

SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of the UVR6 Automatic Voltage Regulator. Always ensure the generator is completely shut down and isolated from all power sources before beginning installation.

Mounting

Securely mount the UVR6 in a location that is protected from excessive vibration, moisture, and extreme temperatures. Ensure adequate ventilation around the unit to prevent overheating. Use appropriate fasteners to

firmly attach the regulator to a stable surface.

Wiring Connections

Connect the UVR6 according to the specific wiring diagram provided with your generator and the regulator itself. The main connections include:

- **Sensing Voltage Input:** Connect to the generator's output terminals (220-480V AC).
- **Power Input:** Connect to the auxiliary winding or a suitable power source (50-280V AC).
- **Exciter Field Output:** Connect to the exciter field of the alternator.

Ensure all connections are tight, properly insulated, and free from corrosion. Incorrect wiring can lead to damage to the AVR or the generator.

Frequency Selection

Verify that the frequency setting on the UVR6 (if adjustable) matches the nominal operating frequency of your generator (50Hz or 60Hz).



Figure 1: Top-down view of the UVR6 circuit board, illustrating the layout of components and connection points.




Figure 2: Side view of the UVR6, showing the accessible terminal blocks for wiring.

OPERATING INSTRUCTIONS

Once the UVR6 is correctly installed and wired, follow these general operating guidelines:

Initial Startup

Before starting the generator, perform a final check of all wiring connections to ensure they are secure. Start the generator according to its manufacturer's instructions.

Voltage Adjustment

The UVR6 typically features potentiometers for fine-tuning the output voltage. Refer to your generator's specific manual for the recommended initial voltage setting procedures. Adjust the voltage gradually to the desired level.

Stability Adjustment

If your UVR6 model includes stability controls, adjust them to prevent voltage oscillations or instability, especially under varying load conditions. This adjustment helps maintain a smooth and consistent output.

Monitoring

Regularly monitor the generator's output voltage using a voltmeter to ensure it remains within the specified operational limits. Any significant deviation may indicate an issue requiring attention.

MAINTENANCE

The UVR6 is designed for reliability, but periodic maintenance checks can extend its lifespan and ensure continued optimal performance.

- **Regular Inspection:** Periodically inspect the AVR for any visible signs of damage, loose connections, or excessive dust accumulation.
- **Cleaning:** Keep the AVR clean and free from dust and debris. Use a soft, dry cloth for cleaning. Avoid using liquid cleaners or solvents, which can damage electronic components.
- **Connection Checks:** Ensure all electrical connections remain tight and free from corrosion. Loose connections can lead to intermittent operation or damage.

TROUBLESHOOTING

If you encounter issues with your generator's voltage regulation, consider the following common troubleshooting steps:

- **No Voltage Output:**
 - Check the sensing voltage input and power input connections.
 - Verify the exciter field connections.
 - Inspect the AVR's internal fuse (if accessible and present) for continuity.
- **Unstable Voltage:**
 - Check for loose wiring connections or poor grounding.
 - Ensure the stability adjustment potentiometer (if present) is correctly set.
 - Verify that the engine governing system is stable and not fluctuating.
- **Over-voltage or Under-voltage:**
 - Re-check the voltage adjustment settings on the AVR.
 - Investigate if there are external load issues or problems with the generator's main windings.
- **Protection System Activation:**
 - If the AVR shuts down or indicates a fault, identify the cause (e.g., over-excitation, over-current, short circuit).
 - Rectify the underlying issue before attempting to restart the generator.

If problems persist after performing these checks, it is recommended to consult a qualified technician or contact Knowtek customer support.

SPECIFICATIONS

Parameter	Value
Sensing Voltage Input	220-480V AC
Voltage Input	50-280V AC
Frequency	50-60Hz nominal
Voltage Output	Max 63V DC at 220V AC input
Current (Continuous)	6A

Current (Intermittent)	7A for 10 seconds
Resistance	10 Ω minimum
Voltage Regulation	$\pm 1.0\%$ with 4% engine governing
Type	Brushless
Package Dimensions	6.69 x 5.91 x 2.76 inches
Item Weight	1.32 pounds
Model Number	UVR6



Figure 3: Bottom view of the UVR6 casing, often containing essential wiring diagrams and regulatory information.

WARRANTY AND SUPPORT

For detailed warranty information, technical assistance, or to report any issues with your Knowtek UVR6 Automatic Voltage Regulator, please contact Knowtek customer service directly. Refer to the official Knowtek website or your purchase documentation for contact details and support resources.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question