

## Philips HR7320/00

# Philips HR7320/00 Food Processor User Manual

Model: HR7320/00

## 1. IMPORTANT SAFETY INFORMATION

---

Please read this user manual carefully before using the appliance and save it for future reference. Incorrect use can lead to potential hazards.

- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling, or cleaning.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Do not immerse the motor unit in water or any other liquid, nor rinse it under the tap. Use only a damp cloth to clean the motor unit.
- Be careful when handling the sharp cutting blades and discs, especially when removing them from the bowl, emptying the bowl, and during cleaning.
- Never use your fingers or an object to push ingredients into the feeding tube while the appliance is running. Always use the pusher provided.
- Ensure the appliance is placed on a stable, flat, and dry surface during use.

## 2. PRODUCT OVERVIEW

---

The Philips HR7320/00 Food Processor is designed for versatile food preparation with its powerful 700W motor and various accessories.



This image displays the Philips HR7320/00 Food Processor, featuring its compact motor base, a transparent processing bowl with a lid, and a pusher. The front panel shows the control dial for speed selection and the Philips logo.

### Main Components:

- **Motor Unit:** The base containing the 700W motor and control dial.
- **Processing Bowl:** A 2.1L transparent bowl for processing ingredients.
- **Lid with Feeding Tube:** Covers the processing bowl and allows ingredients to be added.
- **Pusher:** Used to guide ingredients through the feeding tube.
- **S-Blade:** For chopping, mincing, and pureeing.
- **2-in-1 Stainless Steel Disc:** For slicing and shredding.

- **Blender Jar (Optional Accessory):** For blending liquids and soft ingredients.



This image showcases the Philips HR7320/00 Food Processor alongside its accessories, including a blender jar, a 2-in-1 stainless steel disc for slicing and shredding, and a kneading tool. The main unit is shown with ingredients being processed in the bowl.

### 3. SETUP AND ASSEMBLY

---

Follow these steps for initial setup and assembly before first use.

1. **Unpack:** Carefully remove all parts from the packaging.
2. **Clean:** Wash all detachable parts (bowl, lid, blades, discs) in warm soapy water or in a dishwasher.

Wipe the motor unit with a damp cloth. Ensure all parts are dry before assembly.

3. **Place Motor Unit:** Position the motor unit on a stable, flat, and dry surface.
4. **Attach Bowl:** Place the processing bowl onto the motor unit. Turn it clockwise until it locks into place.
5. **Insert Accessory:** Depending on your task, insert the S-blade or the desired disc onto the drive shaft in the bowl.
6. **Secure Lid:** Place the lid onto the processing bowl. Turn it clockwise until it locks into place. The appliance will not operate if the bowl and lid are not correctly locked.
7. **Insert Pusher:** Place the pusher into the feeding tube of the lid.

## 4. OPERATING INSTRUCTIONS

---

The Philips HR7320/00 Food Processor offers over 19 functions for various food preparation tasks.

### General Operation:

1. Ensure the appliance is correctly assembled and locked.
2. Plug the appliance into a power outlet.
3. Add ingredients to the processing bowl or feeding tube. The large filling opening minimizes pre-cutting.
4. Select the desired speed using the control dial. The color-coded speed guide helps match the speed to the accessory for optimal results.
5. For continuous operation, turn the dial to the desired speed (1, 2, or 3). For pulse function, turn the dial to 'P' and hold briefly.
6. After processing, turn the control dial to '0' and unplug the appliance.
7. Unlock the lid and then the bowl to remove processed food.



This image demonstrates the use of the Philips HR7320/00 Food Processor, showing a hand guiding ingredients like zucchini and cabbage through the large feeding tube into the processing bowl, emphasizing the minimal pre-cutting required.

## Specific Functions:

- **Chopping/Mincing:** Use the S-blade for vegetables, meat, nuts. Use pulse function for coarse chopping, continuous for finer results.
- **Pureeing:** Use the S-blade for making purees, sauces, or baby food.
- **Slicing/Shredding:** Use the 2-in-1 stainless steel disc. Place ingredients in the feeding tube and use the pusher.
- **Blending:** If using the blender attachment, follow its specific assembly instructions. Ideal for smoothies, soups, and sauces.

## 5. MAINTENANCE AND CLEANING

---

Proper cleaning ensures the longevity and hygiene of your food processor. All detachable accessories are dishwasher safe.

### Cleaning Steps:

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Disassemble:** Carefully disassemble all detachable parts.
3. **Wash Detachable Parts:** Wash the processing bowl, lid, pusher, S-blade, and discs in warm water with a little washing-up liquid or in the dishwasher. Be extremely careful when handling the sharp blades and discs.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or rinse it under the tap.
5. **Dry:** Dry all parts thoroughly before storing or reassembling.



This image illustrates several components of the Philips HR7320/00 Food Processor, such as the processing bowl, lid, and discs, arranged in a dishwasher rack, highlighting their dishwasher-safe design for easy cleaning.

## 6. TROUBLESHOOTING

---

If you encounter issues with your food processor, refer to the following common problems and solutions.

- **Appliance does not switch on:**
  - Ensure the power cord is securely plugged into a working outlet.
  - Check if the processing bowl and lid are correctly assembled and locked into place. The appliance has a safety interlock system.
- **Motor stops during operation:**
  - The appliance might be overloaded. Turn off, unplug, remove some ingredients, and restart.
  - Check for any blockages around the blade or disc.
- **Ingredients are not processed evenly:**
  - Ensure you are not overfilling the bowl. Process in smaller batches if necessary.
  - For chopping, use the pulse function for better control over consistency.
  - Ensure the correct blade/disc is used for the task.
- **Loud noise or unusual smell:**
  - Turn off the appliance immediately and unplug it. Check for any foreign objects or damage to the blades/discs. If the issue persists, contact customer support.

## 7. SPECIFICATIONS

---

<b>Brand</b>	Philips
<b>Model Number</b>	HR7320/00
<b>Colour</b>	White
<b>Product Dimensions</b>	24.4 x 24.4 x 37.7 cm
<b>Item Weight</b>	1 kg
<b>Power/Wattage</b>	700 watts
<b>Voltage</b>	240 Volts
<b>Material</b>	ABS, SAN
<b>Number of Speeds</b>	3
<b>Special Feature</b>	Waterproof (referring to specific parts, not motor unit)
<b>Bowl Capacity</b>	2.1 Liters
<b>Recommended Uses</b>	Chop, Grind, Mix, Puree, Process wet ingredients
<b>Product Care Instructions</b>	Dishwasher Safe (for detachable parts)
<b>Included Components</b>	Lid, S-blade, 2-in-1 disc, Pusher (Blender jar optional)

## 8. WARRANTY AND SUPPORT

---

For warranty information, please refer to the warranty card included with your purchase or visit the official Philips website. If you require assistance, have questions, or need to report a fault, please contact Philips customer support.

You can find contact details for Philips customer support on their official website or in the documentation provided with your appliance.