

Knowtek SX440

Knowtek AVR SX440 Automatic Voltage Regulator Instruction Manual

Model: SX440

1. INTRODUCTION

This manual provides essential information for the safe and effective installation, operation, and maintenance of the Knowtek AVR SX440 Automatic Voltage Regulator. The SX440 is designed for brushless generators, functioning as a half-wave phase-controlled thyristor type AVR. It is an integral part of the generator's excitation system, ensuring stable voltage output.

2. PRODUCT OVERVIEW

2.1 Features

- Half-wave phase-controlled thyristor type Automatic Voltage Regulator (AVR).
- Integrated under-speed protection.
- Sensing loss protection features.
- Excitation power derived directly from generator terminals.
- Ensures positive voltage build-up from residual levels through efficient semiconductors.

2.2 Specifications

Parameter	Value
Item Model Number	SX440
Package Dimensions	7.48 x 5.63 x 2.24 inches
Item Weight	1.08 pounds
Manufacturer	KNOWTEK

2.3 Product Views




Figure 1: Top-down view of the Knowtek SX440 AVR, showcasing its main components and warning label.




Figure 2: Angled view of the SX440 AVR, highlighting the various connection terminals and adjustment potentiometers.



Figure 3: Bottom view of the SX440 AVR, showing the mounting points and model identification label.

3. SAFETY INFORMATION

WARNING! ELECTRIC SHOCK RISK!

Always observe the following safety precautions to prevent injury or damage to equipment:

- Installation and maintenance should only be performed by qualified personnel.
- Ensure the generator is completely shut down and disconnected from all power sources before attempting any installation, wiring, or maintenance.
- Do not touch live terminals or heatsinks when the generator is operating or connected to a power source.
- Verify all wiring connections are secure and correct according to the generator manufacturer's specifications and the AVR wiring diagram.
- Protect the AVR from moisture, dust, and extreme temperatures.

4. SETUP AND INSTALLATION

The Knowtek SX440 AVR is designed for integration into brushless generator systems. Proper installation is crucial for optimal performance and safety.

4.1 Mounting

1. Select a suitable location within the generator control panel or enclosure that is free from excessive vibration, heat, and moisture.
2. Ensure adequate ventilation around the AVR to prevent overheating.
3. Mount the AVR securely using appropriate fasteners through its designated mounting holes.

4.2 Wiring Connections

Refer to your generator's specific wiring diagram and the SX440 AVR's terminal markings for precise connections. General connections include:

- **Sensing Input:** Connect to the generator's main output terminals for voltage sensing.
- **Excitation Output:** Connect to the generator's exciter field windings.
- **Auxiliary Power Input:** If applicable, connect to a stable auxiliary power source.
- **Remote Voltage Adjust (Optional):** Connect a remote potentiometer if external voltage adjustment is desired.

Always double-check all connections for correct polarity and tightness before applying power.

5. OPERATING INSTRUCTIONS

Once installed and wired correctly, the SX440 AVR operates automatically to maintain a stable generator output voltage.

5.1 Initial Start-up and Voltage Adjustment

1. With the generator running at rated speed and no load, slowly increase the generator excitation until the desired output voltage is achieved.
2. The SX440 features internal potentiometers for fine-tuning voltage, stability, and under-speed protection settings. Adjust these carefully using a non-conductive tool.
3. If a remote voltage adjust potentiometer is connected, use it to make minor voltage adjustments during operation.

5.2 Under-Speed Protection (UFRO)

The SX440 includes an Under-Frequency Roll-Off (UFRO) circuit that reduces the generator output voltage proportionally with frequency below a preset threshold. This protects the generator from damage during low-speed operation. The UFRO setting can typically be adjusted via an internal potentiometer.

6. MAINTENANCE

The Knowtek SX440 AVR is designed for reliable operation with minimal maintenance. However, periodic checks can help ensure its longevity and performance.

- **Visual Inspection:** Regularly inspect the AVR for any signs of physical damage, loose connections, or discoloration

due to overheating.

- **Cleanliness:** Keep the AVR free from dust, dirt, and debris. Use a soft, dry brush or compressed air for cleaning.
- **Connection Integrity:** Periodically check all wiring connections to ensure they remain tight and free from corrosion.
- **Environmental Conditions:** Ensure the operating environment remains within the specified temperature and humidity ranges.

7. TROUBLESHOOTING

This section provides guidance for common issues. For complex problems, consult a qualified technician.

7.1 Common Issues and Solutions

Issue: Generator has no voltage output or low voltage.

Possible Causes:

- Incorrect wiring or loose connections.
- AVR failure.
- Generator residual magnetism loss.
- Under-speed condition (UFRO activated).

Solutions:

- Verify all wiring connections are secure and correct.
- Check the generator speed; ensure it is at or above the rated frequency.
- Attempt to flash the exciter field to restore residual magnetism (refer to generator manual).
- If the AVR is suspected to be faulty, professional diagnosis and replacement may be necessary.

Issue: Unstable or fluctuating voltage output.

Possible Causes:

- Incorrect stability (STAB) potentiometer setting on the AVR.
- Loose connections or poor grounding.
- Generator engine speed fluctuations.

Solutions:

- Adjust the STAB potentiometer on the AVR incrementally until stable voltage is achieved.
- Inspect all wiring for tightness and ensure proper grounding.
- Address any issues with the generator engine's speed governor.

8. WARRANTY AND SUPPORT

Specific warranty details for the Knowtek SX440 Automatic Voltage Regulator are not provided in the product information. Please refer to your purchase documentation or contact the seller directly for warranty terms and conditions.

For technical support or further assistance, please contact Knowtek customer service or visit the official Knowtek store on Amazon: [Knowtek Store](#).

© 2025 Knowtek. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question