

[Manuals.plus](#) /

› [i-Life](#) /

› i-Life Zed Note CX3 13.3-inch Convertible Laptop User Manual

i-Life Zed Note CX3

i-Life Zed Note CX3 13.3-inch Convertible Laptop User Manual

Model: Zed Note CX3

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your i-Life Zed Note CX3 13.3-inch Convertible Laptop. Please read this guide thoroughly before using your device to ensure optimal performance and longevity. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The i-Life Zed Note CX3 is a versatile 13.3-inch convertible laptop featuring a 360-degree hinge and a touchscreen display, allowing it to function as both a traditional laptop and a tablet. It is powered by an Intel Core i3 processor, 8GB of RAM, and a 256GB SSD, running on Windows 10.

2.1 Key Features

- 13.3-inch Full HD (1920x1080) Touchscreen Display
- 360-degree Convertible Design
- Intel Core i3-5005U Processor
- 8GB DDR3 RAM
- 256GB SSD Storage
- Integrated Intel HD Graphics 5500
- Windows 10 Home Operating System

2.2 Physical Components and Ports

Familiarize yourself with the various ports and components of your laptop.



Figure 1: The i-Life Zed Note CX3 laptop in stand mode, displaying the screen and visible side ports including USB and HDMI.

- **USB 3.0 Port:** For connecting high-speed USB devices.
- **USB Type-C Port:** For data transfer.
- **HDMI Port:** For connecting to external displays.
- **MicroSD Card Slot:** For expanding storage or transferring files.
- **Audio Jack:** For headphones or external speakers.
- **Power Input:** For connecting the AC adapter.
- **Webcam:** Integrated camera for video calls and conferencing.
- **Microphone:** Built-in for audio input.

3. SETUP

3.1 Initial Charging and Power On

1. Connect the provided AC adapter to the laptop's power input port and then to a power outlet.
2. Allow the laptop to charge for at least 30 minutes before initial use, or until the battery indicator shows sufficient charge.
3. Press the power button located on the side or top edge of the laptop to turn it on.

3.2 Windows 10 First-Time Setup

Upon first boot, you will be guided through the Windows 10 setup process. Follow the on-screen instructions to:

- Select your region and language.
- Connect to a Wi-Fi network.
- Accept the license terms.
- Create or sign in with a Microsoft account.
- Set up a PIN or password.
- Adjust privacy settings.

3.3 Connecting to Wi-Fi

During the initial setup, you will be prompted to connect to a wireless network. If you skip this step or need to

connect later:

1. Click the Wi-Fi icon in the taskbar (usually in the bottom-right corner).
2. Select your desired network from the list.
3. Click 'Connect' and enter the network security key (password) if prompted.

4. OPERATING INSTRUCTIONS

4.1 Using Convertible Modes

The Zed Note CX3 features a 360-degree hinge, allowing it to be used in various modes:

- **Laptop Mode:** Traditional laptop configuration for typing and productivity.
- **Tent Mode:** Fold the laptop into an inverted 'V' shape for media consumption or presentations.
- **Stand Mode:** Position the keyboard face down to use the screen as a display.
- **Tablet Mode:** Fold the screen completely back against the base for a tablet experience. Windows 10 will automatically suggest switching to Tablet Mode for optimized touch interaction.



Figure 2: The i-Life Zed Note CX3 laptop configured in tent mode, showcasing the Windows 10 operating system interface.

4.2 Touchscreen and Touchpad Usage

- **Touchscreen:** Use gestures similar to a smartphone or tablet for navigation, scrolling, and selecting items.
- **Touchpad:** Supports multi-touch gestures. Tap to click, two-finger scroll, pinch-to-zoom, and three-finger swipe for task view or desktop navigation.

4.3 Connecting External Devices

- **USB Devices:** Insert USB drives, mice, keyboards, or other peripherals into the available USB 3.0 or Type-C ports.
- **External Display:** Connect an HDMI cable from the laptop's HDMI port to an external monitor or TV. You may need to adjust display settings in Windows (right-click desktop > Display settings).
- **MicroSD Card:** Insert a MicroSD card into the dedicated slot for additional storage or file transfer.

5. MAINTENANCE

5.1 Cleaning the Device

- Use a soft, lint-free cloth slightly dampened with water or a screen cleaner to wipe the display.
- For the keyboard and chassis, use a soft, dry cloth. Avoid harsh chemicals or abrasive materials.
- Periodically use compressed air to clear dust from vents and ports.

5.2 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place if not used for extended periods, with the battery charged to about 50%.
- Use only the original or an approved replacement AC adapter.

5.3 Software Updates

Regularly check for and install Windows updates to ensure system stability, security, and performance. Go to **Settings > Update & Security > Windows Update**

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your i-Life Zed Note CX3.

6.1 No Power / Laptop Not Turning On

- Ensure the AC adapter is securely connected to both the laptop and a working power outlet.
- Verify the power outlet is functional by plugging in another device.
- Try a hard reset: Disconnect the AC adapter, press and hold the power button for 15-20 seconds, then reconnect and try to power on.

6.2 Wi-Fi Connectivity Issues

- Check if Wi-Fi is enabled in Windows (Settings > Network & Internet > Wi-Fi).
- Restart your router and modem.
- Forget the network and reconnect by entering the password again.
- Update your Wi-Fi drivers via Device Manager.

6.3 Slow Performance

- Close unnecessary applications running in the background.
- Check for and install any pending Windows updates.
- Run a disk cleanup and defragmentation (for HDD, not necessary for SSD).
- Scan for malware or viruses.
- Ensure your SSD has sufficient free space (at least 15-20%).

6.4 Touchscreen Not Responding

- Restart the laptop.
- Check Device Manager for any issues with the touchscreen driver. Try updating or reinstalling it.

- Ensure the screen is clean and free of debris.

7. SPECIFICATIONS

Detailed technical specifications for the i-Life Zed Note CX3 laptop.



The image shows a silver i-Life Zed Note CX3 laptop in a tent-like position. The screen displays the Windows 10 desktop with various app icons on the left and a blue background with the Windows logo in the center. The laptop has a sleek, modern design with a thin bezel and a visible hinge mechanism.



The Windows 10 logo is displayed in blue, featuring the four-pane window icon and the text "Windows 10" in a sans-serif font.



The Intel Core i3 inside logo is shown, featuring the Intel logo and the text "CORE i3 inside" in a blue and white color scheme.



13.3"
FHD



8 GB
RAM



256 GB
SSD



Touch
Screen

Figure 3: The i-Life Zed Note CX3 laptop highlighting its key features and specifications.

Feature	Specification
Brand	i-Life
Model Name	Zed Note CX3
Screen Size	13.3 Inches
Screen Resolution	1920 x 1080 Pixels (Full HD)
Processor	Intel Core i3-5005U (2.4 GHz, 2 Cores)
RAM Size	8 GB DDR3
Hard Drive Size	256 GB SSD

Graphics Coprocessor	Intel HD Graphics 5500 (Integrated)
Operating System	Windows 10 Home
Connectivity	Bluetooth, Wi-Fi (802.11a/b/g/n/ac)
Ports	1x USB 3.0, 1x USB Type-C, 1x HDMI, MicroSD Card Reader, Audio Jack
Special Features	Touch Screen, Convertible (360-degree hinge)
Battery Life (Average)	4 Hours (Lithium Ion, 37.5 Watt Hours)
Item Weight	1.5 Kilograms
Product Dimensions	30.7 x 21 x 1.5 cm

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official i-Life website. Keep your proof of purchase for warranty claims.

For general inquiries or further assistance, you may contact i-Life customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0854QKMFY>

More documents and user manuals: <https://manuals.plus/>