

SurTrack FD-8330

SurTrack TrakMotive CV Axle Shaft - FD-8330 User Manual

Model: FD-8330

INTRODUCTION

This manual provides essential information for the SurTrack TrakMotive CV Axle Shaft, Model FD-8330. It covers product overview, specifications, installation guidelines, function, maintenance, and troubleshooting to ensure proper use and longevity of your axle shaft. Please read this manual thoroughly before installation and operation.

PRODUCT OVERVIEW

The SurTrack TrakMotive CV Axle Shaft FD-8330 is a high-quality replacement component designed to transmit power from the vehicle's transmission to the wheels. It is engineered to meet or exceed OEM specifications for fit, form, and function, ensuring reliable performance.



Figure 1: The SurTrack TrakMotive CV Axle Shaft FD-8330, showcasing its complete assembly.

Key Features:

- Designed to exceed OEM quality in fit, form, and function.
- Constructed with high-quality materials for reliability and durability.
- Features precision machined and heat-treated components.
- Includes necessary attached hardware and grease (where applicable).



Figure 2: Detailed view of the CV Axle Shaft with key dimensions, including an overall compressed length of 27 5/16 inches, 27 splines on one end, and 35 splines on the other.




Figure 3: Exploded view highlighting key components and features such as premium neoprene dust boots, stainless steel clamps, precision machined solid steel heat-treated center shafts, high strength spring steel retaining clips, and precision rolled splines and threads. Also shown are precision machined and heat-treated cages, races, and bearings.

SPECIFICATIONS

Attribute	Detail
Manufacturer	SurTrack
Brand	SurTrack
Model	AAR CV Axle Shaft
Item Model Number	FD-8330
Item Weight	15.8 pounds
Product Dimensions	4 x 31 x 4 inches
Exterior	Machined
Manufacturer Part Number	FD-8330
ASIN	B085CKXZT2
Date First Available	March 2, 2020

SETUP AND INSTALLATION

Installation of a CV axle shaft requires specialized tools and automotive knowledge. It is highly recommended that installation be performed by a certified professional mechanic to ensure proper fitment, safety, and vehicle performance.

General Installation Considerations:

- Ensure the vehicle is properly supported on jack stands or a lift.
- Disconnect the battery before beginning work.
- Refer to your vehicle's specific service manual for detailed removal and installation procedures.
- Inspect surrounding components (e.g., wheel bearings, suspension parts) for wear and replace as necessary.
- Ensure all fasteners are torqued to the manufacturer's specifications.
- Verify that the new axle shaft is free from damage before installation.
- After installation, perform a test drive to confirm proper operation and check for any unusual noises or vibrations.

FUNCTION AND OPERATION

The Constant Velocity (CV) Axle Shaft is a critical component of your vehicle's drivetrain, particularly in front-wheel drive, all-wheel drive, and some rear-wheel drive independent suspension systems. Its primary function is to transmit torque from the transaxle or differential to the wheels, allowing them to rotate and propel the vehicle.

The "constant velocity" aspect refers to its ability to transfer power smoothly and efficiently, even when the suspension moves up and down, and the wheels turn left or right. This is achieved through the CV joints at each end of the shaft, which accommodate changes in angle and length without causing vibrations or power fluctuations.

MAINTENANCE

CV axle shafts are generally low-maintenance components. However, regular inspection is crucial for their longevity and safe vehicle operation.

Recommended Maintenance:

- **Regular Visual Inspection:** Periodically inspect the CV boots (the rubber bellows at each end of the axle) for cracks, tears, or signs of grease leakage. Damaged boots can lead to contamination of the CV joint with dirt and moisture, causing premature wear.
- **Listen for Noises:** Pay attention to any clicking, popping, or clunking noises, especially when turning or accelerating. These can be indicators of a failing CV joint.
- **Check for Vibrations:** Unusual vibrations during acceleration or at certain speeds might also indicate an issue with the axle shaft.
- **Professional Inspection:** Include CV axle inspection as part of your routine vehicle maintenance checks performed by a qualified mechanic.

TROUBLESHOOTING

If you experience issues that you suspect are related to your CV axle shaft, consult the following common symptoms and their potential causes. For complex issues, professional diagnosis and repair are recommended.

Symptom	Potential Cause
Clicking or popping noise when turning	Worn outer CV joint.
Clunking noise during acceleration or deceleration	Worn inner CV joint or loose axle nut.
Vibration during acceleration	Bent axle shaft, worn inner CV joint, or unbalanced tire/wheel.
Grease leaking from CV boot	Damaged or torn CV boot. This requires immediate attention to prevent joint failure.
Vehicle pulls to one side	While often alignment-related, a severely worn CV joint can contribute.

Note: Many of these symptoms can also be caused by other vehicle components. A thorough diagnosis by a qualified mechanic is always recommended.

WARRANTY AND SUPPORT

The SurTrack TrakMotive CV Axle Shaft FD-8330 comes with a **limited lifetime warranty**. This warranty typically covers defects in material and workmanship under normal use and service. For specific terms, conditions, and claim procedures, please refer to the official warranty documentation provided by SurTrack or contact their customer support.

Customer Support:

For technical assistance, warranty claims, or any product-related inquiries, please contact SurTrack customer service through their official website or the contact information provided with your purchase. When contacting support, please have your product model number (FD-8330) and purchase details readily available.

