

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Kalorik](#) /

› Kalorik AFO 46129 22 Quart Air Fryer Toaster Oven User Manual

Kalorik AFO 46129

Kalorik AFO 46129 22 Quart Air Fryer Toaster Oven User Manual

Model: AFO 46129

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Kalorik AFO 46129 22 Quart Air Fryer Toaster Oven. Please read all instructions thoroughly before first use and retain this manual for future reference.



Image: The Kalorik AFO 46129 Air Fryer Toaster Oven with its door open, revealing a roasted chicken and various vegetables on a baking pan inside. The control panel with three knobs is visible at the top.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any materials other than manufacturer's recommended accessories in this oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and similar products.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
- Extreme caution should be exercised when removing tray or disposing of hot grease.
- Always wear protective, insulated oven mitts when inserting or removing items from the hot oven.

PARTS AND FEATURES

Familiarize yourself with the components of your Kalorik Air Fryer Toaster Oven:

Control Panel: Features three chrome-plated knobs for function, temperature, and timer settings.



Image: A detailed view of the Kalerik Air Fryer Toaster Oven's control panel, showing the Power/Function knob (Air Fry, Broil, Bake, Toast), Temperature knob (250°F-450°F), and Timer knob (up to 60 minutes), along with Power and Heating indicator lights.

Glass Door: Allows for easy monitoring of cooking progress. Features an auto-shutoff safety feature.

Baking Pan: Used for baking, roasting, and catching drips.



Image: A black, rectangular baking pan, an accessory included with the Kalorik Air Fryer Toaster Oven.

Air Frying Basket: Designed for optimal air circulation during air frying.



Image: A silver, rectangular mesh basket, specifically designed for air frying, included with the Kalorik Air Fryer Toaster Oven.

Air Rack: A wire rack for general cooking and supporting other accessories.



Image: A silver wire rack, an accessory for the Kalorik Air Fryer Toaster Oven, used for various cooking methods.

Tray Handle: For safe insertion and removal of hot trays and racks.



Image: A black metal tray handle, designed to safely remove hot accessories from the Kalorik Air Fryer Toaster Oven.

Crumb Tray: Collects crumbs and drips for easy cleaning. Located at the bottom of the oven.

BEFORE FIRST USE

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wipe the exterior of the oven with a damp cloth.
3. Wash all accessories (baking pan, air frying basket, air rack, tray handle, crumb tray) in warm, soapy water. Rinse and dry thoroughly.
4. Place the oven on a stable, heat-resistant surface, ensuring adequate ventilation around all sides.
5. Plug the appliance into a standard electrical outlet.
6. To eliminate any manufacturing odors, operate the oven empty for approximately 15 minutes at 400°F (200°C) on the "Bake" setting. A slight odor or smoke is normal during this initial use.

SETUP

Ensure the appliance is placed on a flat, stable, heat-resistant surface with at least 4 inches of clearance on all sides for proper ventilation. Insert the crumb tray at the very bottom of the oven before placing any other accessories.

OPERATING INSTRUCTIONS

General Operation

1. Place food on the appropriate accessory (baking pan, air frying basket, or air rack).
2. Insert the accessory into the desired rack position inside the oven.
3. Close the glass door.
4. Turn the **Function** knob to select the desired cooking mode (Air Fry, Broil, Bake, Toast).
5. Turn the **Temperature** knob to set the desired temperature (250°F - 450°F).
6. Turn the **Timer** knob to set the desired cooking time (up to 60 minutes). The oven will begin heating. The "Heating" indicator light will illuminate.
7. When the timer reaches zero, the oven will automatically shut off and a bell will sound.
8. Carefully remove cooked food using the tray handle or oven mitts.

Air Frying

Use the air frying basket for best results when air frying. This method uses rapid hot air circulation to cook food with little to no oil.



Image: The Kalorik Air Fryer Toaster Oven with the air frying basket positioned inside, demonstrating its setup for air frying.

- Place food in the air frying basket. Do not overcrowd the basket to ensure even cooking.
- Insert the air frying basket into the middle or upper rack position.
- Select "Air Fry" function.
- Set temperature and time according to recipe or desired crispness.
- Shake or flip food halfway through cooking for optimal results.

Baking

The oven can be used for baking various items like cakes, cookies, and casseroles.

- Place food in the baking pan or an oven-safe dish on the air rack.
- Insert into the lower or middle rack position.
- Select "Bake" function.
- Set temperature and time as required by your recipe.

Toasting

Toast bread, bagels, and other items quickly and efficiently.

- Place items directly on the air rack.
- Insert into the middle rack position.
- Select "Toast" function.
- Adjust the temperature knob to control toast shade (higher temperature for darker toast).
- Set the timer for the desired toasting duration.

Broiling

Broiling is ideal for quick cooking and browning the tops of dishes.



Image: The Kalorik Air Fryer Toaster Oven with a pizza cooking on a rack inside, illustrating its baking or broiling capability.

- Place food on the baking pan or an oven-safe broiling pan.
- Insert into the upper rack position for best results.
- Select "Broil" function.
- Set the timer. Broiling often requires shorter cooking times and close monitoring to prevent burning.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. Always unplug the oven and allow it to cool completely before cleaning.
2. Remove the crumb tray, baking pan, air frying basket, and air rack. Wash these accessories in warm, soapy water. They are not dishwasher safe.
3. Wipe the interior walls of the oven with a damp cloth and mild detergent. Avoid abrasive cleaners or scouring pads.
4. Clean the exterior of the oven with a damp cloth. Do not immerse the oven in water.
5. Ensure all parts are completely dry before reassembling and storing the oven.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not functioning; timer not set.	Ensure the power cord is securely plugged into a working outlet. Turn the timer knob to the desired cooking time.
Food is not cooking evenly.	Overcrowding the basket/pan; incorrect temperature or time setting.	Do not overcrowd. Cook in smaller batches if necessary. Adjust temperature and time. Flip or shake food halfway through cooking.
White smoke coming from the oven.	Grease or food residue on heating elements or interior.	Unplug and allow to cool. Clean the interior and heating elements thoroughly. Ensure crumb tray is clean.
Food is not crispy when air frying.	Basket overcrowded; insufficient cooking time or temperature; too much moisture in food.	Reduce food quantity. Increase cooking time or temperature. Pat food dry before air frying.

SPECIFICATIONS

- Model:** AFO 46129
- Capacity:** 22 Quarts
- Color:** Black
- Material:** Stainless Steel (80% Stainless steel, 10% Plastics, 10% Electrical parts)
- Wattage:** 1800 watts
- Temperature Range:** 250°F - 450°F
- Timer:** Up to 60 minutes
- Control Method:** Knobs
- Air Frying Technology:** Rapid Air Circulation
- Item Weight:** 16.09 Pounds
- Dishwasher Safe:** No (for accessories)
- UPC:** 848052006935

CUSTOMER SUPPORT

For any questions, assistance, or warranty information regarding your Kalorik AFO 46129 Air Fryer Toaster Oven, please

contact Kalorik customer service. Refer to the product packaging or the official Kalorik website for current contact details.
Website: www.kalorik.com

© 2024 Kalorik. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B086BRG6D2>
More documents and user manuals: <https://manuals.plus/>