

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SKMEI](#) /
- › [SKMEI Digital Watch User Manual](#)

SKMEI SKM-1233-Camouflage Blue-F

SKMEI Digital Watch User Manual

Model: SKM-1233-Camouflage Blue-F

INTRODUCTION

Thank you for choosing the SKMEI Digital Watch. This manual provides detailed instructions on how to set up, operate, and maintain your watch. This multifunctional digital watch features time display, day and week display, 12/24 hour format, pedometer, calorie counter, distance tracking, alarm, stopwatch, EL backlight, and call/SMS reminders. Please read this manual carefully to ensure proper use and longevity of your device.



Image: Front view of the SKMEI Digital Watch, displaying time and various icons for its smart features.

COMPONENT IDENTIFICATION

Familiarize yourself with the buttons and display areas of your watch.



Image: Diagram illustrating the functions of each button and display area on the SKMEI Digital Watch. Key buttons include Light, Mode, Start, and Reset. Display elements show Date, Steps, Calorie, Distance, Alarm Clock, Stopwatch, Remote Camera, Call Remind, App Remind, Week, and Time.

- **Light Button:** Activates the EL backlight.
- **Mode Button:** Cycles through different modes (Time, Pedometer, Alarm, Stopwatch, Bluetooth).
- **Start Button:** Used to start/stop functions or increase values during setting.
- **Reset Button:** Used to reset functions or decrease values during setting.

SETUP

Initial Power On and Time Setting

1. **Power On:** The watch is typically pre-activated. If the display is off, press any button to activate it.
2. **Enter Time Setting Mode:** In Time Mode, press and hold the **Mode** button until the seconds begin to flash.
3. **Adjust Seconds:** Press the **Reset** button to reset seconds to 00.
4. **Select Next Value:** Press the **Mode** button to move to the next setting (e.g., hours, minutes, 12/24 hour format, year, month, day).
5. **Adjust Value:** Use the **Start** button to increase the flashing value.

6. **Save Settings:** Once all settings are adjusted, press the **Mode** button again to exit setting mode.

Connecting to Smartphone (Bluetooth)

To utilize smart functions like call/SMS reminders and activity tracking, connect your watch to your smartphone via Bluetooth.



Image: The SKMEI Digital Watch displayed next to a smartphone showing its companion application interface, indicating connectivity for smart features.

1. **Download App:** Scan the QR code in the watch's packaging or search for the official SKMEI app in your smartphone's app store (e.g., "SKMEI Smart Watch" or similar).
2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Open App:** Launch the downloaded app and follow the on-screen instructions to create an account or log in.
4. **Pair Device:** Within the app, navigate to the device pairing section. The app will search for available watches. Select "SKM-1233" or a similar identifier.
5. **Confirm Pairing:** Confirm the pairing request on both your phone and watch if prompted.
6. **Sync Data:** Once connected, the watch will sync time and activity data with the app.

OPERATING INSTRUCTIONS

Time Mode

This is the default display mode, showing current time, day, and week.

- Press the **Light** button to illuminate the display for a few seconds.
- Press the **Mode** button to cycle through other modes.

Pedometer and Activity Tracking Mode

The watch automatically tracks steps, distance, and calories burned.

1. From Time Mode, press the **Mode** button until you see the pedometer icon or step count display.
2. The watch will continuously record your activity.
3. To view detailed data or historical records, open the connected smartphone app.

Alarm Mode

1. From Time Mode, press the **Mode** button repeatedly until you reach the Alarm Mode (indicated by an alarm icon).
2. Press and hold the **Start** button to enter alarm setting mode. The hour digits will flash.
3. Use the **Start** button to adjust the hour.
4. Press the **Mode** button to move to minutes, then use the **Start** button to adjust.
5. Press the **Mode** button again to toggle alarm ON/OFF.
6. Press the **Mode** button to exit alarm setting.

Stopwatch Mode

1. From Time Mode, press the **Mode** button repeatedly until you reach the Stopwatch Mode.
2. Press the **Start** button to begin timing.
3. Press the **Start** button again to pause timing.
4. Press the **Reset** button to reset the stopwatch to zero.
5. To resume from a paused state, press the **Start** button.

Call/SMS Reminder

When connected to your smartphone via Bluetooth, the watch will vibrate and display an icon for incoming calls or messages (SMS, social media notifications).

- Ensure Bluetooth is active on both the watch and your phone.
- Ensure the SKMEI app is running in the background and has necessary notification permissions.
- The watch will provide a visual and vibratory alert for notifications.

MAINTENANCE

Water Resistance



Image: The SKMEI Digital Watch submerged partially in water, highlighting its 50M water resistance capability.

This watch is water resistant up to 50 meters (164 feet). This means it is suitable for daily use, hand washing, rain, and showering.

- **Do NOT** press any buttons while the watch is submerged in water.
- **Do NOT** expose the watch to hot water or steam (e.g., hot showers, saunas), as this can compromise the water seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.

Cleaning

Wipe the watch case and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

The watch uses a standard watch battery. When the display dims or functions become erratic, it may be time to replace the battery. It is recommended to have battery replacement performed by a qualified watch technician to ensure proper sealing and water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time not set correctly or watch was reset.	Re-set the time following the "Initial Power On and Time Setting" instructions.
Pedometer/Activity data is inaccurate.	Watch not worn correctly; app not synced; sensor interference.	Ensure watch is worn snugly on the wrist. Sync with the app regularly. Avoid strong magnetic fields. Note that stationary arm movements can sometimes be registered as steps.
No call/SMS reminders.	Bluetooth disconnected; app not running; notification permissions not granted.	Check Bluetooth connection. Ensure the SKMEI app is open and running in the background. Verify app notification permissions in your phone settings.
Buttons are unresponsive.	Watch might be in a locked state or internal malfunction.	Try pressing the Light button. If unresponsive, a battery replacement might be needed. If problem persists, contact support.

SPECIFICATIONS

Feature	Detail
Model Number	SKM-1233-Camouflage Blue-F
Movement Type	Japanese Quartz
Case Material	ABS
Band Material	Polyurethane (PU)
Water Resistance	50M (164ft) - Suitable for hand washing, rain, showering. Not for hot water/steam or diving.
Display Type	Digital with EL Backlight
Functions	Time, Day, Week, 12/24H, Pedometer, Calories, Distance, Alarm, Stopwatch, Call/SMS Reminder, Bluetooth Connectivity.
Case Diameter	2 Inches (approx. 5.08 cm)
Case Thickness	0.59 Inches (approx. 1.5 cm)
Band Width	0.87 Inches (approx. 2.2 cm)
Item Weight	145 g

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer.

For technical support or further assistance, please visit the official SKMEI website or contact their customer service department.

