

TUXING TXET061/TXET062

TUXING TXET061 and TXET062 Series PCP Air Compressor O-Ring and Seal Replacement Kit Instruction Manual

Essential guidance for maintaining your TUXING air compressor.

1. INTRODUCTION

This instruction manual provides detailed information for the proper use, installation, and maintenance of the TUXING O-ring and seal replacement kit for TXET061 and TXET062 series PCP air compressors. Adhering to these instructions will help ensure the longevity and optimal performance of your compressor.

2. PRODUCT OVERVIEW

The TUXING O-ring and seal replacement kit is designed to restore the sealing integrity and operational efficiency of your TXET061 or TXET062 series air compressor. Regular replacement of these components is crucial for maintaining high pressure and preventing air leaks.

2.1 Included Components

This kit typically includes a variety of essential components for compressor maintenance:

- Various sizes of O-rings (seal rings)
- Piston rings
- Fuses
- Springs and other small sealing components




Image 1: An assortment of O-rings, seals, and small components included in the TUXING replacement kit. These parts are crucial for maintaining the air-tightness and function of the compressor.



Image 2: A close-up view of the various O-rings, springs, and fuses that constitute the TUXING replacement kit. Each component plays a vital role in the compressor's sealing and electrical protection.

3. COMPATIBILITY

This replacement kit is specifically designed for TUXING TXET061 series and TXET062 series 12V PCP air compressors. Ensure your compressor model matches these specifications before attempting any replacements.

4. INSTALLATION AND REPLACEMENT

Replacing O-rings and seals requires careful attention to detail. It is recommended to consult your specific compressor's user manual for detailed disassembly and reassembly instructions. The following are general guidelines:

1. **Safety First:** Always ensure the compressor is disconnected from all power sources and depressurized before beginning any maintenance.
2. **Identify Worn Parts:** Carefully inspect existing O-rings and seals for signs of wear, cracking, or deformation.
3. **Disassembly:** Follow your compressor's manual to safely disassemble the relevant sections where seals need replacement. Keep track of all components and their original positions.
4. **Clean Surfaces:** Before installing new seals, thoroughly clean the grooves and mating surfaces to remove any debris or old lubricant.
5. **Lubrication:** Apply a thin layer of appropriate O-ring lubricant (compatible with your compressor's materials and operating conditions) to new O-rings before installation. This aids in seating and prevents damage during assembly.
6. **Proper Seating:** Ensure each O-ring and seal is correctly seated in its groove without twisting or pinching.

7. **Reassembly:** Reassemble the compressor components in reverse order of disassembly, ensuring all fasteners are tightened to the manufacturer's specifications.
8. **Testing:** After reassembly, perform a leak test at low pressure before operating the compressor at full capacity.

5. MAINTENANCE

Regular maintenance of your compressor's seals is vital for its performance and lifespan:

- **Periodic Inspection:** Routinely check O-rings and seals for wear, especially in high-stress areas.
- **Cleanliness:** Keep the compressor and its components clean to prevent dirt and debris from compromising seals.
- **Storage:** Store the compressor in a clean, dry environment away from extreme temperatures and direct sunlight, which can degrade rubber components.
- **Lubrication:** Use recommended lubricants for moving parts and seals as per your compressor's manual.

6. TROUBLESHOOTING COMMON ISSUES

If you experience issues after replacing seals, consider the following:

- **Air Leaks:** If air leaks persist, re-check the seating of all newly installed O-rings. Ensure no O-rings are pinched or twisted. Verify that the correct size O-ring was used for each location.
- **Reduced Pressure:** This could indicate an internal leak. Re-examine piston rings and internal seals for proper installation and condition.
- **Compressor Not Starting:** Check the fuse included in the kit. If the original fuse blew, replace it with the correct amperage fuse from the kit. Ensure all electrical connections are secure.
- **Unusual Noises:** Disassemble and inspect for any incorrectly assembled parts or foreign objects.

For complex issues, refer to your compressor's main instruction manual or contact TUXING customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	TUXING
Compatible Models	TXET061, TXET062 Series
Material	Plastic (for some components), Rubber (for O-rings/seals)
Item Weight	Approximately 0.317 ounces (0.01 Kilograms)
Product Dimensions	0.79 x 0.79 x 0.39 inches (packaging/overall kit)
Included Components	O-ring seal kits, ring seals, piston rings, fuse

8. SAFETY INFORMATION

Always prioritize safety when working with air compressors and their components:

- Disconnect power and depressurize the system before maintenance.
- Wear appropriate personal protective equipment (PPE), such as safety glasses.

- Ensure the work area is well-lit and free of obstructions.
- Do not modify the replacement parts or use them for purposes other than intended.
- Keep small parts out of reach of children.

9. WARRANTY AND SUPPORT

Specific warranty information for this replacement kit is not provided in the product details. For any product-related inquiries, technical support, or warranty claims, please refer to the original TUXING air compressor manual or contact TUXING customer service directly through their official channels.

You can often find support information on the [TUXING Brand Store on Amazon](#).

© 2025 TUXING. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question