

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Walfront](#) /

› [Walfront TA802A Pocket Pen Digital Multimeter User Manual](#)

## Walfront TA802A

# Walfront TA802A Pocket Pen Digital Multimeter User Manual

Model: TA802A

## 1. INTRODUCTION

The Walfront TA802A is a compact and intelligent pocket pen-type digital multimeter designed for accurate and stable electrical measurements. It features an auto-ranging function, a large rotatable LED display for enhanced readability, Non-Contact Voltage (NCV) detection, and a built-in flashlight for use in low-light conditions. This manual provides essential instructions for the safe and effective use of your device.



Figure 1: Walfront TA802A Pocket Pen Digital Multimeter with connected test leads.

## 2. SAFETY INFORMATION

Before using the multimeter, please read and understand all safety warnings and operating instructions. Failure to do so may result in injury or damage to the meter or equipment under test.

- Always ensure the test leads are in good condition and properly connected.
- Do not exceed the maximum input values specified for each measurement range.
- Exercise extreme caution when working with voltages above 30V AC RMS, 42V peak, or 60V DC. These voltages pose a shock hazard.
- Do not operate the meter if it appears damaged or if the case is open.
- Replace batteries immediately when the low battery indicator appears.

## 3. PRODUCT OVERVIEW

The TA802A is designed for portability and ease of use. Key components include the main unit, test leads, and a



## Bidirectional screen display, can be viewed from multiple angles




Figure 3: The bidirectional screen display can be rotated by long-pressing the screen button, enhancing readability.

## 4. SETUP

### 4.1 Battery Installation

The TA802A typically uses standard AAA batteries. To install or replace batteries:

1. Ensure the multimeter is powered off.
2. Locate the battery compartment cover on the back of the device.
3. Use a screwdriver (if necessary) to open the cover.
4. Insert new batteries, observing the correct polarity (+/-).
5. Securely close the battery compartment cover.

### 4.2 Connecting Test Leads

Connect the test leads to the appropriate input jacks on the multimeter. The black lead typically connects to the 'COM' (common) jack, and the red lead connects to the jack corresponding to the desired measurement function

(e.g., VΩHz for voltage, resistance, frequency).

## 5. OPERATING INSTRUCTIONS

The TA802A features an intelligent auto-ranging function, simplifying operation for various measurements.



Figure 4: The TA802A multimeter being used to measure components on a circuit board.

### 5.1 Power On/Off

Press the power button to turn the multimeter on or off. The device may also have an auto-power-off feature to conserve battery life.

### 5.2 Function Selection

Rotate the central dial to select the desired measurement function (e.g., Voltage, Resistance, Diode, Continuity, Frequency, NCV). The multimeter will automatically select the appropriate range for most measurements.

### 5.3 Non-Contact Voltage (NCV) Detection

To use the NCV function:

1. Select the NCV function on the dial.
2. Bring the tip of the multimeter close to the conductor or wire you wish to test.
3. The device will indicate the presence of AC voltage through visual (LED) and/or audible (beeper) signals. This function is useful for detecting live wires and identifying line break points.

## 5.4 Flashlight Function

The TA802A includes a flashlight at the pen tip. This feature is useful for illuminating work areas in dark environments. Refer to the device's specific buttons for activating the flashlight.

## 6. MAINTENANCE

### 6.1 Cleaning

Wipe the meter's case with a damp cloth and mild detergent. Do not use abrasives or solvents. Ensure the device is powered off and disconnected from any circuits before cleaning.

### 6.2 Battery Replacement

Refer to section 4.1 for battery replacement instructions. Always use the specified battery type.

### 6.3 Storage

When not in use for extended periods, remove the batteries to prevent leakage. Store the multimeter in a cool, dry place, away from direct sunlight and extreme temperatures.

## 7. TROUBLESHOOTING

- **No Display/Power:** Check battery installation and charge. Replace batteries if necessary. Ensure the power button is pressed correctly.
- **Incorrect Readings:** Verify that the correct function is selected for the measurement. Ensure test leads are properly connected and making good contact with the circuit. Check for damaged test leads.
- **NCV Not Detecting:** Ensure the NCV function is selected. The sensor needs to be in close proximity to a live AC voltage source.
- **Auto-Power Off:** This is a normal function to save battery. Press any button or rotate the dial to reactivate the meter.

## 8. SPECIFICATIONS

The following table outlines the general specifications for the Walfront TA802A Pocket Pen Digital Multimeter.



Figure 5: Dimensions of the Walfront TA802A Pocket Pen Digital Multimeter.

Feature	Specification
Model Number	TA802A (Manufacturer's internal: Walfrontygnfac3r8e)
Display	LED, 6000 Counts, True RMS, Bidirectional Rotation
Measurement Accuracy	High precision, intelligent auto-identification
Special Functions	NCV (Non-Contact Voltage) detection, Flashlight, Anti-burn protection
Portability	Compact, pen-type design
Origin	China
ASIN	B08BL8J7PP

## 9. WARRANTY AND SUPPORT

Information regarding specific warranty terms and customer support for the Walfront TA802A Pocket Pen Digital Multimeter was not available in the provided product data. Please refer to the product packaging or contact the seller directly for details on warranty coverage and technical support.