

[Manuals.plus](#) /

> [Aosom](#) /

> Aosom Youth Kick Scooter Instruction Manual (Model B08BN4LFN8)

## Aosom B08BN4LFN8

# Aosom Youth Kick Scooter Instruction Manual

Model: B08BN4LFN8

## 1. INTRODUCTION

Thank you for choosing the Aosom Youth Kick Scooter. This manual provides essential information for the safe assembly, operation, and maintenance of your scooter. Please read it thoroughly before first use and retain it for future reference. This scooter is designed for children aged 5 years and older, with a maximum load capacity of 220 lbs.

### Key Features:

- **Adjustable Handlebar:** The handlebar height can be adjusted from 34.75" to 37" to accommodate various user heights.
- **Safe Braking:** Equipped with a front and rear wheel dual braking system for reliable stopping power.
- **Durable Construction:** Features a sturdy steel frame and wear-resistant aluminum alloy wheels.
- **Inflatable Tires:** Inflatable, slip-resistant rubber wheels provide a smooth ride and long-term use.
- **Integrated Kickstand:** A convenient kickstand is included for easy parking.

## 2. SAFETY INFORMATION

Your safety is paramount. Always follow these guidelines to prevent injury:

- Always wear a helmet, knee pads, and elbow pads when riding the scooter.
- Adult supervision is recommended, especially for younger riders.
- Ensure all bolts, nuts, and quick-release mechanisms are securely tightened before each ride.
- Check brake functionality before each use.
- Ride on smooth, dry, paved surfaces away from traffic. Avoid riding on wet, uneven, or slippery surfaces.
- Do not ride at night or in low visibility conditions.
- Do not perform stunts or dangerous maneuvers.
- One rider at a time.
- Keep fingers and clothing away from moving parts.

## 3. SETUP AND ASSEMBLY

Assembly is required. Please follow these steps carefully. It is recommended to have two adults for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify all components are present according to the parts list (not provided in this manual, refer to your product packaging).

2. **Attach Front Wheel:** Secure the front wheel to the fork using the provided hardware. Ensure the wheel spins freely and is centered.
3. **Install Handlebar:** Insert the handlebar stem into the front fork tube. Adjust the handlebar to the desired height and tighten the quick-release clamp and any bolts securely. Ensure the handlebar is aligned with the front wheel.
4. **Connect Brakes:** Connect the brake cables to the brake levers on the handlebar. Adjust the brake calipers to ensure proper engagement with the wheels and smooth operation. The brake levers should be easily accessible and provide firm stopping power.
5. **Inflate Tires:** The scooter is equipped with inflatable tires. Inflate both the 16" front tire and 12" rear tire to the recommended pressure (usually indicated on the tire sidewall).
6. **Final Inspection:** Before first use, double-check all connections, bolts, and nuts to ensure they are tight and secure. Test the brakes and handlebar stability.



Image: Fully assembled Aosom Youth Kick Scooter.

# ADJUSTABLE HANDLEBAR HEIGHT




Image: Adjustable handlebar height feature.

## 4. OPERATING INSTRUCTIONS

### Riding the Scooter:

- Place one foot firmly on the foot deck.
- Use the other foot to push off the ground, generating momentum.
- Once moving, place both feet on the foot deck, one behind the other, or side-by-side if comfortable.
- Steer by gently turning the handlebars in the desired direction.

### Using the Brakes:

The scooter features dual hand brakes for effective stopping.

- To slow down or stop, gently squeeze both brake levers simultaneously.
- Avoid sudden, hard braking, especially with the front brake, as this can cause loss of control.

- Practice braking at low speeds to get a feel for the scooter's stopping distance.

### Adjusting Handlebar Height:

The handlebar height can be adjusted to suit the rider's height for optimal comfort and control.

1. Locate the quick-release clamp on the handlebar stem.
2. Open the quick-release clamp.
3. Adjust the handlebar to the desired height. Ensure the minimum insertion mark on the stem is not visible.
4. Close the quick-release clamp firmly. If it feels loose, tighten the adjustment nut on the opposite side of the clamp.



Image: Detail of the dual brakes and non-slip foot deck.

Your browser does not support the video tag.

Video: Official video demonstrating the Aosom Youth Kick Scooter in use, highlighting its adjustable handlebar and suitability for teens.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your scooter.

- **Tire Pressure:** Check tire pressure regularly and inflate to the recommended PSI (pounds per square inch) found on the tire sidewall. Properly inflated tires improve ride quality and prevent flats.
- **Brake Inspection:** Periodically inspect brake cables, levers, and pads for wear or damage. Ensure brakes engage smoothly and effectively. Adjust if necessary.
- **Cleaning:** Clean the scooter with a damp cloth and mild soap. Avoid using harsh chemicals or abrasive cleaners. Dry thoroughly after cleaning.
- **Fastener Check:** Regularly check all bolts, nuts, and screws for tightness. Tighten any loose fasteners to prevent parts from detaching during use.
- **Storage:** Store the scooter in a dry, cool place away from direct sunlight and moisture to prevent rust and material degradation.



Image: Detail of the front wheel and brake.



Image: Detail of the rear wheel and brake.

## 6. TROUBLESHOOTING

Here are some common issues and their solutions:

| Problem                              | Possible Cause                           | Solution                                                                                                                       |
|--------------------------------------|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Scooter feels unstable or wobbly     | Loose handlebar or wheel fasteners.      | Check and tighten all bolts, especially on the handlebar stem and wheel axles.                                                 |
| Brakes are not effective             | Brake cables are loose or pads are worn. | Adjust brake cable tension. Inspect brake pads for wear and replace if necessary. Ensure brake levers are properly positioned. |
| Tires are flat or losing air quickly | Low tire pressure or puncture.           | Inflate tires to recommended PSI. Check for punctures and repair or replace the inner tube if needed.                          |

| Problem                   | Possible Cause                                  | Solution                                                                                                                               |
|---------------------------|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Wheels do not spin freely | Over-tightened wheel nuts or misaligned brakes. | Loosen wheel nuts slightly (ensure they are still secure). Adjust brake calipers to ensure they are not rubbing against the wheel rim. |

## 7. SPECIFICATIONS

Detailed specifications for the Aosom Youth Kick Scooter:

- **Brand:** Aosom
- **Model Name:** Kids Scooter
- **ASIN:** B08BN4LFN8
- **UPC:** 842525164160
- **Color:** Blue
- **Age Range (Description):** Big Kid (Recommended 5+ years old)
- **Weight Limit:** 220 Pounds
- **Overall Dimensions:** 53.25" L x 22.75" W x 34.75" - 37" H
- **Front Tire Diameter:** 16 Inches
- **Rear Tire Diameter:** 12 Inches
- **Number of Wheels:** 2
- **Wheel Material:** Rubber
- **Frame Material:** Steel / Metal
- **Handlebar Type:** Adjustable
- **Brake Style:** Front and Rear Dual Braking
- **Item Weight:** 18 Pounds
- **Included Components:** Adjustable Handlebar, Rear Dual Brakes



Image: Scooter dimensions overview.

## 8. WARRANTY

This Aosom Youth Kick Scooter comes with a **1 Year Warranty Against Manufacturer Defects**. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or normal wear and tear.

## 9. SUPPORT

If you encounter any issues or have questions regarding your Aosom Youth Kick Scooter that are not addressed in this manual, please contact Aosom customer service. Refer to your product packaging or the Aosom website for the most current contact information.

For online support and additional resources, visit the official Aosom website: [www.aosom.com](http://www.aosom.com)

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B08BN4LFN8>

More documents and user manuals: <https://manuals.plus/>