

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KOBI](#) /

› [Kobi Air Fryer User Manual](#)

KOBI AF55LBLK

Kobi Air Fryer User Manual

Model: AF55LBLK

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is ETL Listed, ensuring it meets safety standards.

PRODUCT OVERVIEW

The Kobi Air Fryer is designed to provide a healthier alternative to traditional deep frying, utilizing rapid air circulation to cook food with significantly less oil. This section details the main components and features of your air fryer.



Main Unit and Control Panel

This image displays the Kobi Air Fryer's sleek black exterior and its intuitive LED touch control panel. The control panel features dedicated buttons for various cooking functions, temperature and time adjustments, and power controls. The large handle for the cooking basket is prominently visible.

8 Cooking Presets

Customize to suit your own personal taste



Fries



Chicken



Steak



Shrimp



Cup-Cake



Fish



Vegetables



Bacon



8 Cooking Presets

The Kobi Air Fryer comes equipped with 8 convenient preset programs to simplify your cooking. These include options for Fries, Chicken, Steak, Shrimp, Cupcakes, Fish, Vegetables, and Bacon, allowing for quick and optimized cooking with a single touch.

Fry with 85% Less Fat

Less oil, and More Flavor.



Air Fry



Traditional Deep Fry

Healthier Frying with 85% Less Fat

This image illustrates the core benefit of air frying: achieving crispy results with significantly less oil compared to traditional deep frying. The Kobi Air Fryer uses hot air circulation to cook food, reducing fat content by up to 85% while maintaining flavor and texture.

Rapid 360° Heat Circulation

Cook your food in minutes! Enjoy fast cooking thanks to powerful air fryer's rapid air circulation



Rapid 360° Heat Circulation

The Kobi Air Fryer employs rapid 360-degree heat circulation technology to ensure even and efficient cooking. This system circulates hot air around the food, resulting in uniformly cooked and crispy dishes. Features like Fast Preheat, Quick Thaw, and Auto-off enhance convenience.

Trendy & Compact Design

Compared to cylindrical air fryers, our air fryer's square frame saves counter space without sacrificing its capacity.



Trendy & Compact Design

Despite its generous capacity, the Kobi Air Fryer features a square frame design that saves counter space. Its modern aesthetic allows it to blend seamlessly into any kitchen decor, making it a practical and stylish appliance.

Enjoy a Variety of Delicacies

100 Delicious recipes included!



Enjoy a Variety of Delicacies

The air fryer is versatile, capable of preparing a wide range of dishes from crispy fried foods to roasted meats and vegetables. This image shows skewers being cooked in the air fryer, alongside fresh salads, demonstrating the diverse meal options possible.

Ergonomic Design

The fryer's touch screen display is angled to face you, increasing visibility and ease of use



Ergonomic Design

The air fryer's touch screen display is angled at 35 degrees, enhancing visibility and ease of use. This ergonomic consideration makes interacting with the control panel more comfortable and intuitive during operation.

5.8-Quart Large Basket

BPA-Free & PFOA Free Non-Stick Basket

You can easily and effectively estimate how many servings of a recipe you can make, simply based on the size of your 5.8-quart air fryer



Dishwasher Safe



Removable Basket

5.8-Quart Large Non-Stick Basket

The Kobi Air Fryer features a spacious 5.8-quart square nonstick basket, ideal for cooking large ingredients and serving 3-5 people. The basket is BPA-free and PFOA-free, ensuring food safety, and is also removable and dishwasher safe for easy cleaning.

100 Free Recipes Book

Our Kobi chefs handcrafted over 100 delicious recipes to inspire ideas for every meal.



100 Free Recipes Book Included

To help you get started and explore the full potential of your air fryer, a recipe book with 100 delicious and easy recipes is included. This resource provides inspiration for a wide variety of meals you can prepare.

SETUP AND FIRST USE

Unpacking

1. Carefully remove the air fryer and all packaging materials from the box.
2. Remove any stickers or labels from the appliance. Ensure all protective films, especially from the control panel and basket, are completely removed.
3. Check that all components are present and undamaged.

Initial Cleaning

- Wash the removable nonstick basket and crisper plate thoroughly with hot water, dish soap, and a non-abrasive sponge. These parts are also dishwasher safe.
- Wipe the inside and outside of the appliance with a damp cloth.
- Do not immerse the main unit in water or any other liquid.
- Ensure all parts are completely dry before use.

Placement

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is at least 6 inches (15 cm) of free space on the back, sides, and above the appliance to allow for proper air circulation.
- Do not place the appliance against a wall or other appliances.

First Use Preheating

For best results and to eliminate any manufacturing odors, it is recommended to preheat the air fryer before its first use without any food inside.

1. Plug the power cord into a grounded wall outlet.
2. Set the temperature to 400°F (200°C) and the timer for 10-15 minutes.
3. Allow the unit to run through the cycle. A slight odor may be present, which is normal for the first use.
4. Once complete, unplug the unit and let it cool down completely before proceeding with cooking.

OPERATING INSTRUCTIONS

Control Panel Overview

The Kobi Air Fryer features an intuitive LED touch display for easy operation.

- **Power Button:** Turns the unit on/off and starts/pauses cooking.
- **Temperature Controls (Up/Down Arrows):** Adjusts cooking temperature from 170°F to 400°F.
- **Time Controls (Up/Down Arrows):** Adjusts cooking time.
- **Preset Icons:** One-touch buttons for common dishes (Fries, Chicken, Steak, Shrimp, Cupcakes, Fish, Vegetables, Bacon).

General Cooking Steps

1. **Prepare Food:** Place your ingredients in the air fryer basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the basket back into the air fryer until it clicks securely into place.
3. **Power On:** Press the Power button to turn on the unit.

4. Set Temperature and Time:

- **Manual Setting:** Use the Temperature and Time control arrows to set your desired cooking parameters.
- **Preset Program:** Select one of the 8 preset icons. The unit will automatically set the optimal temperature and time for that food type. You can still adjust these settings manually after selecting a preset if needed.

5. Start Cooking:

Press the Power button again to begin the cooking cycle.

6. Shake Reminder:

For certain foods, the air fryer may beep to remind you to shake the basket for even cooking. Carefully pull out the basket, shake the contents, and reinsert it. Cooking will resume automatically.

7. Cooking Complete:

The air fryer will beep when the cooking time is complete. Carefully remove the basket and transfer the cooked food.

Cooking Tips

- **Preheating:** Always preheat the air fryer for 3-5 minutes before adding food for best results and crispiness.
- **Oil Usage:** While not always necessary, a light spray of oil can enhance crispiness for some foods.
- **Batch Cooking:** For larger quantities, cook in smaller batches to ensure even air circulation and crisping.
- **Food Size:** Cut food into uniform pieces for consistent cooking.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your Kobi Air Fryer and ensure optimal performance.

1. Unplug and Cool:

Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.

2. Clean Basket and Crisper Plate:

- The removable nonstick coated basket and crisper plate are dishwasher safe.
- Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak the basket in warm, soapy water for about 10 minutes.
- Ensure these parts are PFOA-free and BPA-free.

3. Clean Interior:

Wipe the interior of the air fryer with a damp cloth or non-abrasive sponge. For baked-on food, a small amount of mild dish soap can be used. Avoid abrasive cleaners or metal scouring pads.

4. Clean Exterior:

Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive materials, as they may damage the finish.

5. Storage:

Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your Kobi Air Fryer, consult the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Ensure the power cord is securely plugged into a working grounded outlet. Check your circuit breaker. If still not working, contact customer support.
Food is not crispy.	Basket overfilled; insufficient preheating; food not shaken; too much moisture.	Do not overfill the basket. Preheat the air fryer before adding food. Shake the basket halfway through cooking. Pat dry moist ingredients before air frying. Lightly spray with oil if desired.
White smoke coming from the appliance.	Grease residue from previous use; cooking fatty foods; protective film not removed.	Clean the basket and interior thoroughly after each use. For fatty foods, drain excess fat during cooking. Ensure all protective films and stickers are removed from the unit before first use.
Appliance smells during first use.	Normal manufacturing residue.	This is normal. Run the air fryer empty for 10-15 minutes at 400°F (200°C) before first use to burn off any residual odors. Ensure good ventilation.
Basket does not slide in properly.	Basket not aligned correctly; debris in the drawer.	Ensure the basket is properly aligned with the grooves. Check for any food particles or debris obstructing the drawer.

SPECIFICATIONS

Feature	Detail
Model Name	AF55LBLK
Brand	KOBI
Capacity	5.8 Quarts
Product Dimensions (D x W x H)	13.75" x 10.5" x 12.8"
Basket Dimension	8" x 8" x 5.5"
Wattage	1700 Watts
Voltage	120 Volts (USA and Canada only)
Temperature Range	170°F - 400°F
Control Method	Touch
Material	Stainless Steel (Inner & Outer)
Nonstick Coating	Yes, PFOA-free & BPA-free
Dishwasher Safe Parts	Removable Basket
Certifications	ETL Listed / FDA Compliant

WARRANTY AND SUPPORT

Kobi products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Kobi website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Kobi Customer Service. Contact details can typically be found on the Kobi website or on the product packaging.

You can also refer to the official user manual PDF for more detailed information:[Kobi Air Fryer User Manual \(PDF\)](#)

© 2023 Kobi. All rights reserved.

Related Documents - AF55LBLK

	<p>Kobi 3.7 Quart Air Fryer AFM35LBLK Instruction Manual</p> <p>User manual for the Kobi 3.7 Quart (3.5 Liter) Air Fryer, model AFM35LBLK. Includes safety instructions, operating guide, cleaning, troubleshooting, and warranty information for healthier cooking.</p>
	<p>KOBI LISSE 2 ST 45W BLACK Tower Fan User Manual and Safety Guide</p> <p>Comprehensive user manual and safety guide for the KOBI LISSE 2 ST 45W BLACK tower fan, detailing assembly, operation, maintenance, and technical specifications.</p>
	<p>SOLAR LED MHCS 10W - Kobi Solar Floodlight with Motion Sensor and Remote Control</p> <p>Comprehensive guide to the Kobi SOLAR LED MHCS 10W solar-powered LED floodlight, detailing technical specifications, operating modes, remote control functions, installation, battery replacement, and disposal information.</p>
	<p>Kobi 2025/26: Katalog Oświetlenia LED</p> <p>Przegląd katalogu produktów oświetleniowych Kobi na lata 2025/26. Odkryj szeroką gamę innowacyjnych rozwiązań LED, od żarówek po systemy oświetleniowe, zaprojektowane z myślą o jakości, funkcjonalności i estetyce.</p>

Kobi SMART LED GS 9.5W E27 RGB WW WIFI Product Information Sheet

Product information sheet for the Kobi SMART LED GS 9.5W E27 RGB WW WIFI light source, detailing energy efficiency, luminous flux, power consumption, and other technical specifications as per EU regulations.