

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Mando](#) /
- > [Mando MP-18HD 18000HC BTU Split Air Conditioner \(Hot and Cold\) User Manual](#)

Mando MP-18HD

Mando MP-18HD 18000HC BTU Split Air Conditioner User Manual

Model: MP-18HD | Brand: Mando

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Mando MP-18HD 18000HC BTU Split Air Conditioner. Please read this manual thoroughly before using the appliance and retain it for future reference. This unit is designed to provide both cooling and heating functions for your indoor environment.



Image: The Mando MP-18HD Split Air Conditioner indoor unit, shown in white, with its accompanying remote control. This image illustrates the primary component visible within the room.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- **Electrical Safety:** Ensure the power supply matches the unit's specifications (125V, 900W). Do not use damaged power cords or plugs.
- **Installation:** Installation must be performed by qualified personnel in accordance with local electrical and safety codes. Improper installation can lead to electric shock, fire, or water leakage.
- **Maintenance:** Disconnect power before cleaning or performing any maintenance. Do not attempt to repair the unit yourself. Contact qualified service personnel.
- **Refrigerant:** This unit uses R-410A refrigerant. Handle with care and ensure proper ventilation during service.
- **Children and Pets:** Keep children and pets away from the unit during operation and maintenance.

3. PACKAGE CONTENTS

Verify that all components are present upon unpacking:

- 1 x Mando MP-18HD 18000HC BTU Split Air Conditioner Indoor Unit
- 1 x Mando MP-18HD 18000HC BTU Split Air Conditioner Outdoor Unit
- 1 x Remote Control
- 1 x User Manual (this document)
- Installation Accessories (e.g., piping, wiring, drainage hose - specific items may vary)

4. SETUP

Installation of a split air conditioner requires specialized tools and knowledge. It is highly recommended that you arrange for professional installation by a certified technician.

4.1. Choosing an Installation Location

- **Indoor Unit:** Select a location that allows for even air distribution throughout the room, away from direct sunlight or heat sources. Ensure there is sufficient space around the unit for maintenance.
- **Outdoor Unit:** Choose a well-ventilated area, free from obstructions, and where noise will not disturb neighbors. Ensure it is on a stable, level surface.

4.2. Installation Steps (Overview for Professional Installers)

1. Mount the indoor unit securely on the wall.
2. Install the outdoor unit on a stable base.
3. Connect the refrigerant piping between the indoor and outdoor units.
4. Connect the electrical wiring according to the wiring diagram provided with the unit.
5. Install the drainage hose for condensate removal.
6. Perform a vacuum test and charge the system with R-410A refrigerant if necessary.
7. Test the unit's operation in all modes.

5. OPERATING INSTRUCTIONS

Your Mando MP-18HD air conditioner offers various modes and settings for optimal comfort.

5.1. Remote Control Overview

The remote control allows you to manage all functions of the air conditioner. Point the remote control directly at the indoor unit when operating.

5.2. Basic Operation

- **Power On/Off:** Press the **ON/OFF** button to start or stop the unit.
- **Mode Selection:** Press the **MODE** button to cycle through available modes: **Cool**, **Heat**, **Fan**, **Dry**, and **Auto**.
- **Temperature Adjustment:** Use the **TEMP UP** (▲) and **TEMP DOWN** (▼) buttons to set your desired temperature.
- **Fan Speed:** Press the **FAN SPEED** button to select between **Low**, **Medium**, **High**, or **Auto** fan speeds.
- **Swing Function:** Activate the **SWING** button for automatic louver movement to distribute air evenly.

5.3. Advanced Functions

- **Timer:** Set the unit to turn on or off automatically after a specified period using the **TIMER ON/OFF** buttons.
- **Sleep Mode:** The **SLEEP** function adjusts the temperature gradually for comfortable sleep and energy saving.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner. Always disconnect power before performing maintenance.

6.1. Air Filter Cleaning

Clean the air filters every two weeks, or more frequently if the unit is used heavily or in dusty

environments.

1. Open the front panel of the indoor unit.
2. Remove the air filters.
3. Wash the filters with lukewarm water and a mild detergent. Rinse thoroughly.
4. Allow filters to dry completely in a shaded area before reinstalling.

6.2. Outdoor Unit Cleaning

Periodically check and clean the outdoor unit's coils and fins to ensure proper airflow and heat exchange. Remove any debris, leaves, or dirt. This should ideally be done by a professional.

6.3. Seasonal Checks

- **Before Summer:** Ensure the drainage hose is clear and free of blockages. Check for any unusual noises or vibrations.
- **Before Winter:** Verify that the heating function operates correctly. Clean filters and ensure the outdoor unit is clear of snow or ice.

7. TROUBLESHOOTING

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Unit does not start	No power, circuit breaker tripped, remote control batteries low.	Check power supply, reset breaker, replace remote batteries.
Insufficient cooling/heating	Dirty air filters, blocked outdoor unit, wrong mode selected, room too large.	Clean filters, clear outdoor unit, select correct mode, ensure unit size matches room.
Unusual noise	Loose parts, foreign objects in fan, unit not level.	Check for loose parts, remove obstructions, ensure unit is level. If noise persists, contact service.
Water leakage from indoor unit	Blocked drainage hose, improper installation.	Check and clear drainage hose. If problem persists, professional inspection is required.

If the problem persists after attempting these solutions, please contact Mando customer support or a qualified service technician.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Mando
Model Number	MP-18HD
Part Number	1116373311022001
Type	Split Air Conditioner (Hot and Cold)
Cooling/Heating Capacity	18000HC BTU
Color	White
Power Source	Corded Electric
Voltage	125 Volts
Wattage	900 Watts
Installation Method	Split System
Noise Level	50 Decibels
Refrigerant	R-410A
Product Dimensions (L x W x H)	93.6 x 38 x 23.9 cm
Item Weight	43 Kilograms
Batteries Required	No

9. WARRANTY AND SUPPORT

Your Mando MP-18HD Split Air Conditioner comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage period and what is covered.

For technical support, service requests, or warranty claims, please contact Mando customer service. Contact details are typically found on the product packaging or the official Mando website.

Extended warranty plans may be available for purchase separately to provide additional coverage beyond the standard manufacturer's warranty.

