

DmofwHi DSC101

DmofwHi Electric Garlic Chopper Instruction Manual

Model: DSC101

INTRODUCTION

Thank you for choosing the DmofwHi Electric Garlic Chopper, Model DSC101. This cordless mini food chopper is designed for quick and efficient preparation of various ingredients. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep this manual for future reference.

Important Safety Information

- Always ensure the chopper is fully assembled and the lid is securely in place before operation.
- Keep hands and utensils away from the moving blades during operation.
- The blades are very sharp. Handle with extreme care during assembly, disassembly, and cleaning.
- Do not immerse the motor unit (top part) in water or any other liquid. Clean with a damp cloth only.
- This appliance is not intended for use by children. Keep out of reach of children.
- Do not attempt to chop hard ingredients like coffee beans, ice, or frozen foods, as this may damage the blades or motor.
- Ensure the USB charging port is dry before connecting the charging cable.
- Do not overfill the chopper bowl. Observe the MAX fill line.
- If the appliance malfunctions, discontinue use immediately and contact customer support.

PRODUCT COMPONENTS

The DmofwHi Electric Garlic Chopper consists of the following parts:

- **Motor Unit (Lid):** Contains the motor, control button, and USB charging port.
- **304 Stainless Steel Blade Assembly:** Sharp blades for chopping.
- **Transparent Chopper Bowl (250ml):** For holding ingredients during chopping.
- **USB Charging Cable:** For recharging the internal battery.



Image: Main components of the DmofwHi Electric Garlic Chopper.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, wash the chopper bowl and blade assembly with warm, soapy water. Rinse thoroughly and dry completely. Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water.
3. **Charge Battery:** The chopper is USB rechargeable. Connect the provided USB cable to the charging port on the motor unit and plug the other end into a USB power source (e.g., computer, wall adapter). Charge for approximately 3 hours for a full charge. The indicator light will show charging status (e.g., red for charging, off or blue for fully charged, refer to specific product indicator if available).
4. **Assemble Blade:** Place the blade assembly onto the central pin inside the chopper bowl. Ensure it sits securely.



Image: Inserting the blade assembly into the chopper bowl.

OPERATING INSTRUCTIONS

1. **Prepare Ingredients:** Cut ingredients into small pieces (approximately 1-2 cm) before placing them into the chopper bowl. This ensures efficient chopping and prevents overloading.
2. **Load Chopper:** Place the prepared ingredients into the chopper bowl, around the blade assembly. Do not exceed the "MAX" fill line indicated on the bowl.



Image: Adding ingredients to the chopper bowl.

3. **Secure Motor Unit:** Place the motor unit (lid) onto the chopper bowl, aligning it properly. The magnetic child safety lock will engage, allowing the device to operate. If not properly aligned, the chopper will not start.
4. **Chop:** Press and hold the power button on top of the motor unit to begin chopping. Release the button to stop. Pulse for coarse chopping or hold for finer results. For best results, use short pulses.



Image: Operating the chopper with a single button press.

5. **Retrieve Food:** Once chopping is complete, remove the motor unit, then carefully remove the blade assembly. Empty the chopped ingredients from the bowl.



Image: Finely chopped ingredients ready for use.

Example Uses

- Chop garlic, ginger, chili, and onions for cooking.
- Mince small amounts of meat.
- Prepare purees for baby food (ensure ingredients are soft).
- Chop nuts for baking or garnishes.

MEET

all your needs
of different
seasonings



pumpkin



garlic



ginger



veggies



chili



walnut



peanut



meat

Image: The chopper can process various ingredients for different culinary needs.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your DmofwHi Electric Garlic Chopper.

- **Disassembly:** Separate the motor unit, blade assembly, and chopper bowl.
- **Chopper Bowl and Blade:** Wash the chopper bowl and blade assembly with warm, soapy water immediately after use. Rinse thoroughly and dry completely. Be extremely careful when handling the sharp blades.
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or place it in a dishwasher.
- **Storage:** Store all components in a dry place.
- **Dishwasher Safety:** The chopper bowl and blade are **not** dishwasher safe. Hand wash only.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chopper does not start.	Lid not properly secured. Battery is low or depleted.	Ensure the motor unit is correctly aligned and securely placed on the chopper bowl. The magnetic safety lock must engage. Charge the chopper for at least 3 hours.

Problem	Possible Cause	Solution
Ingredients are not chopped evenly.	Ingredients are too large. Overfilled bowl. Not pulsing correctly.	Cut ingredients into smaller, uniform pieces before chopping. Do not exceed the MAX fill line. Use short, intermittent pulses rather than a continuous press.
Motor sounds strained or stops during operation.	Overloaded with ingredients. Ingredients are too hard. Low battery.	Reduce the amount of ingredients in the bowl. Avoid chopping very hard items. Charge the chopper.

Relevant Videos

Watch this video for a demonstration of the chopper's functionality:

Your browser does not support the video tag.

Video: Demonstration of the DmofwHi Cordless Kitchen Chopper in use.

See how the chopper can be used for various kitchen tasks:

Your browser does not support the video tag.

Video: Overview of kitchen finds, including the DmofwHi chopper for dicing ingredients.



SPECIFICATIONS

Feature	Detail
Brand	DmofwHi
Model Name	DSC101
Special Feature	USB Rechargeable
Product Dimensions	3.94"D x 3.94"W x 4.33"H
Color	Blue
Bowl Capacity	250ml (8.5 Ounces)
Recommended Uses	Chop (Garlic, Ginger, Onion, Meat, etc.)
Number of Speeds	1
Product Care Instructions	Hand Wash (Motor unit wipe clean)
Included Components	Chopping Blade, Container, Lid
Dishwasher Safe	No
Blade Material	304 Stainless Steel
Power Source	Battery Powered (1 Lithium Ion battery included)
Item Weight	13.1 ounces

Feature	Detail
Wattage	37 watts

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided with your purchase or visit the official DmofwHi website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question